European Space Agency Research and Science Support Department Planetary Missions Division

ROSETTA-COSIMA

To Planetary Science Archive Interface Control Document

FMI_S-COS-ICD-001-AD-05

Issue 1.5

09 Sebtember 2015

Prepared by: Maria Genzer, Jouni Rynö, FMI

Approved by: Johan Silen, FMI



Distribution List

Recipient	Organisation	Recipient



Change Log

Date	Sections Changed	Reasons for Change
1 March 2004	All sections	Draft 2
23.January.2006	All sections	First official release
9 October. 2006	1.5, 2, 3,4.3	Dataset delivery scheme updated, geometry information added. All the labels updated
12 December 2008		Spectrum data contains mass scale
3 February 2011	2.3, 2.4.1, 3.2.3, 4.3	New formats for images, new products for scans and heating
19 March 2015		Update in the labels, delivery schedule
09 September 2015	4.3.6	Update HEAT.TAB

TBD ITEMS

Section	Description	



Table Of Contents

1 INTRODUCTION	4
1.1 Purpose and Scope	Δ
1.2 Archiving Authorities.	
1.3 Contents.	
1.4 Intended Readership	
1.5 APPLICABLE AND REFERENCE DOCUMENTS.	
1.5 APPLICABLE AND REFERENCE DOCUMENTS	
1.7 Contact Names and Addresses.	
2 OVERVIEW OF INSTRUMENT DESIGN, DATA HANDLING PROCESS AND PRODUC	T GENERATION
	7
2.1 Scientific Objectives	7
2.2 Instrument sub-systems.	
2.2.1 TMU	
2.2.2 COSISCOPE	
2.2.3 Primary Ion Source (PIS)	
2.2.4 Primary Ion Beam System (PIBS)	
2.2.5 Time-Of-Flight Spectrometer (TOF)	
2.2.6 TDC	
2.3 Data Handling Process	
2.4 Overview of Data Products	
2.4.1 General	
2.4.2 Software	
2.4.2.1 Data processing software	
2.4.3 Documentation.	
2.4.4 Derived and other Data Products.	
2.4.5 Ancillary Data Usage	
3 ARCHIVE FORMAT AND CONTENT	15
3.1 Deliveries and Archive Volume Format	15
3.2 Conventions	
3.2.1 Data Set ID Formation	
3.2.2 Data Directory Naming Convention	
3.2.3 Filenaming Convention COSIMA data products will be named as follows:	
3.3 Standards Used in Data Product Generation.	16
3.3.1 PDS Standards.	
3.3.2 Time Standards.	
3.3.2.1 Spacecraft Clock Count, OBT.	
3.3.3 Reference Systems	
3.3.4 Other Applicable Standards.	
3.4 Data Validation.	
3.5 Content	
3.5.1 Volume Set	
3.5.2 Data Set	
3.5.3 Directories	
3.5.3.1 Root Directory	
y .	
3.5.3.3 Catalog Directory	
3.5.3.5 Browse Directory and Browse Files.	
3.5.3.6 Geometry Directory	
3.5.3.7 Software Directory	

3.5.3.8 Gazetter Directory	18
3.5.3.9 Label Directory	
3.5.3.10 Document Directory	18
3.5.3.11 Extras Directory	19
3.5.3.12 Data Directory	19
4 DETAILED INTERFACE SPECIFICATIONS	20
4.1 Structure and Organization Overview	
4.2 Data Sets, Definition and Content	
4.3 Data Product Design	
4.3.1 Time-of flight spectrum product	
4.3.1.1 General description	
4.3.1.2 Label example	
4.3.2 Peak list product	
4.3.2.1 General Description.	
4.3.2.2 Label example	
4.3.3 Time-of-flight spectrum housekeeping data product	
4.3.3.1 General description	
4.3.3.2 Label example	
4.3.4 Scan data product	
4.3.4.1 General description	
4.3.4.2 Label example	
4.3.5 Scan housekeeping data product	
4.3.5.1 General description	
4.3.5.2 Label example	
4.3.6 Heating data product	
4.3.6.1 General description.	
4.3.6.2 Label example	
4.3.7 Cleaning data product	
4.3.8 Cleaning housekeeping data product	
4.3.8.1 General description	
4.3.8.2 Label example.	
4.3.9 COSISCOPE image product	
4.3.9.1 General description.	
4.3.9.2 Label example.	
4.3.10 COSISCOPE dust grain list product	
4.3.10.1 General description.	
4.3.10.2 Label template	
4.3.11 COSISCOPE housekeeping product	62
4.3.11.1 General information.	62
4.3.11.2 Label example	
4.3.12 Substrate history ancillary product	
4.3.12.1 General description.	
4.3.12.2 Label example	
5 APPENDIX: DIRECTORY LISTING OF DATA SET RO-CAL-COSIMA-3-V3.	

1 Introduction

1.1 Purpose and Scope

The purpose of this EAICD (Experimenter to (Science) Archive Interface Control Document) is two fold. First it provides users of the the COSIMA instrument with a detailed description of the product and a description of how it was generated, including data sources and destinations. Secondly, it is the official interface between the COSIMA instrument team and Rosetta archiving authority.

1.2 Archiving Authorities

ESA's Planetary Science Archive (PSA).

1.3 Contents

This document describes the data flow of the COSIMA instrument on ROSETTA from the spacecraft until the insertion into the PSA for ESA. It includes information on how data were processed, formatted, labeled and uniquely identified. The document discusses general naming schemes for data volumes, data sets, data and label files. Standards used to generate the product are explained. Software that may be used to access the product is explained further on.

The design of the data set structure and the data product is given. Examples of these are given in the appendix.

1.4 Intended Readership

The staff of the archiving authority (Planetary Science Archive, ESA, RSSD, design team) and any potential user of the COSIMA data.

1.5 Applicable and Reference Documents

[AD-01] Planetary Data System Data Preparation Workbook, February 17, 1995, Version 3.1, JPL, D-7669, Part 1

[AD-02] Planetary Data System Standards Reference, August 1, 2003, Version 3.6, JPL, D-7669, Part 2

[AD-03] ROSETTA Archive Generation, Validation and Transfer Plan, October 6, 2005, RO-EST-PL-5011, Issue 2, Revision 2

[AD-04] Rosetta Time Handling, February 28, 2006, RO-EST-TN-3165, Issue 1, Revision 1

[RD-01] COSIMA User Manual, Version 3.7, 16 June 2010

[RD-02] Kissel et al:"Kissel, J. et al., COSIMA - High resolution time-of-flight secondary ion mass spectrometer for the analysis of cometary dust particles onboard Rosetta, Space Sci. Rev., 128(1-4), 823-867. doi:10.1007/s11214-006-9083-0. 2007

[RD-03] Dahl, D.A., INEEL, Idaho Falls, Idaho 83415, DHL@inel.gov: The SIMION software manual, 1997 (and later versions).

[RD-04] Engrand C., Kissel J., Krueger F.R., Martin P., Silén J., Thirkell L., Thomas R., Varmuza K.: "Chemometric evaluation of time-of-flight secondary ion mass spectrometry data of minerals in the frame of future *in situ* analyses of cometary material by COSIMA onboard ROSETTA", *Rapid Commun. Mass Spectrom.* 20, 1361-1368, 2006.

[RD-05] Jessberger, E.K., J. Kissel (1991): Chemical properties of cometary dust and a note on carbon isotopes. in: *Comets in the post-Halley era*. Eds. R. Newburn, M. Neugebauer, J. Rahe. Springer Verlag, Heidelberg, 1075-1092

[RD-06] Kissel, J., R.Z. Sagdeev, J.L. Bertaux, V.N. Angarov, J. Audouze, J.E. Blamont, K. Büchler, H. von Hoerner, N.A. Inogamov, V.N. Khromov, W. Knabe, F.R. Krueger, Y. Langevin, A.C. Levasseur-Regourd, G.G. Managadze, S.N. Podkolzin, V.D. Sharipo, S.R. Tabaldyev, and B.V. Zubkov":

- "Composition of Comet Halley Dust Particles From VEGA Observations", NATURE, Vol.321, No.6067, 280–282, 1986.
- [RD-07] Kissel, J., D.E. Brownlee, K. Büchler, B.C. Clark, H. Fechtig, E. Grün, K. Hornung, E.B. Igenbergs, E.K. Jessberger, F.R. Krueger, H. Kuczera, J.A.M. McDonnell, G.E. Morfill, J. Rahe, G.H. Schwehm, Z. Sekanina, N.G. Utterback, H.J. Völk, and H. Zook: "Composition of Comet Halley Dust Particles From GIOTTO Observations", NATURE (Encounters with Comet Halley The First Results), Vol. 321, NO. 6067, 336–337, 1986.
- [RD-08] Kissel, J. and F.R. Krueger: "The Organic Component in Dust From Comet Halley as Measured by the PUMA Mass-Spectrometer on Board VEGA 1", NATURE 326, 755–760, 1987.
- [RD-09] Krueger, F.R.: "Dust Collector Materials for SIMS Analysis in Space", A Feasibility Study for CoMA, part 1, Aug. 1988, part 2, Jan. 1989, and part 3, Sept. 1989.
- [RD-10] Krueger, F.R., A. Korth, and J. Kissel: "The Organic Matter of Comet Halley as Inferred by Joint Gas Phase and Solid Phase Analyses", Space Science Reviews 56, 167–175, 1991.
- [RD-11] Mamyrin B.A., V.I. Karatyev, D.V. Shmikk, and V.A. Zagulin: "Mass-Reflectron A New High-Resolution Nonmagnetic Time-of-Flight Mass-Spectrometer" Zh Eksp. i Teor. Fiz. 64, 82 or: Sov. Phys. JETP 37, No.1, July 1973.
- [RD-12] Mazets, E.P., R.Z. Sagdeev, R.L. Aptekar, S.V. Golenetskii, Yu.A. Guryan, A.V. Dyachkov, V.N. Ilyinskii, V.N. Panov, G.G. Petrov, A.V. Savvin, I.A. Sokolov, D.D. Frederiks, N.G. Khavenson, V.D. Shapiro, and V.I. Shevchenko: "Dust in comet P/Halley from VEGA observations", Astronomy and Astrophysics, 187, 699–706, 1987.
- [RD-13] McDonnell, J.A.M., S.F. Green, E. Grün, J. Kissel, S. Nappo, G.S. Pankiewicz, and C.H. Perry: "In Situ Exploration of the Dusty Coma of Comet P/Halley at Giotto's Encounter: Flux Rates and Time Profiles From 10-19 kg to 10-5 kg", Adv. Space Res. Vol.9, No.3, 277–280, 1989.
- [RD-14] Schwab, M., CEMEC GmbH, Obererlbach, FRG: Design of the COSIMA Target Manipulator, (private communication), 1998.
 - [RD-15] Stephan, T.: "TOF-SIMS in Cosmochemistry", Planet. Space Sci., 49, 859-906, 2001.
- [RD-16] Varmuza K., W. Werther, F.R. Krueger, J. Kissel, E.R. Schmid: "Organic substances in cometary grains: Comparison of secondary ion mass spectral data and californium-252 plasma desorption data from reference compounds", Int. J. Mass Spectrom., 189, 79-92, 1999.
- [RD-17] Varmuza K., Kissel J., Krueger F. R., Schmid E. R.: "Chemometrics and TOF-SIMS of organic compounds near a comet", in Advances in Mass Spectrometry, Gelpi E., Ed.; Wiley & Sons, Chichester, Vol. 15, p. 229-246, 2001.
- [RD-18] Werther W., Demuth W., Krueger F. R., Kissel J., Schmid E. R., Varmuza K.: "Evaluation of mass spectra from organic compounds assumed to be present in cometary grains. Exploratory data analysis", J. Chemom., 16, 99-110, 2002.
- [RD-19] Zscheeg, H, J. Kissel, Gh. Natour, and E. Vollmer: "CoMA an Advanced Space Experiment For in Situ Analysis of Cometary Matter", Astrophsics and Space Science 195, 447–461, 1992.

1.6 Acronyms and Abbreviations

PDS

ANCDR	Ancillary Data Record
COSIMA	Cometary Secondary Ion Mass Analyzer
DDS	Data Distribution System
ESA	European Space Agency
FM	Flight Model
FMI	Finnish Meteorological Institute
HVC	High Voltage Control
LVC	Low Voltage Control
MPS	Max-Planc-Institut für Sonnensystemforschung

Planetary Data System

PIS Primary Ion Source

PIBS Primary Ion Beam System
PDF Portable Document Format
PSA Planetary Science Archive
REFDR Reformatted Data Record

RSDB Rosetta Database

SIMS Secondary Ion Mass Spectrometer

TBC To Be Confirmed
TBD To Be Defined
TBW To Be Written

TDC Time-to-Digital Converter
TMU Target Manipulator Unit

TOF Time-Of-Flight

UTC Universal Time Coordinated

1.7 Contact Names and Addresses

PDS datasets:

Finnish Meteorological Institute Johan Silén, Jouni Rynö, Maria Genzer E-mail: <u>firstname.lastname@fmi.fi</u>

Tel: + 358 9 19291 Fax: + 358 9 1929 4603

Address:

Finnish Meteorological Institute Observation Services P.O. Box 503 00101 Helsinki, Finland

Science issues:

Dr. Martin Hilchenbach Max-Planck-Institut für Sonnensystemforschung Max-Planck-Str. 2 37191 Katlenburg-Lindau Germany

Tel: +49 5556 979 162 Fax +49 5556 979 240

2 Overview of Instrument Design, Data Handling Process and Product Generation

2.1 Scientific Objectives

The in situ chemical analysis of solids in space is among the tasks which are technically most difficult. There are two main reasons for that: With a few exceptions solids in space are not abundant, and secondly it is not easy to remove small samples from the solid into the vacuum for the analysis in a mass spectrometer.

For COSIMA the objects of interest are cometary dust particles, which are abundant, indeed, in the neighbourhood of the comet nucleus. It remains, however, to collect and bring the particles to the entrance of the spectrometer.

Most mass spectrometers need parts of the sample to be analyzed, to carry an electronic charge. The process of removing an ion from the specimen is then the critical feature of the method to be chosen.

The only mass spectrometric data on cometary dust particles available to date, come from the dust impact mass spectrometers PIA and PUMA on the GIOTTO and VEGA spacecrafts, respectively. While other, remote, or indirect methods allow measurements of collective properties of the cometary dust, the mass spectrometers allowed the analysis of individual particles (cf Kissel et al. 1986a+b). Since then we know unambiguously that each particle is an intimate mixture of a mineral core and ices, and simple as well as complex organic molecules. Since the impact velocity was large (>60 km/s) mostly atomic ions were formed and analyzed in the Halley case. In a first attempt, however, Kissel and Krueger (1987) found evidence for the chemical nature of the organic cometary material. It is clear that not a few well known molecules constitute the cometary organics, but rather some chemical classes, with each being represented by a large number of individual substances. Indeed, it seems, that all stable molecules compatible with the chemical environment are formed and even cross-linked between them.

COSIMA therefore needed to be based on a method which is readily available in laboratory, and which allows for tracing the ion directly to the molecular and structural form in which it was present in the solid. Since the size distribution of the dust particles is known (cf, Mazets et al. 1987, McDonnell et al. 1989) a reasonable ionizing beam focus should be achieved under the limitations of space instrumentation. Even though the method would be destructive, its sensitivity should be high enough to allow several analyses at different depths for one individual, say 20 µm particle.

To satisfy all these requirements we choose the method of Secondary Ion Mass Spectroscopy (SIMS). A fast primary ion, in this case 115 In $^+$ at 10 keV, impacts the sample and releases by desorption molecules of the material under test, of which typically 0.1 to 10 % are ionized, the so-called secondary ions. For sensitivity reasons, the analysis of a rather large mass range should be achieved simultaneously, which in turn leads to the type of a time-of-flight mass spectrometer. The mass resolution must be high enough to resolve isobaric ions, at least between atomic and molecular ions. The total ion mass should at least cover 3500 Da. In total, the COSIMA instrument has the following main functional hardware elements:

- the dust collector and target manipulator (TMU),
- COSISCOPE, a microscope CCD camera for target inspection,
- the primary ion source,
- the mass spectrometer including the ion extraction optics and the ion detector
- Electronics and computer.

It should be mentioned at this point, that COSIMA did profit from but is not identical to the earlier development of the CoMA instrument for the NASA mission CRAF (Zscheeg, 1992) which was canceled in 1992.

The entire development of COSIMA was challenged by the complexity of the cometary material which has to be expected. This has focused the goal of COSIMA on the identification of chemical classes and functional groups rather than the identification of individual substances. Consequently the system must have the capability to use the methods of chemometry to compress the raw data on board, which helps to reduce the data volume without losing any of the chemical information.

There is also another important aspect for COSIMA, which comes from the rather long time the spacecraft travels from launch in 2004 until the core of the measurements takes place in 2014: Quite a large number of relevant results will be obtained from laboratory measurements with TOF SIMS, be it by the COSIMA team or be it in the published literature. In addition, NASA in its DISCOVERY program has several comet missions, which are expected to produce new, relevant data, before COSIMA enters its main analysis phase. Even if most of the flexibility is with the software involved, it is the hardware, which has to provide the resources necessary. Looking back at the fast development in the computer sector over the last ten years this alone is a demanding task, even without the complexity of an up to date analysis instrument.

The scientific return from COSIMA consists primarily of time-of-flight spectra supported by housekeeping data. In addition to this, a limited number of peaks presented as a peak list, may be available. The time-of-flight spectra are archived according to standard PDS rules. These spectra are calibrated to a preliminary mass scale by automatic software.

In addition to time-of-flight spectra, pictures of dust targets (substrates) taken by COSISCOPE camera, and lists of dust grains found on the targets, are also archived.

Operational history of each target substrate is given. The history contains information about substrate storage and expose periods, cleaning and heating actions, COSISCOPE camera images and grains lists and any spectra taken. The history product contains history from the moment substrates were installed in the COSIMA flight instrument.

2.2 Instrument sub-systems

COSIMA sub-systems are described in more detail in COSIMA paper [RD2]. Only a brief description is given here, as the paper can found in ASCII and in PDF form from the DOCUMENT directory.




Figure 1: COSIMA subsystemFigures schematics

2.2.1 TMU

The Target Manipulator Unit keeps track of, stores and moves dust collection substrates in the instrument. There are total of 24 target holders, each containing 3 substrates. The substrate itself is a 10*10 millimeter plate, each having different chemical properties. The TMU can also be used to scan a substrate in front of an ion beam. The operation of the TMU is constrained by heat dissipation and is in general slow (tens of minutes per operation).

The substrates can have the following position identifications::

STORAGE, in target storage

IMAGE, substrate image

GRAINS, dust position list

PEAKS, peak list acquisition

SCAN, total count acquition

SPECTRUM, spectrum acquistion

EXPOSE, exposed to the outside, still in TMU grasp

COLLECT, exposed to the outside

CLEAN, at beam cleaning position

HEAT, at chemistry (heating) station

In the substrate history, if the substrate is not in the STORAGE, EXPOSE, COLLECT or HEAT position, it is grasped by the TMU and usually moved to the analysis position for SPECTRUM, SCAN or PEAKS or in front of the COSISCOPE for IMAGE or GRAINS.

The 24 target holders are numbered with hexadecimal numbers from #C1 to #D8. The top substrate is marked with the number #100, the middle with #200 and the low with #300. The combination of these numbers give the substrate identification number used in the instrument commanding and data handling.

The subsrates have the following properties:

#1C1	Palladium, black
#2C1	Platinum, deep black
#3C1	Platinum, deep black
#1C2	Silver, 73 micrometer thickness, blank with rectangular hole 3.5x3.5mm
#2C2	Silver, 69 micrometer thickness, blank with AgTe spot of about 3 mm size at center
#3C2	Gold, 17 micrometer thickness, olivine particles
#1C3	Gold, 8 micrometer thickness
#2C3	Gold, 15 micrometer thickness
#3C3	Gold, 20-30 micrometer thickness
#1C4	Palladium, black
#2C4	Silver, 14 micrometer thickness
#3C4	Gold, 12 micrometer thickness
#1C5	Platinum, light black,
#2C5	Platinum, deep black
#3C5	Gold, 13 micrometer thickness
#1C6	Platinum, deep black
#2C6	Platinum, deep black
#3C6	Gold, 8 micrometer thickness
#1C7	Silver, blank

- #2C7 Silver, 21 micrometer thickness
- #3C7 Gold, 15 micrometer thickness
- #1C8 Platinum, deep black
- #2C8 Platinum, deep black
- #3C8 Gold, 20-30 micrometer thickness
- #1C9 Gold, 5-8 micrometer thickness
- #2C9 Gold, 5-8 micrometer thickness
- #3C9 Gold, 11 micrometer thickness
- #1CA Gold, 5-8 micrometer thickness
- #2CA Gold, 16 micrometer thickness
- #3CA Silver, 10 micrometer thickness
- #1CB Gold, 17 micrometer thickness
- #2CB Gold, 14 micrometer thickness
- #3CB Gold, 20-30 micrometer thickness
- #1CC Silver, 21 micrometer thickness
- #2CC Silver, 21 micrometer thickness
- #3CC Silver, 24 micrometer thickness
- #1CD Gold, 5-8 micrometer thickness
- #2CD Gold, 14 micrometer thickness
- #3CD Gold, 20-30 micrometer thickness
- #1CE Gold, 5-8 micrometer thickness, Ag particles
- #2CE Gold, 11 micrometer thickness
- #3CE Gold, 20-30 micrometer thickness
- #1CF Gold, 8 micrometer thickness
- #2CF Gold, 12 micrometer thickness, Ag particles
- #3CF Gold, 20-30 micrometer thickness
- #1D0 Gold, 20-30 micrometer thickness
- #2D0 Gold, 20-30 micrometer thickness
- #3D0 Gold, 20-30 micrometer thickness, Ag particles
- #1D1 Silver, blank
- #2D1 Gold, 13 micrometer thickness
- #3D1 Gold, 13 micrometer thickness
- #1D2 Gold, 8 micrometer thickness
- #2D2 Gold, 8 micrometer thickness
- #3D2 Silver, 30 micrometer thickness
- #1D3 Silver, 10 micrometer thickness
- #2D3 Silver, 10 micrometer thickness
- #3D3 Silver, 32 micrometer thickness
- #1D4 Platinum, sintered
- #2D4 Platinum, deep black
- #3D4 Platinum, deep black

#1D5	Platinum, deep black
#2D5	Silver, 22 micrometer thickness
#3D5	Silver, 21 micrometer thickness
#1D6	Platinum, deep black
#2D6	Palladium, black
#3D6	Platinum, deep black
#1D7	Silver, blank
#2D7	Platinum, sintered
#3D7	Platinum, sintered
#1D8	Silver, blank, square hole 3.5x3.5mm at center
#2D8	Silver, blank
#3D8	Gold, 8 micrometer thickness

Positions in the substrate are given in substrate coordinates, which have the origin at lower left corner and range from 0 to 10000 micrometers in both horizontal (X) and vertical (Y) direction.

2.2.2 COSISCOPE

COSISCOPE is a CCD camera that is used to take pictures of TMU target substrates and find dust grains on them. COSISCOPE returns CCD images and grain lists with dust grain coordinates, sizes and brightness properties. The gray image has a 10 bit depth with resolution of 1024*1024 pixels and covers an area of 14*14 millimeters.

The COSISCOPE pixel coordinates are converted to substrate coordinates, which have the origin at lower left corner and range from 0 to 10000 micrometers in both horizontal (X) and vertical (Y) direction.

2.2.3 Primary Ion Source (PIS)

The Primary Ion Source provides isotopically clean ¹¹⁵In⁺. The ion source has a limited lifetime of nominally 2000 hours. After a long period of inactivity it may be difficult to start. The instrument contains two ion sources, both of which can be used. The startup of the PIS is slow (~ 0.5-1 hour). PIS has two ion sources, A (stands for 'Analyse') and C (stands for 'Clean'). A is primarily used for analysis operations, and C for cleaning operations.

2.2.4 Primary Ion Beam System (PIBS)

The Primary Ion Beam System focuses, bunches and deflects ions into periodic pulse trains to hit the dust grains to be analyzed. The beam thickness is less than 100 μ m and the pulse width a few ns. The PIBS can also be used to clean the target by a continuous beam. The instrument contains one analysis beam and one cleaning beam, each of which can use either ion source.

lons from two emitters (A and C) can reach either of two positions: 'Analyze' or 'Clean', depending of the Beam Switch (BS) in the center. The focusing elements are electrically shared, as only one beam can be active at any time. Chopper and Bunchers (CB) provide the pulsed beam for analysis, the deflection plates (PX,PY) are used for steering the beam spot on the target.

On the analyse channel, a first lens LA1 (or LC1 in the backup configuration) gives an image of the emitter in the inlet plane of the CHOPPER, then the buncher compresses the ion beam into the short pulses required on the target. A second lens LA2 builds the final image on the target sample.

The other ion beam used for cleaning has a first lens LC1 (or LA1 in the backup configuration), which gives an image used by LC2 to build the final image on the target in the clean position. The ion beam for cleaning is not pulsed.

2.2.5 Time-Of-Flight Spectrometer (TOF)

The Time Of Flight spectrometer consists of an ion extraction part, an ion reflectron and a detector. The ion extraction section is equipped with deflection plates (TX, TY) to control which ions can reach the detector. The reflectron removes some energy dispersion of incident ions and improves the mass resolution of the instrument. The detector is of micro sphere type.

2.2.6 TDC

The Time to Digital Converter is a digital counter measuring the time of flight for each individual ion. The device is controlled by the onboard computer. The accumulated measurement represents the time-of-flight spectrum of COSIMA.

2.3 Data Handling Process

All PDS data products will be prepared at the Finnish Meteorological Institute (see chapter 1.7 for contact information). All data processing levels mentioned in this document are PSA-compliant, as defined in RO-EST-PL-5011.

Level 1a COSIMA data will be fetched from the Rosetta Data Distribution System (DDS) by FMI, where it will be processed to Level 2 (REFDR), and further to Level 3 products.

COSIMA Level 2 (REFDR) products are:

- Time-of-flight spectra, with automatically calibrated mass scale and relevant housekeeping data. Spectra can be of either Positive or Negative ions.
- Onboard calculated peak list and relevant housekeeping data. The spectrum is given as counts per integer mass lines, separated to organic and inorcanic massed.
- Scan over substrate position or some measurement control parameter and relevan housekeeping data. The data is total counts of the events from the time-of-flight spectra for three possible mass/time ranges. The time range of the scan can contain spectra or peak list data.
- Substrate heating information.
- Substrate cleaning with the ion bean and the related housekeeping data.
- Substrate images. The images can be illuminated with either plus (right) side or minus (left) side led.
- Substrate dust grain feature (position, size, brightness) lists and relevant housekeeping data.
- Substrate history (auxiliary data)

The mass scale is calibrated with only two lines:

- positive mode
 - H or ¹²C for low masses
 - 115 In or 107 Ag or 109 Ag for high masses
- negative mode
 - H or CH for low masses
 - Cl or Br for high masses

There is no dead time correction nor background removal. The user should always check the calibration for any scientific analysis.

For the peak lists, the separation between organic and inorganic peaks is done according to the following formula:

Starting from the integer mass (M), the bin interval for the

- inorganic ions: M*1.0003 Δm ... M*1.0003
- organic ions: M*1.0003 ... M*1.0003 + ∆m

```
where \Delta m = 0.2
```

For the calculated mass scale, a confidence number is calculated. This number is the procentual amount of counts inside the mass windows compared to the total counts. The mass window is defined as

```
m*f \pm m^p*q, where p = log(0.3/0.05)/log(300/12) q = 0.0.5 / (12^p)
```

which gives mass 12 ± 0.05 and mass 300 ± 0.3 . If suitable peaks to establish the scale cannot be found, the confidence number is 0.0% and the mass scale is calculated from the default values.

In the products PDS header there is a label DATA_QUALITY_ID. This is "-1", when the mass scale is calculated by the software. In the future, when real comet dust spectra will be analyzed, the flag may change to inform, that the mass scale is established either by human or more advanced analysis software. When that happens, the product label will contain the description of the new flag values.

The HK data for the spectra and images is given in already calibrated form, without raw values. They can be used to check, if there's some instrument setup reason, why the spectrum signal to noise ratio or peak shape is as it is. The HK values don't contribute anything numerical to the spectrum mass scaling and are for background information only. The same goes with the image data.

It should be pointed out, that an established mass scale is already an interpretation of the data and regardless of the flag, each data user should check the scale.

2.4 Overview of Data Products

2.4.1 General

COSIMA contains 24 target holders, each having three different substrates for dust collection. From data analysis point of view, each substrate has different history. Each substrate can be exposed to dust, heated, imaged with COSISCOPE, and measured and cleaned by ion beam.

The data user should start the data analysis from the substrate history file stored in the substrate subdirectory in the data directory, The history files contain time ordered information from actions taken with the substrate in question. For exposure and storage there is only the time period. For the following products the archive pointer is given:

- time of flight ion spectrum. The main product of COSIMA, taken from a small area from the substrate surface. The preliminary mass scale is automatically generated with the equivalent software as onboard COSIMA for the peak list generation. For the comet phase data, the mass scale may also be established by a human or more advanced analysis software, case by case.
- peak list. The peak list is generated onboard COSIMA for integer mass lines for organic and inorganic masses separately. It may be used for pre-analysis of the grains, when full spectra would be too large to send due to operational and telemetry quota constrains
- scan. The measurement position or some measurement parameter is varied. The product is the
 total counts from the three possible time/mass ranges. During the scan COSIMA can also
 generate spectrum or peak data for each scan step value.
- image. The image is a COSISCOPE compressed image take from the whole substrate. The transmitted image may also contain only a subset of the image
- grain list. The COSISCOPE can detect individual dust grains from the substrate surface and provide them as a list with position, size and illumination characteristics.
- heat. The substrate is heated and the heat curve is available as the product.
- clean: The substrate is cleaned by the ion beam.

The relevant calibrated housekeeping data is provided together the data products for background information. They don't contribute anything numerical to the data products calibration.

During the ground calibration phase only few substrates were actively used for instrument calibration. These operations must be anyway used for background information in interpreting data during the comet phase.

Before the comet phase no real science is expected to be available from data.

Geometry information for the COSIMA products is not available. As the substrate exposure will take at least hours, often days, there is no simple way to tell, where the dust particles originate from. The data user should pick the exposure/collect period(s) from the substrate history file and make his/her own judgment. The time the individual spectrum or peak list product is made, has no connection to the time the dust particle is collected.

2.4.2 Software

2.4.2.1 Data processing software

An automatic script will retrieve data from the DDS and store it in an internal database. The housekeeping data will be plotted internally to check the general status of the instrument.

For PSA-compliant level 2 products generation (REFDR), data is retrieved from the internal database. The housekeeping data is calibrated with calibration coefficients stored in the RSDB, resulting in physical units. PDS data products are formed from mass spectra time series, parameter scan, substrate heating, substrate cleaning, COSISCOPE grain lists, COSISCOPE images, and calibrated housekeeping data. Peaks, images, and grain lists will need no additional calibration. In addition, target substrate history will be assembled as ancillary data products.

This software producing level 2 data from level 1b data stored in the internal database will be used only by the data producers and will not be archived.

Transformation of TOF spectra into mass spectra is done automatically with the equivalent software onboard the COSIMA instrument. See chapter 2.3.

2.4.2.2 Scientific analysis software

N/A. Data product files will be either ASCII TABLEs or FITS IMAGEs. For the FITS standard based images the DS9 software is recommend.

2.4.3 Documentation

The COSIMA instrument is extensively described in a paper "COSIMA, a High Resolution Time of Flight Spectrometer for Secondary Ion Mass Spectroscopy of Cometary Dust Particles" by Kissel et.al. [RD-02]. That paper together with this EAICD can be found from the DOCUMENT directory.

2.4.4 Derived and other Data Products

N/A

2.4.5 Ancillary Data Usage

The COSIMA instrument measures "off-line" in the sense that target assemblies are exposed independently of any spacecraft or COSIMA activity. For each target substrate, a list containing substrate history, including exposure time period, heating in the chemistry station, cleaning, analyzing and imaging is provided. The list is formatted as a table and stored in the same directory with the science products obtained from that substrate.

As stated in the 2.4.1, these history files are the starting point of the COSIMA data analysis.

3 Archive Format and Content

3.1 Deliveries and Archive Volume Format

There will be only one dataset available at all times. For all the pre-comet phases, it will be named RO-CAL-COSIMA-3-Vx.y. For the comet phase, the dataset name will be changed to RO-C-COSIMA-3-Vx.y.

For each delivery, the new data is incremented to the old data and the major version number is incremented by one. This scheme is used to make sure, that the data user always have the full substrate history available. The history products are essential in the spectrum interpretation and are the recommed starting point for the data browsing. The following delivery schedule is expected:

dataset ID	coverage	date
RO-CAL-COSIMA-2-V1.0	Ground calibration, commissioning, first cruise phases. No mass scale available	2006
RO-CAL-COSIMA-3-V2.0	adds active checkout data up to PC8	2008
RO-CAL-COSIMA-3-V3.0	adds active checkout data up to hibernation	2010
RO-C-COSIMA-3-V1.0	adds comet prelanding data	end 2014
RO-C-COSIMA-3-V2.0	adds comet escort data	mid 2015
RO-C-COSIMA-3-V3.0	adds comet escort data	end 2015
RO-C-COSIMA-3-V4.0	adds comet escort data	mid 2016
RO-C-COSIMA-3-V5.0	adds final data	end 2016

The passive checkouts do not contribute much to the dataset, only one target is taken from the target storage and deposited back. No measurements are made.

The dataset is organized according to tree structure in the illustration 3.1.




Illustration 3.1:

3.2 Conventions

3.2.1 Data Set ID Formation

Data set ID will be formed according to PDS standards and following the Rosetta Archive Plan (RO-EST-PL-5011). It will have the following components:

- Instrument host: RO
- Target: CAL for pre-flight data set, C for in-flight data set

- Instrument: COS
- Data processing level number, 3.
- Version number

The pre-comet dataset naming is thus starting from "RO-CAL-COSIMA-2-V1.0" and changed in the comet phase to names starting from "RO-C-COSIMA-3-V1.0"

3.2.2 Data Directory Naming Convention

/DATA directory be divided to subdirectories for each Cosima target substrate. The subdirectory names will be of format SUB_YXX, where Y (1-3) is the substrate position in the target assembly, and XX is target assembly ID numbered from C1 to D8 hexadecimal. For example: SUB_1C1, SUB_2C1, etc. Substrate numbering is also explained in Chapter 4.1

3.2.3 Filenaming Convention COSIMA data products will be named as follows:

- Spectra: CS_YXX_YYYYMMDDThhmmss_SP_Z.TAB, where YXX is substrate code as defined above (chapter 3.2.2), and Z is either 'P' for positive or 'N' for negative ions.
- Peak lists: CS_YXX_YYYYMMDDThhmmss_PK_Z.TAB, where YXX and Z as above.
- Scan: CS_YXX_YYYYMMDDThhmmss_SCAN.TAB, where YXX as above
- Heat: CS_YXX_YYYYMMDDThhmmss_HEAT.TAB, where YXX as above
- Cleaning: CS_YXX_YYYYMMDDThhmmss_CLEA.TAB, where YXX as above
- Cosiscope images of substrates: CS_YXX_YYYYMMDDThhmmss_IM_Z.FIT, where YXX as above, and Z is either 'P' for plus side led or 'M' for minus side led illumination.
- Grain lists: CS_YXX_YYYYMMDDThhmmss_GR__.TAB, where YXX as above.
- Housekeeping files: CS_YXX_YYYYMMDDThhmmss_S_HK.TAB (for spectra and peak lists), CS_YXX_YYYYMMDDThhmmss_SCHK (for scan housekeeping), CS_YXX_YYYYMMDDThhmmss_CLHK (for cleaning housekeeping) or CS_YXX_YYYYMMDDThhmmss_G_HK.TAB (for images and grain lists). YXX as above.
- Substrate history (ancillary data): CS YXX SUBSTRATE HIST.TAB

YYYYMMDDThhmmss is the date and time of operation start in UTC.

3.3 Standards Used in Data Product Generation

3.3.1 PDS Standards

PDS standard used is 3.6. All data processing levels mentioned in this document are PSA-compliant, as defined in RO-EST-PL-5011.

3.3.2 Time Standards

Time standard used is UTC. Time format is YYYY-MM-DDThh:mm:ss.

3.3.2.1 Spacecraft Clock Count, OBT

The PDS keywords SPACECRAFT_CLOCK_START_COUNT and SPACECRAFT_CLOCK_STOP_COUNT refer to OBT as defined in [AD 04, Rosetta Time Handling, chapter 4.2]]

The header of the experiment telemetry source packets contains the data acquisition start time in OBT as 32 bit of unit seconds followed by 16 bit of fractional seconds (see section 2.3). OBT = 0 is at 2003-01-01-700:00:00 UTC. The time resolution is $2-16 = 1.53 \times 10-5$ seconds.

The OBT is represented in the following format:

SPACECRAFT CLOCK START/STOP COUNT =

[&]quot;<reset number>/<unit seconds>.<fractional seconds>"

The unit seconds and the fractional seconds are separated by the full stop character. Note that this is not a decimal point. The fractional seconds are expressed as multiples of $2-16 = 1.53 \times 10-5$ seconds and count from 0 to $2^{10}-1=65535$. E.g. in SPACECRAFT_CLOCK_START_COUNT = "1/21983325.392" the 392 fractional seconds correspond to $392 \times 2-16 = 0.00598$ decimal seconds.

The spacecraft clock could be reset during the mission (although this is not planned). This would imply a change of the zero point. The zero point of the OBT will be indicated by pre-pending the reset number (integer starting at 1) and a slash to the unit seconds, i.e. "1/" means OBT = 0 at 2003-01-01T00:00:00 UTC.

Examples:

SPACECRAFT_CLOCK_START_COUNT = "1/21983325.39258" SPACECRAFT_CLOCK_START_COUNT = "1/21983325.392" SPACECRAFT_CLOCK_STOP_COUNT = "1/21983342"

3.3.3 Reference Systems

N/A

3.3.4 Other Applicable Standards

N/A

3.4 Data Validation

Formats will be checked with PSA Validation and Verification Tool.

The instrument data is validated according to the outline of the COSIMA proposal and the COSIMA instrument paper (Kissel et al, to be published in 2006 within the frame of the ROSETTA instrument papers). COSIMA consists of groups in France, Finland and Germany and Cols ins the US, Austria and The Netherlands. The COSIMA laboratory reference model is located at the Max-Planck-Insitut for Solar System Research in Katlenburg-Lindau, Germany. The COSIMA instrument is operated by FMI in Helsinki, Finland and MPS in Lindau, Germany. The reference model is used for calibration and cross-reference measurements of the COSIMA flight model. The flight data will be analysed in a near time frame. Since COSIMA stores the original cometary samples, with this approach interesting samples can be screened again, e.g. with an improved count statistics. The science goals are achieved in the precomet rendevous phase preparation with the reference model laboratory measurements and with the operational scenario of COSIMA in the comet orbiting phase of ROSETTA.

3.5 Content

3.5.1 Volume Set

1 volume will contain 1 COSIMA data set. Data set structure is defined in Chapter 3.1.

3.5.2 Data Set

COSIMA data will form one data set. It will contain time-of-flight spectra, peaks lists, target substrate images, grain lists and target history (ancillary data) obtained after the flight targets were installed in the flying instrument (XM).

The data set will be named according to PDS standards and following the Rosetta Archive Plan (RO-EST-PL-5011). Each component of the name will match the corresponding component of the data set ID.

Data set name components are:

- Instrument host: ROSETTA-ORBITER
- Target: CAL for pre-comet phase, 67P for comet phasedata sets
- Instrument name: COSIMA
- Data processing level, 3
- Version number

Example: "ROSETTA-ORBITER 67P COSIMA 3 V3.0"

3.5.3 Directories

3.5.3.1 Root Directory

General archive description: AAREADME.TXT, VOLDESC.CAT

3.5.3.2 Calibration Directory

N/A

3.5.3.3 Catalog Directory

CATINFO.TXT

MISSION.CAT and INSTHOST.CAT from ESA – Mission and spacecraft descriptions.

INST.CAT – Instrument description

DATASET.CAT - Dataset description

REFERENCE.CAT - References

SOFTWARE.CAT - empty for COSIMA datasets.

PERSON.CAT - COSIMA contacts

TARGET.CAT - Target descriptions

3.5.3.4 Index Directory

INDXINFO.TXT, INDEX.LBL and INDEX.TAB

3.5.3.5 Browse Directory and Browse Files

N/A

3.5.3.6 Geometry Directory

N/A

3.5.3.7 Software Directory

N/A

3.5.3.8 Gazetter Directory

N/A

3.5.3.9 Label Directory

LABINFO.TXT

Format containers (*.FMT)

3.5.3.10Document Directory

COSIMASIS: This EAICD with detached labels and images in JPG format.

COSIMAPAPER: COSIMA instrument paper with detached labels and images in JPG format

3.5.3.11Extras Directory

N/A

3.5.3.12Data Directory

See chapter 3.2.2.

4 Detailed Interface Specifications

4.1 Structure and Organization Overview

/DATA directory will be divided to sub-directories for each COSIMA target substrate. Names of these sub-directories will follow the scheme defined in chapter 3.2.2.

The target substrate code in the directory name consists of 3 alphanumeric characters. The last two characters represent hexadecimal code of the target substrate. There are 24 target assemblies, numbered C1-D8 (hex). Each assembly holds 3 substrates, resulting in total of 72 substrates. The first character in the code is a number defining the substrate position in the assembly. Possible numbers are 1,2 and 3 for top, middle and low substrate, respectively. Thus directory name SUB_1C1 identifies that the data inside contains measurements of top substrate of target assembly C1. Other directories containing measurements of target assembly C1 are SUB_2C1 and SUB_3C1.

Data products will be stored in sub-directories SUB_XYY. File naming of the data files is described in chapter 3.2.3. Each sub-directory SUB_XYY will also include the history of that substrate. The history contains information about substrate storage and expose periods, cleaning and heating actions, COSISCOPE camera images and grains lists and any spectra taken. The history product contains history from the moment substrates were installed in the COSIMA flight instrument.

4.2 Data Sets, Definition and Content

See chapter 3.5.2.

4.3 Data Product Design

4.3.1 Time-of flight spectrum product

4.3.1.1 General description

COSIMA time-of-flight spectrum product has the following elements:

- Time-of-flight spectrum: event count series in ascii format.
- Event count: number of events in a time bin.
- Mass: calibrated mass for the time bin.

4.3.1.2 Label example

```
PDS VERSION ID
                                   = PDS3
LABEL REVISION NOTE
                                   = "V1.1"
/* FILE FORMAT */
RECORD TYPE
                                   = FIXED LENGTH
RECORD BYTES
                                   = 30
                                   = 131185
FILE_RECORDS
LABEL RECORDS
                                   = 112
/* POINTER TO DATA OBJECTS */
^SCALE_TABLE
                                   = 113
^MASS SPECTRUM TABLE
                                   = 114
/* GENERAL DATA DESCRIPTION PARAMETERS */
FILE_NAME
                                  = "CS_2D8_20070927T182348_SP_P.TAB"
DATA_SET_ID
DATA_SET_NAME
                                   = "RO-CAL-COSIMA-3-V2.0"
                                  = "ROSETTA-ORBITER CAL COSIMA 3 V2.0"
                                   = "CS_2D8_20070927T182348_SP_P.TAB"
PRODUCT ID
PRODUCT_CREATION_TIME
PRODUCT_TYPE
                                   = 2008 - 11 - 12T09 : 15 : 39
                                   = "REFDR"
                                   = "3"
PROCESSING_LEVEL_ID
                                  = "ROSETTA"
MISSION ID
                                  = "INTERNATIONAL ROSETTA MISSION"
MISSION_NAME
                                  = "EARTH SWING-BY 2"
MISSION PHASE NAME
INSTRUMENT_HOST_ID
INSTRUMENT_HOST_NAME
                                   = "R0"
                                   = "ROSETTA-ORBITER"
```

```
INSTRUMENT ID
                                    = "COSIMA"
                                    = "COMETARY SECONDARY ION MASS ANALYZER"
INSTRUMENT_NAME
INSTRUMENT_TYPE
INSTRUMENT_MODE_ID
                                    = "MASS SPECTROMETER"
                                   = "SPECTRUM"
                                   = "TIME OF FLIGHT MASS SPECTRUM MEASUREMENT"
INSTRUMENT_MODE_DESC
TARGET NAME
                                    = "CALIBRATION"
TARGET_TYPE
START_TIME
STOP_TIME
                                    = "CALIBRATION"
                                    = 2007-09-27T18:23:48
                                    = 2007-09-27T18:33:53
SPACECRAFT_CLOCK_START_COUNT
SPACECRAFT_CLOCK_STOP_COUNT
                                    = "1/0149538196.41251"
                                    = "1/0149538801.41245"
                                    = "N/A"
SC_SUN_POSTTION_VECTOR
SC_TARGET_POSITION_VECTOR
                                   = "N/A"
SC_TARGET_VELOCITY_VECTOR
SPACECRAFT_ALTITUDE
                                    = "N/A"
                                    = "N/A"
                                    = "N/A"
SUB SPACECRAFT LATITUDE
                                    = "N/A"
SUB SPACECRAFT LONGITUDE
                                    = "FMI"
PRODUCER_ID
PRODUCER_FULL_NAME
                                   = "JOHAN SILEN"
                                   = "FINNISH METEOROLOGICAL INSTITUTE"
PRODUCER_INSTITUTION_NAME
DATA_QUALITY_ID
DATA_QUALITY_DESC
                                    = "-1 = not checked"
ROSETTA:COSIMA_SUBSTRATE_ID
ROSETTA:COSIMA_SUBSTRATE_DESC
                                    = "2D8"
                                    = "Silver, blank"
ROSETTA:COSIMA_SUBSTRATE_X
ROSETTA:COSIMA_SUBSTRATE_Y
                                    = 5000
                                    = 5000
ROSETTA: COSIMA_SPECTRUM_POL
                                    = "POSITIVE"
                                    = 795091
ROSETTA: COSIMA SPECTRUM SHOTS
OBJECT
                                    = SCALE TABLE
  NAME
                                    = SCALE
  INTERCHANGE_FORMAT
                                    = ASCII
  ROWS
                                    = 1
  COLUMNS
                                    = 3
  ROW_BYTES
                                    = 30
                                    = "COSIMA_SPECTRUM_PEAK_SCALE.FMT"
= "COSIMA_PEAK_LIST_MASS_SCALE"
  ^STRUCTURE
  DESCRIPTION
                                    = SCALE_TABLE
END OBJECT
                                    = MASS_SPECTRUM_TABLE
OBJECT
                                    = MASS_SPECTRUM
  NAME
  INTERCHANGE_FORMAT
                                    = ASCII
  ROWS
                                    = 131072
  COLUMNS
                                    = 3
  ROW BYTES
                                    = 30
                                    = "COSIMA_SPECTRUM_DATA.FMT"
  ^STRUCTURE
                                    = "COSIMA TIME OF FLIGHT MASS SPECTRUM"
  DESCRIPTION
END_OBJECT
                                    = MASS_SPECTRUM_TABLE
END
COSIMA SPECTRUM PEAK SCALE.FMT
                                    = COLUMN
  OR 1FCT
```

```
COLUMN NUMBER
                               = 1
                               = SCALE_A
  NAME
 DATA_TYPE
START_BYTE
                               = ASCII_REAL
                               = 1
 BYTES
                               = 10
                               = "F10.2"
 FORMAT
                               = "FACTOR A FROM THE TIME TO MASS FUNCTION
 DESCRIPTION
                                  T = A * SQRT(M) + B"
END OBJECT
                               = COLUMN
OBJECT
                               = COLUMN
  COLUMN NUMBER
                               = 2
  NAME
                               = SCALE B
 DATA TYPE
                               = ASCII_REAL
  START_BYTE
                               = 12
  RYTES
                               = 10
                               = "F10.2"
 FORMAT
 DESCRIPTION
                               = "FACTOR B FROM THE TIME TO MASS FUNCTION
                                  T = A * SQRT(M) + B"
END OBJECT
                               = COLUMN
0BJECT
                               = COLUMN
```

```
COLUMN NUMBER
                               = 3
                               = SCALE CONFIDENCE
  NAME
  DATA TYPE
                               = ASCII_REAL
  START_BYTE
                               = 23
  BYTES
                               = 5
  FORMAT
                               = "F5.1"
  DESCRIPTION
                               = "MASS SCALE CONFIDENCE LEVEL IN PROCENTS"
END_OBJECT
                     = COLUMN
```

COSIMA SPECTRUM DATA.FMT

```
= COLUMN
 OBJECT
   COLUMN NUMBER
   NAME
                                = INDEX
   DATA_TYPE
                                = ASCII_INTEGER
   START_BYTE
   BYTES
                                = 6
                                = "16"
   FORMAT
                                = "TIME OF FLIGHT TIME STEP INDEX.
   DESCRIPTION
                                   TIME STEP IS 0.000000001953125 SECONDS"
 END_OBJECT
                                = COLUMN
 OBJECT
                                = COLUMN
   COLUMN_NUMBER
                                = 2
   NAME
                                = MASS COUNT
  DATA_TYPE
START_BYTE
                                = ASCIT_INTEGER
                                = 8
   BYTES
                                = 10
   FORMAT
                                = "I10"
                                = "TIME INTEGRAGED MASS COUNT AT THE TIME STEP"
  DESCRIPTION
 END OBJECT
                                = COLUMN
 OBJECT
                                = COLUMN
   COLUMN NUMBER
                                = 3
   NAME
                                = MASS NUMBER
   DATA_TYPE
                                = ASCII_REAL
   START_BYTE
                                = 19
                                = 10
   BYTES
                                = "F10.5"
   FORMAT
   DESCRIPTION
                                = "CALIBRATED MASS NUMBER AT THE TIME STEP"
END_OBJECT
                      = COLUMN
```

4.3.2 Peak list product

4.3.2.1 General Description

COSIMA peak list has the following elements:

- Instrument onboard calculated mass scale.
- Peak list for organic and inorganic masses

4.3.2.2 Label example

```
PDS VERSION ID
                                  = PDS3
LABEL_REVISION_NOTE
                                  = "V1.1"
/* FILE FORMAT */
RECORD_TYPE
                                  = FIXED LENGTH
RECORD BYTES
                                  = 29
FILE_RECORDS
                                  = 446
LABEL_RECORDS
                                   = 115
/* POINTERS TO DATA OBJECTS */
^SCALE TABLE
                                  = 116
^PEAK_TABLE
                                   = 117
/* GENERAL DATA DESCRIPTION PARAMETERS */
                               = "CS_2D8_20070927T184705_PK_N.TAB"
FILE_NAME
DATA_SET_ID
DATA_SET_NAME
PRODUCT_ID
                                  = "RO-CAL-COSIMA-3-V2.0"
                                 = "ROSETTA-ORBITER CAL COSIMA 3 V2.0"
                                  = "CS_2D8_20070927T184705_PK_N.TAB"
PRODUCT CREATION TIME
                                  = 2008 - 11 - 12T09 : 15 : 40
```

```
PRODUCT TYPE
                                    = "REFDR"
                                    = "3"
PROCESSING_LEVEL_ID
                                    = "ROSETTA"
MISSION ID
                                   = "INTERNATIONAL ROSETTA MISSION"
MISSION NAME
                                   = "EARTH SWING-BY 2"
MISSION_PHASE_NAME
INSTRUMENT HOST ID
                                   = "R0"
INSTRUMENT_HOST_NAME
                                   = "ROSETTA-ORBITER"
INSTRUMENT_ID
INSTRUMENT_NAME
INSTRUMENT_TYPE
                                   = "COSIMA"
                                   = "COMETARY SECONDARY ION MASS ANALYZER"
                                   = "MASS SPECTROMETER"
                                   = "SPECTRUM"
INSTRUMENT_MODE_ID
                                   = "TIME OF FLIGHT MASS SPECTRUM MEASUREMENT"
INSTRUMENT_MODE_DESC
                                   = "CALIBRATION"
TARGET_NAME
                                    = "CALIBRATION"
TARGET_TYPE
START_TIME
STOP_TIME
                                    = 2007-09-27T18:47:05
                                    = 2007-09-27T18:57:10
SPACECRAFT_CLOCK_START_COUNT
SPACECRAFT_CLOCK_STOP_COUNT
SC_SUN_POSITION_VECTOR
                                    = "1/0149539593.41237"
                                    = "1/0149540198.41230"
                                    = "N/A"
SC_TARGET_POSITION_VECTOR
SC_TARGET_VELOCITY_VECTOR
SPACECRAFT_ALTITUDE
                                    = "N/A"
                                   = "N/A"
                                   = "N/A"
SUB_SPACECRAFT_LATITUDE
SUB_SPACECRAFT_LONGITUDE
                                    = "N/A"
                                    = "N/A"
                                   = "FMI"
PRODUCER ID
                                    = "JOHAN SILEN"
PRODUCER_FULL_NAME
                                   = "FINNISH METEOROLOGICAL INSTITUTE"
PRODUCER_INSTITUTION_NAME
DATA_QUALITY_ID
                                    = -1
                                    = "-1 = not checked"
DATA_QUALITY_DESC
                                    = "2D8"
ROSETTA: COSIMA SUBSTRATE ID
ROSETTA:COSIMA_SUBSTRATE_DESC
ROSETTA:COSIMA_SUBSTRATE_X
                                    = "Silver, blank"
                                    = 5000
ROSETTA:COSIMA_SUBSTRATE_Y
ROSETTA:COSIMA_SPECTRUM_POL
                                    = 5000
                                    = "NEGATIVE"
                                    = 828459
ROSETTA:COSIMA_SPECTRUM_SHOTS
                                    = SCALE TABLE
OBJECT
  NAME
                                    = SCALE
  INTERCHANGE_FORMAT
                                    = ASCII
  ROWS
                                    = 1
  COLUMNS
                                    = 3
  ROW BYTES
                                    = 29
                                    = "COSIMA SPECTRUM PEAK SCALE.FMT"
  ^STRUCTURE
                                    = "COSIMA PEAK LIST MASS SCALE"
  DESCRIPTION
END OBJECT
                                    = SCALE TABLE
OBJECT
                                    = PEAK_TABLE
  NAME
                                    = PEAK_LIST
  INTERCHANGE FORMAT
                                    = ASCII
  ROWS
                                    = 330
  COLUMNS
                                    = 3
  ROW BYTES
                                   = 29
                                    = "COSIMA_SPECTRUM_PEAKS.FMT"
  ^STRUCTURE
                                    = "COSIMA SPECTRUM PEAK LIST"
  DESCRIPTION
                                    = PEAK_TABLE
END_OBJECT
FND
COSIMA_SPECTRUM_PEAK_SCALE.FMT
                                    = COLUMN
  OR 1FCT
    COLUMN NUMBER
                                    = 1
    NAME
                                    = SCALE A
    DATA TYPE
                                    = ASCII_REAL
    START_BYTE
                                    = 1
    BYTES
                                    = 10
                                    = "F10.2"
    FORMAT
                                    = "FACTOR A FROM THE TIME TO MASS FUNCTION
    DESCRIPTION
                                       T = A * SQRT(M) + B"
  END OBJECT
                                    = COLUMN
                                    = COLUMN
  0BJECT
    COLUMN NUMBER
                                    = 2
    NAME
                                    = SCALE B
    DATA_TYPE
                                    = ASCII REAL
    START BYTE
```

```
BYTES
                               = 10
                               = "F10.2"
  FORMAT
  DESCRIPTION
                               = "FACTOR B FROM THE TIME TO MASS FUNCTION
                                  T = A * SQRT(M) + B"
                               = COLUMN
END OBJECT
OBJECT
                               = COLUMN
  COLUMN NUMBER
                               = 3
                               = SCALE_CONFIDENCE
  NAME
                               = ASCII_REAL
  DATA TYPE
  START_BYTE
                               = 23
  BYTES
                               = 5
  FORMAT
                               = "F5.1"
  DESCRIPTION
                               = "MASS SCALE CONFIDENCE LEVEL IN PROCENTS"
                     = COLUMN
END OBJECT
```

COSIMA SPECTRUM PEAKS.FMT

```
OBJECT
                                   = COLUMN
   COLUMN NUMBER
                                   = 1
   NAME
                                   = INDEX
   DATA_TYPE
START_BYTE
                                   = ASCII INTEGER
                                   = 1
   BYTES
                                   = 5
   FORMAT
                                   = "I5"
                                   = "INTEGER MASS. IF HIGHER THAN 300, THEN THE
   DESCRIPTION
                                      INTERVAL FROM PREVIOUS VALUE TO CURRENT
                                      VALUE"
 END OBJECT
                                   = COLUMN
 OBJECT
                                   = COLUMN
   COLUMN_NUMBER
                                  = 2
   NAME
                                  = INORGANIC_COUNT
   DATA TYPE
                                   = ASCII INTEGER
   START_BYTE
                                   = 7
   BYTES
                                   = 10
   FORMAT
                                   = "I10"
                                   = "INORGANIC PEAK HEIGHT COUNT. IF MASS INDEX IS HIGHER THAN 300, THEN THE SUM OF
   DESCRIPTION
                                      ORGANIC AND INORGANIC COUNTS FOR THE
                                      INTERVAL FROM PREVIOUS INDEX"
                                   = COLUMN
 END OBJECT
 OBJECT
                                   = COLUMN
   COLUMN NUMBER
                                   = 3
                                  = ORGANIC COUNT
   NAME
   DATA TYPE
                                   = ASCII INTEGER
   START_BYTE
                                   = 18
   BYTES
                                   = 10
   FORMAT
                                   = "I10"
                                   = "ORGANIC PEAK HEIGHT COUNT. IF MASS INDEX IS HIGHER THAN 300, THEN THE SUM OF
   DESCRIPTION
                                      INORGANIC AND ORGANIC COUNTS FOR THE
                                      INTERVAL FROM PREVIOUS INDEX"
                        = COLUMN
END_OBJECT
```

4.3.3 Time-of-flight spectrum housekeeping data product

4.3.3.1 General description

With each measured time-of-flight spectrum or peak list, housekeeping data is associated. The housekeeping product has the following elements:

- Voltages, currents and temperatures of the instrument during spectrum measurement
- TDC unit timing parameters
- TDC unit calibration results

Detailed contents of the elements are described in the label example below.

4.3.3.2 Label example

```
PDS_VERSION_ID = PDS3
LABEL REVISION NOTE = "V1.1"
```

```
/* FILE FORMAT */
RECORD TYPE
                                        = FIXED LENGTH
RECORD BYTES
                                        = 897
FILE_RECORDS
                                        = 11
LABEL RECORDS
                                        = 5
/* POINTER TO DATA OBJECT */
^HK_TABLE
^TDC_TIMING_TABLE
^TDC_CALIBRATION_TABLE
                                        = 6
                                        = 7
                                        = 8
/* GENERAL DATA DESCRIPTION PARAMETERS */
FILE_NAME
                                       = "CS_2D8_20070927T182348_S_HK.TAB"
                                        = "RO-CAL-COSIMA-3-V2.0"
DATA_SET_ID
DATA_SET_NAME
PRODUCT ID
                                        = "ROSETTA-ORBITER CAL COSIMA 3 V2.0"
                                        = "CS_2D8_20070927T182348_S_HK"
                                        = 2008 - 11 - 12T09 : 15 : 38
PRODUCT_CREATION_TIME
PRODUCT_TYPE
                                        = "ANCDR"
PROCESSING_LEVEL_ID
                                        = "6"
                                        = "ROSETTA"
MISSION_ID
                                       = "INTERNATIONAL ROSETTA MISSION"
MISSION_NAME
MISSION PHASE_NAME
                                       = "EARTH SWING-BY 2"
INSTRUMENT_HOST_ID
INSTRUMENT_HOST_NAME
INSTRUMENT_ID
                                       = "R0"
                                       = "ROSETTA-ORBITER"
                                       = "COSIMA"
                                       = "COMETARY SECONDARY ION MASS ANALYZER"
INSTRUMENT_NAME
INSTRUMENT_TYPE
INSTRUMENT_MODE_ID
                                       = "MASS SPECTROMETER"
                                       = "SPECTRUM"
INSTRUMENT_MODE_DESC
                                       = "TIME OF FLIGHT MASS SPECTRUM MEASUREMENT"
                                        = "CALIBRATION"
TARGET NAME
TARGET TYPE
                                        = "CALIBRATION"
START_TIME
STOP_TIME
                                        = 2007-09-27T18:23:48
                                        = 2007-09-27T18:33:53
SPACECRAFT_CLOCK_START_COUNT
SPACECRAFT_CLOCK_STOP_COUNT
                                        = "1/0149538196.41251"
                                        = "1/0149538801.41245"
SC_SUN_POSITION_VECTOR
SC_TARGET_POSITION_VECTOR
SC_TARGET_VELOCITY_VECTOR
SPACECRAFT_ALTITUDE
                                        = "N/A"
                                       = "N/A"
                                       = "N/A"
                                        = "N/A"
SUB_SPACECRAFT_LATITUDE
SUB_SPACECRAFT_LONGITUDE
                                       = "N/A"
                                        = "N/A"
                                        = "FMI"
PRODUCER_ID
PRODUCER FULL NAME
                                       = "JOHAN SILEN"
PRODUCER_INSTITUTION_NAME
                                        = "FINNISH METEOROLOGICAL INSTITUTE"
DATA_QUALITY_ID
DATA_QUALITY_DESC
                                        = "-1 = not checked"
ROSETTA: COSIMA_SUBSTRATE_ID
ROSETTA: COSIMA_SUBSTRATE_DESC
ROSETTA: COSIMA_SUBSTRATE_X
ROSETTA: COSIMA_SUBSTRATE_Y
ROSETTA: COSIMA_SUBSTRATE_Y
ROSETTA: COSIMA_SPECTRUM_POL
                                        = "2D8"
= "Silver, blank"
                                        = 5000
                                        = 5000
                                        = "POSITIVE"
ROSETTA: COSIMA SPECTRUM SHOTS
                                        = 795091
OBJECT
                                        = HK_TABLE
                                        = HOUSEKEEPING
  NAME
  INTERCHANGE_FORMAT
                                        = ASCII
  ROWS
                                        = 1
  COLUMNS
                                        = 112
                                        = 897
  ROW BYTES
  ^STRUCTURE
                                        = "COSIMA_SPECTRUM_HK.FMT"
                                        = "COSIMA SPECTRUM HOUSEKEEPING INFORMATION,
  DESCRIPTION
                                            INCLUDING VOLTAGES, CURRENTS AND
                                            TEMPERATUES"
END OBJECT
                                        = HK TABLE
                                        = TDC_TIMING_TABLE
= TDC_TIMING
OBJECT
  NAME
  INTERCHANGE_FORMAT
                                        = ASC\overline{I}I
                                        = 1
  ROWS
                                        = 7
  COLUMNS
  ROW_BYTES
                                        = 897
  ^STRUCTURE
                                        = "COSIMA SPECTRUM TDC TIMING.FMT"
                                        = "TIME TO DIGITAL UNIT TIMING PARAMETERS"
  DESCRIPTION
END_OBJECT
                                        = TDC_TIMING_TABLE
```

```
OBJECT
                                 = TDC_CALIBRATION_TABLE
                                 = TDC CALIBRATION
  INTERCHANGE FORMAT
                                 = ASC\overline{I}I
                                 = 4
  ROWS
  COLUMNS
                                 = 5
                                 = 897
 ROW BYTES
                                 = "COSIMA_SPECTRUM_TDC_CALIB.FMT"
= "TIME TO DIGITAL UNIT CALIBRATION RESULTS"
  ^STRUCTURE
  DESCRIPTION
                                 = TDC_CALIBRATION_TABLE
END OBJECT
END
COSIMA SPECTRUM HK.FMT:
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                        = 1
                        = "T REF MIN"
  DATA TYPE
                        = ASCII_REAL
  START_BYTE
                        = 1
  BYTES
                        = 7
                        = "DEGREE CELSIUS"
 UNIT
                        = 999.9
 MISSING_CONSTANT
                        = "F7.1"
  FORMAT
                        = "T_REF TEMPERATURE MINIMUM AT REFERENCE POINT"
 DESCRIPTION
                        = COLUMN
END_OBJECT
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 2
= "T_REF_MEAN"
  NAME
 DATA_TYPE
                        = ASCII_REAL
  START_BYTE
                        = 9
  BYTES
                        = 7
                        = "DEGREE CELSIUS"
  UNIT
 MISSING_CONSTANT
                        = 999.9
                        = "F7.1"
  FORMAT
                        = "T REF TEMPERATURE MEAN AT REFERENCE POINT"
  DESCRIPTION
                        = COLUMN
END_OBJECT
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 3
                        = "T REF MAX"
  DATA TYPE
                        = ASCII_REAL
  START_BYTE
                        = 17
  BYTES
                        = 7
                        = "DEGREE CELSIUS"
  UNIT
 MISSING_CONSTANT
                        = 999.9
                        = "F7.1"
  FORMAT
                        = "T REF TEMPERATURE MAXIMUM AT REFERENCE POINT"
 DESCRIPTION
                        = CO\overline{L}UMN
END_OBJECT
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 4
                        = "T REF STD"
  DATA TYPE
                        = ASCII_REAL
  START_BYTE
                        = 25
  BYTES
                        = 7
                        = "DEGREE CELSIUS"
 UNIT
                        = 999.9
 MISSING_CONSTANT
                        = "F7.1"
  FORMAT
                        = "T REF TEMPERATURE STANDARD DEVIATION AT
 DESCRIPTION
                           REFERENCE POINT"
END_OBJECT
                         = COLUMN
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                        = "T TDC MIN"
  NAME
 DATA_TYPE
                        = ASCII_REAL
  START BYTE
                        = 33
  BYTES
                        = "DEGREE CELSIUS"
  UNIT
  MISSING_CONSTANT
                        = 999.9
                        = "F7.1"
  FORMAT
```

= "T_TDC TIME TO DIGITAL UNIT DELAY LINE TEMPERATURE

DESCRIPTION

```
MINIMUM"
END_OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                        = 6
  NAME
                        = "T TDC MEAN"
                       = ASCII_REAL
  DATA TYPE
  START_BYTE
                        = 41
  BYTES
                        = 7
                       = "DEGREE CELSIUS"
  UNIT
 MISSING_CONSTANT
                       = 999.9
                        = "F7.1"
  FORMAT
                        = "T_TDC TIME TO DIGITAL UNIT DELAY LINE TEMPERATURE
 DESCRIPTION
                          MEAN"
END OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                       = "T TDC MAX"
  NAME
 DATA_TYPE
START_BYTE
                       = ASCII_REAL
                       = 49
  BYTES
                       = 7
                       = "DEGREE CELSIUS"
  UNIT
  MISSING CONSTANT
                       = 999.9
                       = "F7.1"
  FORMAT
 DESCRIPTION
                       = "T_TDC TIME TO DIGITAL UNIT DELAY LINE TEMPERATURE
                          MAXIMUM"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
 COLUMN_NUMBER
                       = 8
                       = "T TDC STD"
  NAME
  DATA_TYPE
                       = ASCII_REAL
  START_BYTE
                       = 57
                       = 7
  BYTES
                       = "DEGREE CELSIUS"
  UNIT
                       = 999.9
 MISSING_CONSTANT
                       = "F7.1"
  FORMAT
                        = "T_TDC TIME TO DIGITAL UNIT DELAY LINE TEMPERATURE
  DESCRIPTION
                          STANDARD DEVIATION"
END_OBJECT
                        = COLUMN
                       = COLUMN
OBJECT
  COLUMN_NUMBER
                       = 9
                       = "T_PIBS_MIN"
  NAME
  DATA TYPE
                       = ASCII_REAL
  START_BYTE
                       = 65
  BYTES
                       = 7
                       = "DEGREE CELSIUS"
 UNIT
                       = 999.9
 MISSING_CONSTANT
                       = "F7.1"
  FORMAT
                       = "T PIBS PRIMARY ION BEAM SYSTEM TEMPERATURE MINIMUM"
 DESCRIPTION
                        = CO\overline{L}UMN
END_OBJECT
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                       = 10
= "T_PIBS_MEAN"
  NAME
  DATA TYPE
                       = ASCII_REAL
  START_BYTE
                       = 73
  BYTES
                       = 7
                       = "DEGREE CELSIUS"
  UNIT
                       = 999.9
 MISSING_CONSTANT
                       = "F7.1"
  FORMAT
                       = "T PIBS PRIMARY ION BEAM SYSTEM TEMPERATURE MEAN"
  DESCRIPTION
                        = COLUMN
END_OBJECT
OBJECT
                        = COLUMN
                       = 11
= "T_PIBS_MAX"
  COLUMN_NUMBER
  NAME
                       = ASCII_REAL
  DATA TYPE
  START_BYTE
                        = 81
  BYTES
                        = 7
  UNIT
                       = "DEGREE CELSIUS"
                        = 999.9
 MISSING_CONSTANT
```

```
= "F7.1"
  FORMAT
 DESCRIPTION
                        = "T PIBS PRIMARY ION BEAM SYSTEM TEMPERATURE MAXIMUM"
END OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 12
                          "T PIBS STD"
  NAME
                       =
                        = ASCII_REAL
 DATA_TYPE
  START BYTE
                        = 89
  BYTES
                       = 7
                        = "DEGREE CELSIUS"
  UNIT
  MISSING_CONSTANT
                        = 999.9
                        = "F7.1"
  FORMAT
 DESCRIPTION
                        = "T_PIBS PRIMARY ION BEAM SYSTEM TEMPERATURE STANDARD
                           DEVIATION"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 13
                        = "T LVC_MIN"
  NAME
  DATA_TYPE
                        = ASCII_REAL
  START_BYTE
                       = 97
  BYTES
                        = 7
                        = "DEGREE CELSIUS"
  UNIT
 MISSING_CONSTANT
                       = 999.9
                        = "F7.1"
  FORMAT
                       = "T_LVC LOW VOLTAGE CONVERTER TEMPERATURE MINIMUM"
  DESCRIPTION
                        = CO\overline{L}UMN
END_OBJECT
OBJECT
                        = COLUMN
 COLUMN_NUMBER
                       = 14
                        = "T_LVC_MEAN"
  NAME
  DATA_TYPE
                        = ASCII_REAL
  START_BYTE
                       = 105
  BYTES
                        = 7
                        = "DEGREE CELSIUS"
  UNIT
 MISSING_CONSTANT
                       = 999.9
                        = "F7.1"
  FORMAT
                       = "T_LVC LOW VOLTAGE CONVERTER TEMPERATURE MEAN"
 DESCRIPTION
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 15
                        = "T_LVC_MAX"
  NAME
  DATA TYPE
                       = ASCII REAL
  START_BYTE
                       = 113
  BYTES
                        = 7
                        = "DEGREE CELSIUS"
  UNIT
 MISSING_CONSTANT
                       = 999.9
                        = "F7.1"
  FORMAT
                        = "T_LVC LOW VOLTAGE CONVERTER TEMPERATURE MAXIMUM"
  DESCRIPTION
                        = CO\overline{L}UMN
END OBJECT
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 16
                        = "T_LVC_STD"
  NAME
 DATA_TYPE
                       = ASCII_REAL
  START_BYTE
                       = 121
  BYTES
                        = 7
                        = "DEGREE CELSIUS"
 UNIT
 MISSING_CONSTANT
                        = 999.9
                        = "F7.1"
  FORMAT
                        = "T_LVC LOW VOLTAGE CONVERTER TEMPERATURE STANDARD
 DESCRIPTION
                           DEVIATION"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
                        = 17
= "T_CPU_MIN"
  COLUMN_NUMBER
  NAME
                        = ASCII_REAL
  DATA TYPE
  START_BYTE
                        = 129
  BYTES
                        = "DEGREE CELSIUS"
 MISSING_CONSTANT
                        = 999.9
```

```
= "F7.1"
  FORMAT
  DESCRIPTION
                          = "T_CPU PROCESSOR TEMPERATURE MINIMUM"
END OBJECT
                          = COLUMN
OBJECT
                          = COLUMN
  COLUMN_NUMBER
                          = 18
                             "T CPU MEAN"
  NAME
                         =
  DATA_TYPE
                          = ASCII_REAL
  START_BYTE
                         = 137
  BYTES
 UNIT = "DEGRE
MISSING_CONSTANT = 999.9
FORMAT = "F7.1"
DESCRIPTION = "T_CPU
                         = "DEGREE CELSIUS"
                         = "T_CPU PROCESSOR TEMPERATURE MEAN"
END OBJECT
                          = COLUMN
OBJECT
                          = COLUMN
                   = "T_CPU_Mm."
= MSCII_REAL
= 145
  COLUMN_NUMBER
                         = "T CPU MAX"
  NAME
  DATA_TYPE
START_BYTE
  BYTES
                          = "DEGREE CELSIUS"
  UNIT
 MISSING_CONSTANT
FORMAT
DESCRIPTION
                          = 999.9
                         = "F7.1"
                         = "T_CPU PROCESSOR TEMPERATURE MAXIMUM"
END_OBJECT
                          = COLUMN
OBJECT
                          = COLUMN
                    = 20
= "T_CPU_STD"
  COLUMN_NUMBER
  NAME
  DATA_TYPE
                         = ASCII_REAL
  START_BYTE
                         = 153
                         = 7
  BYTES
                          = "DEGREE CELSIUS"
  UNIT
 MISSING_CONSTANT = 999.9
FORMAT = "F7.1"
DESCRIPTION = "T_CPU PROCESSOR TEMPERATURE STANDARD DEVIATION"
END_OBJECT
                          = COLUMN
                    = 21
= "T_HVC_MIN"
= ASCII RE^.
OBJECT
  COLUMN_NUMBER
  NAME
  DATA_TYPE
START_BYTE
 BYTES
UNIT
MISSING_CONSTANT = 999.9
FORMAT = "F7.1"
= "T_HVC
- COLUMN
  BYTES
                          = "DEGREE CELSIUS"
                          = "T_HVC MOTHERBOARD TEMPERATURE MINIMUM"
END OBJECT
                          = COLUMN
OBJECT
                          = COLUMN
  COLUMN_NUMBER
                          = 22
                         = "T HVC MEAN"
  NAME
  DATA_TYPE
START_BYTE
                         = ASCII_REAL
                         = 169
  BYTES
                          = "DEGREE CELSIUS"
  UNIT
  MISSING_CONSTANT
                          = 999.9
                         = "F7.1"
  FORMAT
                          = "T_HVC MOTHERBOARD TEMPERATURE MEAN"
  DESCRIPTION
END_OBJECT
                          = COLUMN
                          = COLUMN
OBJECT.
  COLUMN_NUMBER
                          = 23
  NAME
                          = "T HVC MAX"
  DATA_TYPE
                          = ASCII_REAL
  START_BYTE
                          = 177
  BYTES
                          = "DEGREE CELSIUS"
  UNIT
  MISSING_CONSTANT
                          = 999.9
                          = "F7.1"
  FORMAT
                          = "T_HVC MOTHERBOARD TEMPERATURE MAXIMUM"
  DESCRIPTION
```

```
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
 COLUMN NUMBER
                        = 24
                        = "T_HVC_STD"
 NAME
 DATA TYPE
                        = ASCII REAL
 START_BYTE
                        = 185
 BYTES
                        = 7
                        = "DEGREE CELSIUS"
 UNIT
 MISSING_CONSTANT
                        = 999.9
                        = "F7.1"
 FORMAT
                        = "T_HVC MOTHERBOARD TEMPERATURE STANDARD DEVIATION"
 DESCRIPTION
                         = COLUMN
END_OBJECT
OBJECT
                         = COLUMN
 COLUMN NUMBER
                        = 25
                        = "V_EL1_MIN"
 NAME
 DATA_TYPE
                         = ASCII_REAL
 START_BYTE
                        = 193
                        = 7
= "V0LT"
 BYTES
 UNIT
 MISSING_CONSTANT
                        = 99999.9
                        = "F7.1"
 FORMAT
                         = "V_EL1 EXTRACTION LENS 1 VOLTAGE MINIMUM,
 DESCRIPTION
                           IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                         = COLUMN
OBJECT
                        = COLUMN
                        = 26
= "V_EL1_MEAN"
 COLUMN_NUMBER
 NAME
 DATA TYPE
                        = ASCII_REAL
                         = 201
 START_BYTE
 BYTES
                        = 7
                        = "V0LT"
 UNIT
                        = 99999.9
 MISSING_CONSTANT
 FORMAT
                         = "F7.1"
                         = "V EL1 EXTRACTION LENS 1 VOLTAGE MEAN,
 DESCRIPTION
                            IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
 COLUMN_NUMBER
                         = 27
                        = "V EL1 MAX"
 NAME
                        = ASCII_REAL
 DATA_TYPE
 START BYTE
                        = 209
 BYTES
                        = "V0LT"
 UNIT
 MISSING_CONSTANT
                        = 99999.9
                        = "F7.1"
 FORMAT
                         = "V_EL1 EXTRACTION LENS 1 VOLTAGE MAXIMUM,
 DESCRIPTION
                           IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
 COLUMN_NUMBER
                        = 28
                        = "V_EL1_STD"
 NAME
 DATA_TYPE
                        = ASCII_REAL
 START_BYTE
                        = 217
 BYTES
                        = 7
                        = "V0LT"
 UNIT
 MISSING_CONSTANT
                        = 99999.9
                         = "F7.1"
 FORMAT
                         = "V_EL1 EXTRACTION LENS 1 VOLTAGE STANDARD DEVIATION,
 DESCRIPTION
                           IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
                        = 29
= "V_TOF1_MIN"
 COLUMN_NUMBER
 NAME
                        = ASCII_REAL
 DATA TYPE
 \mathsf{STAR}\overline{\mathsf{T}}\_\mathsf{BYTE}
                        = 225
 BYTES
 UNIT
                        = "V0LT"
                         = 99999.9
 MISSING_CONSTANT
```

```
= "F7.1"
  FORMAT
 DESCRIPTION
                        = "V_TOF1 HIGH VOLTAGE CONVERTER 1 VOLTAGE MINIMUM,
                           IN THE TIME-OF-FLIGHT SECTION"
END OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
 COLUMN_NUMBER
                        = 30
                        = "V_T0F1_MEAN"
  NAME
  DATA TYPE
                        = ASCII REAL
  START_BYTE
                        = 233
  BYTES
                        = 7
  UNIT
                        = "V0LT"
                        = 99999.9
 MISSING_CONSTANT
                        = "F7.1"
  FORMAT
  DESCRIPTION
                        = "V TOF1 HIGH VOLTAGE CONVERTER 1 VOLTAGE MEAN,
                            IN THE TIME-OF-FLIGHT SECTION"
END OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
                        = 31
= "V_T0F1_MAX"
  COLUMN_NUMBER
  NAME
                        = ASCII_REAL
  DATA TYPE
  START_BYTE
                        = 241
  BYTES
                        = "V0LT"
 UNIT
                        = 99999.9
 {\tt MISSING\_CONSTANT}
  FORMAT
                        = "F7.1"
 DESCRIPTION
                           "V TOF1 HIGH VOLTAGE CONVERTER 1 VOLTAGE MAXIMUM,
                           IN THE TIME-OF-FLIGHT SECTION"
END OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                        = 32
                        = "V TOF1 STD"
  NAME
                        = ASCII_REAL
  DATA_TYPE
  START BYTE
                          249
  BYTES
                        = 7
                        = "V0LT"
  UNIT
                        = 99999.9
  MISSING_CONSTANT
  FORMAT
                        = "F7.1"
                        = "V_TOF1 HIGH VOLTAGE CONVERTER 1 VOLTAGE STANDARD
  DESCRIPTION
                           DEVIATION, IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 33
                        = "V_T0F2_MIN"
  NAME
  DATA_TYPE
                        = ASCII_REAL
  START BYTE
                        = 257
  BYTES
                        = 7
                        = "V0LT"
  UNIT
                        = 99999.9
 MISSING_CONSTANT
                        = "F7.1"
  FORMAT
  DESCRIPTION
                        = "V_TOF2 HIGH VOLTAGE CONVERTER 2 VOLTAGE MINIMUM,
                            IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 34
                          "V TOF2_MEAN"
  NAME
  DATA TYPE
                        = ASCII_REAL
  START_BYTE
                        = 265
  BYTES
                        = "V0LT"
  UNIT
                        = 99999.9
  MISSING_CONSTANT
  FORMAT
                        = "F7.1"
                          "V TOF2 HIGH VOLTAGE CONVERTER 2 VOLTAGE MEAN,
 DESCRIPTION
                            IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                        = COLUMN
                        = COLUMN
OBJECT.
  COLUMN_NUMBER
                        = 35
  NAME
                        = "V TOF2 MAX"
 DATA_TYPE
                        = ASCII_REAL
```

```
START BYTE
                         = 273
  BYTES
                         = 7
                         = "V0LT"
  UNIT
                        = 99999.9
 MISSING_CONSTANT
                         = "F7.1"
  FORMAT
  DESCRIPTION
                         = "V TOF2 HIGH VOLTAGE CONVERTER 2 VOLTAGE MAXIMUM,
                            IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
                        = 36
= "V_T0F2_STD"
  COLUMN NUMBER
  NAME
                         = ASCII_REAL
  DATA TYPE
  START_BYTE
                         = 281
  BYTES
                           "VOLT"
  UNIT
                         =
 MISSING_CONSTANT
                         = 99999.9
  FORMAT
                         = "F7.1"
 DESCRIPTION
                         = "V TOF2 HIGH VOLTAGE CONVERTER 2 VOLTAGE STANDARD
                            DEVIATION, IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                         = COLUMN
                         = COLUMN
OBJECT.
  COLUMN NUMBER
                           37
                           "V DT MIN"
  NAME
                         = ASCII_REAL
 DATA_TYPE
  START_BYTE
                         =
                           289
  BYTES
                         = 7
                         = "V0LT"
  UNIT
                         = 99999.9
  MISSING CONSTANT
                         = "F7.1"
  FORMAT
                         = "V_DT DRIFT TUBE VOLTAGE MINIMUM,
  DESCRIPTION
                            IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                         = 38
                         = "V_DT_MEAN"
  NAME
  DATA_TYPE
                         = ASCII_REAL
  START_BYTE
                         = 297
  BYTES
                         = 7
                         = "V0LT"
  UNIT
 {\tt MISSING\_CONSTANT}
                         = 99999.9
                         = "F7.1"
  FORMAT
                         = "V DT DRIFT TUBE VOLTAGE MEAN,
  DESCRIPTION
                            IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
                         = 39
= "V DT MAX"
  COLUMN_NUMBER
  DATA TYPE
                         = ASCII REAL
  START_BYTE
                         = 305
  BYTES
                         = "V0LT"
  UNIT
                        = 99999.9
= "F7.1"
 MISSING_CONSTANT
  FORMAT
 DESCRIPTION
                         = "V DT DRIFT TUBE VOLTAGE MAXIMUM,
                            IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
  COLUMN_NUMBER
                         = 40
                           "V DT STD"
  NAME
 DATA_TYPE
                         = ASCII_REAL
  START BYTE
                           313
  BYTES
                         =
                         = "V0LT"
  UNIT
 MISSING_CONSTANT
                        = 99999.9
                           "F7.1"
  FORMAT
 DESCRIPTION
                         = "V DT DRIFT TUBE VOLTAGE STANDARD DEVIATION,
                            IN THE TIME-OF-FLIGHT SECTION"
END OBJECT
                         = COLUMN
```

```
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 41
  NAME
                        = "V PA MIN"
                        = ASCII_REAL
  DATA TYPE
  START_BYTE
                        = 321
  BYTES
                        = 7
                        = "V0LT"
  UNIT
 MISSING_CONSTANT
                        = 99999.9
  FORMAT
                         = "F7.1"
                        = "V PA POST-ACCELERATION VOLTAGE MINIMUM.
 DESCRIPTION
                           IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  COLUMN NUMBER
                         = "V PA MEAN"
  NAME
 DATA_TYPE
                         = ASCII REAL
  START_BYTE
                         = 329
  BYTES
                        = 7
                        = "V0LT"
  UNIT
                        = 99999.9
 MISSING_CONSTANT
                           "F7.1"
  FORMAT
                         =
 DESCRIPTION
                         = "V PA POST-ACCELERATION VOLTAGE MEAN,
                            IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                        = 43
                        = "V PA_MAX"
  NAME
  DATA TYPE
                         = ASCII REAL
  START BYTE
                        = 337
  BYTES
                        = 7
                        = "V0LT"
  UNIT
                        = 99999.9
  MISSING_CONSTANT
                        = "F7.1"
  FORMAT
                         = "V_PA POST-ACCELERATION VOLTAGE MAXIMUM,
  DESCRIPTION
                            IN THE TIME-OF-FLIGHT SECTION"
END OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                        = 44
                        = "V PA STD"
  NAME
  DATA TYPE
                         = ASCII REAL
  START_BYTE
                         = 345
  BYTES
                         = 7
                        = "V0LT"
  UNIT
 {\tt MISSING\_CONSTANT}
                        = 99999.9
                         = "F7.1"
  FORMAT
  DESCRIPTION
                           "V PA POST-ACCELERATION VOLTAGE STANDARD DEVIATION,
                            IN THE TIME-OF-FLIGHT SECTION"
END OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
  COLUMN_NUMBER
                         = 45
                           "V DET MIN"
  NAME
 DATA_TYPE
START_BYTE
                        = ASCII_REAL
                        = 353
  BYTES
                        = "V0LT"
  UNIT
                        = 99999.9
  MISSING_CONSTANT
                        = "F7.1"
  FORMAT
                         = "V_DET ION DETECTOR VOLTAGE MINIMUM,
  DESCRIPTION
                            IN THE TIME-OF-FLIGHT SECTION"
                         = COLUMN
END_OBJECT
OBJECT
                         = COLUMN
 COLUMN_NUMBER
                        = 46
                         = "V_DET_MEAN"
  NAME
  DATA_TYPE
                        = ASCII_REAL
  START_BYTE
                        = 361
  BYTES
                        = 7
                        = "V0LT"
  UNIT
  MISSING CONSTANT
                        = 99999.9
                         = "F7.1"
  FORMAT
```

```
DESCRIPTION
                        = "V DET ION DETECTOR VOLTAGE MEAN.
                           IN THE TIME-OF-FLIGHT SECTION"
END OBJECT
                         = COLUMN
                        = COLUMN
OBJECT
  COLUMN NUMBER
                        = 47
                           "V DET MAX"
  NAME
                        =
 DATA_TYPE
                        = ASCII_REAL
  START BYTE
                        = 369
  BYTES
                        = 7
                        = "V0LT"
  UNIT
  MISSING_CONSTANT
                        = 99999.9
  FORMAT
                        = "F7.1"
 DESCRIPTION
                        = "V_DET ION DETECTOR VOLTAGE MAXIMUM,
                           IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 48
                        = "V DET_STD"
  NAME
                        = ASCII_REAL
  DATA_TYPE
  START_BYTE
                        = 377
  BYTFS
                        = 7
                        = "V0LT"
  UNIT
                        = 99999.9
 MISSING_CONSTANT
                        = "F7.1"
  FORMAT
                        = "V_DET ION DETECTOR VOLTAGE STANDARD DEVIATION,
 DESCRIPTION
                           IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                        = 49
  NAME
                        = "V_DX_TOF_MIN"
  DATA TYPE
                        = ASCII_REAL
  START_BYTE
                        = 385
  BYTES
                        = "V0LT"
 UNIT
                        = 99999.9
 {\tt MISSING\_CONSTANT}
  FORMAT
                        = "F7.1"
 DESCRIPTION
                          "V DX TOF X-DIRECTION DEFLECTION VOLTAGE MINIMUM,
                           IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN NUMBER
                        = "V_DX_TOF_MEAN"
  NAME
 DATA_TYPE
                        = ASCII_REAL
  START_BYTE
                        = 393
  BYTES
                        = 7
                        = "V0LT"
  UNTT
                        = 99999.9
  MISSING CONSTANT
                        = "F7.1"
  FORMAT
 DESCRIPTION
                        = "V_DX_TOF X-DIRECTION DEFLECTION VOLTAGE MEAN,
                            IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN NUMBER
                        = 51
                        = "V_DX_T0F_MAX"
  NAME
  DATA_TYPE
                        = ASCII_REAL
  START_BYTE
                        = 401
                        = 7
  BYTES
                        = "V0LT"
  UNIT
                        = 99999.9
 MISSING_CONSTANT
                        = "F7.1"
  FORMAT
                           "V DX TOF X-DIRECTION DEFLECTION VOLTAGE MAXIMUM,
  DESCRIPTION
                            IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 52
                        = "V DX TOF STD"
  NAME
  DATA TYPE
                        = ASCII REAL
  START_BYTE
                        = 409
```

```
BYTES
                           = 7
                           = "V0LT"
  UNIT
  MISSING CONSTANT
                           = 99999.9
  FORMAT
                             "F7.1"
 DESCRIPTION
                           = "V_DX_TOF X-DIRECTION DEFLECTION VOLTAGE STANDARD
                              DEVIATION, IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
OBJECT
                           = COLUMN
  COLUMN NUMBER
                           = 53
                           = "V_DY_TOF_MIN"
  NAME
  DATA_TYPE
                           = ASCII_REAL
  START_BYTE
                           = 417
  BYTES
                           = 7
                           = "V0LT"
  UNIT
                           = 99999.9
 MISSING_CONSTANT
                           = "F7.1"
  FORMAT
                           = "V DY TOF Y-DIRECTION DEFLECTION VOLTAGE MINIMUM,
  DESCRIPTION
                              \overline{\mathsf{IN}} \overline{\mathsf{THE}} \overline{\mathsf{TIME}} \overline{\mathsf{OF}} \overline{\mathsf{FLIGHT}} \overline{\mathsf{SECTION}}"
END_OBJECT
                           = COLUMN
OBJECT
                           = COLUMN
                           = 54
= "V_DY_TOF_MEAN"
  COLUMN_NUMBER
  NAME
  DATA TYPE
                           = ASCII_REAL
  \mathsf{STAR}\overline{\mathsf{T}}_{\mathsf{BYTE}}
                           = 425
  BYTES
                           = 7
                             "VOLT"
  UNIT
                           =
                           = 99999.9
  MISSING_CONSTANT
  FORMAT
                           = "F7.1"
 DESCRIPTION
                             "V DY TOF Y-DIRECTION DEFLECTION VOLTAGE MEAN.
                              IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                           = COLUMN
                           = COLUMN
OBJECT
  COLUMN_NUMBER
                             55
                             "V DY TOF MAX"
  NAME
                           =
                           = ASCII_REAL
 DATA_TYPE
  START_BYTE
                           = 433
  BYTES
                           = "V0LT"
  UNIT
  MISSING_CONSTANT
                           = 99999.9
                           = "F7.1"
  FORMAT
 DESCRIPTION
                           = "V DY TOF Y-DIRECTION DEFLECTION VOLTAGE MAXIMUM,
                               IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                           = COLUMN
OBJECT
                           = COLUMN
 COLUMN_NUMBER
                           = 56
                           = "V_DY_TOF_STD"
  NAME
  DATA TYPE
                           = ASCII REAL
  START_BYTE
                           = 441
  BYTES
                           = 7
  UNIT
                           = "V0LT"
 MISSING_CONSTANT
                           = 99999.9
                           = "F7.1"
  FORMAT
                           = "V_DY_TOF Y-DIRECTION DEFLECTION VOLTAGE STANDARD
  DESCRIPTION
                              DEVIATION, IN THE TIME-OF-FLIGHT SECTION"
END_OBJECT
                           = COLUMN
                           = COLUMN
OBJECT
                           = 57
= "V_L1_MIN"
  COLUMN_NUMBER
  NAME
                           = ASCII_REAL
  DATA TYPE
  START_BYTE
                           = 449
  BYTES
  UNIT
                             "V0LT"
                           = 99999.9
  MISSING_CONSTANT
                           = "F7.1"
  FORMAT
                             "V L1 LENS 1 VOLTAGE MINIMUM,
  DESCRIPTION
                              IN THE PRIMARY ION BEAM SYSTEM"
END OBJECT
                           = COLUMN
                           = COLUMN
OBJECT
```

```
COLUMN_NUMBER
                        = 58
                        = "V_L1_MEAN"
  NAME
  DATA TYPE
                        = ASCII_REAL
  START_BYTE
                        = 457
                        = 7
  BYTES
  UNIT
                        = "V0LT"
 MISSING_CONSTANT
                        = 99999.9
                        = "F7.1"
  FORMAT
                        = "V_L1 LENS 1 VOLTAGE MEAN,
IN THE PRIMARY ION BEAM SYSTEM"
  DESCRIPTION
END_OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                        = 59
                        = "V L1 MAX"
  DATA TYPE
                        = ASCII_REAL
  START_BYTE
                        = 465
  BYTES
                        = 7
                        = "V0LT"
 UNIT
 MISSING_CONSTANT
                     = 99999.9
                        = "F7.1"
  FORMAT
                        = "V_L1 LENS 1 VOLTAGE MAXIMUM,
 DESCRIPTION
                         IN THE PRIMARY ION BEAM SYSTEM"
END OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                        = "V L1 STD"
  NAME
 DATA_TYPE
                        = ASCII_REAL
  START BYTE
                        = 473
  BYTES
                       = 7
 = "VOLT"
FORMAT
DESCRIPTION

= "VOLT"
= 99999.9
= "F7.3"
 FUKMAI
DESCRIPTION
                        = "V_L1 LENS 1 VOLTAGE STANDARD DEVIATION,
                        IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
 COLUMN_NUMBER
                        = 61
                        = "V_L2_MIN"
  NAME
  DATA_TYPE
                        = ASCII_REAL
  START BYTE
                        = 481
  BYTES
                        = 7
                        = "V0LT"
  UNIT
 MISSING_CONSTANT = 99999.9
FORMAT = "F7.1"
                        = "V_L2 LENS 2 VOLTAGE MINIMUM,
  DESCRIPTION
                          IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 62
  NAME
                        = "V_L2_MEAN"
  DATA TYPE
                        = ASCII_REAL
  START_BYTE
                        = 489
  BYTES
                        = 7
                        = "V0LT"
  UNIT
 MISSING_CONSTANT
                        = 99999.9
  FORMAT
                        = "F7.1"
 DESCRIPTION
                        = "V L2 LENS 2 VOLTAGE MEAN,
                          IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                        = COLUMN
                        = COLUMN
OBJECT.
  COLUMN NUMBER
                        = 63
  NAME
                        = "V L2 MAX"
 DATA_TYPE
                        = ASCII_REAL
  START_BYTE
                        = 497
  BYTES
                        = 7
                        = "V0LT"
  UNIT
                        = 99999.9
  MISSING_CONSTANT
  FORMAT
                        = "F7.1"
                        = "V_L2 LENS 2 VOLTAGE MAXIMUM,
  DESCRIPTION
```

```
IN THE PRIMARY ION BEAM SYSTEM"
END OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                         = 64
  NAME
                         = "V L2 STD"
  DATA TYPE
                         = ASCII_REAL
  \mathsf{STAR}\overline{\mathsf{T}}_\mathsf{BYTE}
                         = 505
  BYTES
                         = 7
                         = "V0LT"
  UNIT
  {\tt MISSING\_CONSTANT}
                         = 99999.9
  FORMAT
                         = "F7.1"
                         = "V L2 LENS 2 VOLTAGE STANDARD DEVIATION,
  DESCRIPTION
                            IN THE PRIMARY ION BEAM SYSTEM"
END OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
  COLUMN_NUMBER
                         = 65
                         = "V BS1 MIN"
  NAME
  DATA_TYPE
START_BYTE
                         = ASCII_REAL
                         = 513
  BYTES
                         = 7
                         = "V0LT"
  UNIT
                         = 99999.9
  MISSING CONSTANT
                         = "F7.1"
  FORMAT
  DESCRIPTION
                         = "V_BS1 BEAM SWITCH 1 VOLTAGE MINIMUM,
                            IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                         = 66
                         = "V_BS1_MEAN"
  NAME
  DATA_TYPE
                         = ASCII_REAL
  START_BYTE
                         = 521
  BYTES
                         = 7
                         = "V0LT"
  UNIT
                         = 99999.9
  MISSING_CONSTANT
                         = "F7.1"
  FORMAT
                         = "V_BS1 BEAM SWITCH 1 VOLTAGE MEAN,
  DESCRIPTION
                            IN THE PRIMARY ION BEAM SYSTEM"
                         = COLUMN
END_OBJECT
                         = COLUMN
OBJECT
  COLUMN_NUMBER
                         = 67
                         = "V BS1 MAX"
  NAME
  DATA TYPE
                         = ASCII_REAL
  START_BYTE
                         = 529
  BYTES
                         = 7
                         = "V0LT"
  UNIT
                         = 99999.9
  MISSING_CONSTANT
  FORMAT
                         = "F7.1"
  DESCRIPTION
                         = "V BS1 BEAM SWITCH 1 VOLTAGE MAXIMUM,
                            IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
  COLUMN_NUMBER
                         = 68
                         = "V BS1 STD"
  NAME
  DATA_TYPE
                         = ASCII_REAL
  START_BYTE
                         = 537
  BYTES
                         = "V0LT"
  UNIT
                         = 99999.9
  MISSING_CONSTANT
                         = "F7.1"
  FORMAT
  DESCRIPTION
                         = "V BS1 BEAM SWITCH 1 VOLTAGE STANDARD DEVIATION,
                            IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                         = 69
                         = "V_BS2_MIN"
  NAME
  DATA_TYPE
                         = ASCII REAL
  START BYTE
                         = 545
  BYTES
                         = 7
```

```
= "V0LT"
  UNIT
 MISSING_CONSTANT
                        = 99999.9
  FORMAT
                        = "F7.1"
 DESCRIPTION
                        = "V BS2 BEAM SWITCH 2 VOLTAGE MINIMUM,
                           IN THE PRIMARY ION BEAM SYSTEM"
END OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN NUMBER
                        = "V BS2 MEAN"
  NAME
 DATA_TYPE
                        = ASCII_REAL
  START_BYTE
                        = 553
  BYTES
                        = 7
                        = "V0LT"
  UNIT
  MISSING CONSTANT
                        = 99999.9
                          "F7.1"
  FORMAT
                        = "V_BS2 BEAM SWITCH 2 VOLTAGE MEAN,
 DESCRIPTION
                           IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 71
                        = "V_BS2_MAX"
  NAME
 DATA_TYPE
                        = ASCII REAL
  START_BYTE
                        = 561
  BYTES
                        = 7
                        = "V0LT"
  UNIT
                        = 99999.9
 MISSING_CONSTANT
                        = "F7.1"
  FORMAT
                        = "V BS2 BEAM SWITCH 2 VOLTAGE MAXIMUM,
  DESCRIPTION
                            IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 72
                           "V_BS2_STD"
  NAME
  DATA TYPE
                        = ASCII_REAL
  START_BYTE
                        = 569
  BYTES
  UNIT
                        = "V0LT"
 {\tt MISSING\_CONSTANT}
                        = 99999.9
                        = "F7.1"
  FORMAT
  DESCRIPTION
                           "V BS2 BEAM SWITCH 2 VOLTAGE STANDARD DEVIATION,
                           IN THE PRIMARY ION BEAM SYSTEM"
END OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 73
                           "V CB1 MIN"
  NAME
                        =
                        = ASCII_REAL
 DATA_TYPE
  START BYTE
                        = 577
                        = 7
  BYTES
                        = "V0LT"
  UNIT
  MISSING_CONSTANT
                        = 99999.9
                        = "F7.1"
  FORMAT
                        = "V_CB1 BEAM CHOPPER POSITIVE VOLTAGE MINIMUM,
 DESCRIPTION
                            IN THE PRIMARY ION BEAM SYSTEM"
END OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
 COLUMN_NUMBER
                        = 74
                        = "V CB1_MEAN"
  NAME
  DATA_TYPE
                        = ASCII_REAL
  START BYTE
                        = 585
  BYTES
                        = 7
                        = "V0LT"
  UNIT
 MISSING_CONSTANT
                        = 99999.9
                        = "F7.1"
  FORMAT
                        = "V_CB1 BEAM CHOPPER POSITIVE VOLTAGE MEAN,
  DESCRIPTION
                            IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                        = COLUMN
                        = COLUMN
  COLUMN_NUMBER
                        = 75
```

```
= "V CB1 MAX"
 NAME
                        = ASCII_REAL
 DATA_TYPE
 START_BYTE
                        = 593
 BYTES
                        = 7
                        = "V0LT"
 UNIT
 MISSING CONSTANT
                        = 99999.9
                        = "F7.1"
 FORMAT
 DESCRIPTION
                        = "V_CB1 BEAM CHOPPER POSITIVE VOLTAGE MAXIMUM,
                           IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
 COLUMN_NUMBER
                        = 76
                        = "V_CB1_STD"
 NAME
 DATA TYPE
                        = ASCII REAL
 START_BYTE
                        = 601
 BYTES
                        = 7
                        = "V0LT"
 UNIT
 {\tt MISSING\_CONSTANT}
                        = 99999.9
                        = "F7.1"
 FORMAT
                        = "V_CB1 BEAM CHOPPER POSITIVE VOLTAGE STANDARD
 DESCRIPTION
                           DEVIATION, IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
                        = 77
= "V_CB2_MIN"
 COLUMN_NUMBER
 NAME
 DATA_TYPE
                        = ASCII_REAL
 START_BYTE
                        = 609
 BYTES
                        = "V0LT"
 UNIT
 {\tt MISSING\_CONSTANT}
                        = 99999.9
 FORMAT
                        = "F7.1"
                        = "V CB2 BEAM CHOPPER NEGATIVE VOLTAGE MINIMUM,
 DESCRIPTION
                           IN THE PRIMARY ION BEAM SYSTEM"
END OBJECT
                        = COLUMN
OBJECT
 COLUMN_NUMBER
                        = 78
 NAME
                        = "V CB2 MEAN"
 DATA_TYPE
                        = ASCII_REAL
 START_BYTE
                        = 617
 BYTES
                        = 7
                        = "V0LT"
 UNTT
                        = 99999.9
 MISSING CONSTANT
                        = "F7.1"
 FORMAT
 DESCRIPTION
                        = "V_CB2 BEAM CHOPPER NEGATIVE VOLTAGE MEAN,
                           IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
 COLUMN NUMBER
                        = 79
                        = "V_CB2_MAX"
 NAME
 DATA_TYPE
START_BYTE
                        = ASCII_REAL
                        = 625
 BYTES
                        = 7
                        = "V0LT"
 UNIT
 MISSING CONSTANT
                        = 99999.9
 FORMAT
                        = "F7.1"
                        = "V_CB2 BEAM CHOPPER NEGATIVE VOLTAGE MAXIMUM,
 DESCRIPTION
                           IN THE PRIMARY ION BEAM SYSTEM"
                        = COLUMN
END_OBJECT
OBJECT
                        = COLUMN
 COLUMN_NUMBER
                        = 80
                          "V CB2 STD"
 NAME
 DATA TYPE
                        = ASCII_REAL
 START_BYTE
                        = 633
 BYTES
                        = 7
                        = "V0LT"
 UNIT
                        = 99999.9
 MISSING_CONSTANT
 FORMAT
                        = "F7.1"
 DESCRIPTION
                        = "V CB2 BEAM CHOPPER NEGATIVE VOLTAGE STANDARD
                           DEVIATION, IN THE PRIMARY ION BEAM SYSTEM"
```

```
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
                        = 81
= "V_DX_PIBS_MIN"
  COLUMN NUMBER
  NAME
  DATA TYPE
                         = ASCII REAL
  START_BYTE
                         = 641
  BYTES
                        = 7
                         = "V0LT"
  UNIT
                        = 99999.9
 MISSING_CONSTANT
                         = "F7.1"
  FORMAT
                         = "V_DX_PIBS X-DIRECTION DEFLECTION VOLTAGE MINIMUM,
  DESCRIPTION
                           IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                         = 82
  NAME
                          "V_DX_PIBS_MEAN"
                         = ASCII_REAL
  DATA TYPE
  START_BYTE
                         = 649
  BYTES
                         = 7
                         = "V0LT"
  UNIT
 MISSING_CONSTANT
                         = 99999.9
  FORMAT
                         = "F7.1"
 DESCRIPTION
                          "V DX PIBS X-DIRECTION DEFLECTION VOLTAGE MEAN,
                           IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
  COLUMN NUMBER
                         = 83
                          "V DX PIBS MAX"
  NAME
                         =
                         = ASCII_REAL
 DATA_TYPE
  START_BYTE
                        = 657
  BYTES
                        = 7
                        = "V0LT"
  UNIT
                         = 99999.9
  MISSING CONSTANT
                         = "F7.1"
  FORMAT
 DESCRIPTION
                         = "V DX PIBS X-DIRECTION DEFLECTION VOLTAGE MAXIMUM,
                            IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
 COLUMN_NUMBER
                         = 84
                         = "V_DX_PIBS_STD"
  NAME
  DATA TYPE
                        = ASCII REAL
  START_BYTE
                        = 665
  BYTES
                         = 7
                         = "V0LT"
  UNIT
                         = 99999.9
 MISSING_CONSTANT
                         = "F7.1"
  FORMAT
                         = "V DX PIBS X-DIRECTION DEFLECTION VOLTAGE STANDARD
  DESCRIPTION
                            DEVIATION, IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
                        = 85
= "V_DY_PIBS_MIN"
  COLUMN_NUMBER
  NAME
  DATA TYPE
                         = ASCII REAL
  START_BYTE
                         = 673
  BYTES
                        = "V0LT"
 UNIT
                         = 99999.9
 MISSING_CONSTANT
                         = "F7.1"
  FORMAT
 DESCRIPTION
                           "V DY PIBS Y-DIRECTION DEFLECTION VOLTAGE MINIMUM,
                            IN THE PRIMARY ION BEAM SYSTEM"
END OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                         = 86
                         = "V DY PIBS MEAN"
  NAME
 DATA_TYPE
                         = ASCII_REAL
  START BYTE
                         = 681
  BYTES
                         = "V0LT"
  UNIT
```

```
= 99999.9
 MISSING_CONSTANT
                        = "F7.1"
  FORMAT
                        = "V DY PIBS Y-DIRECTION DEFLECTION VOLTAGE MEAN,
 DESCRIPTION
                           IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                        = 87
                        = "V DY PIBS MAX"
  NAME
  DATA TYPE
                        = ASCII_REAL
  START_BYTE
                        = 689
  BYTES
                        = 7
                        = "V0LT"
 UNIT
                        = 99999.9
 {\tt MISSING\_CONSTANT}
  FORMAT
                        = "F7.1"
 DESCRIPTION
                        = "V DY PIBS Y-DIRECTION DEFLECTION VOLTAGE MAXIMUM.
                           IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 88
                        = "V_DY_PIBS_STD"
  NAME
                        = ASCII_REAL
  DATA_TYPE
  START BYTE
                        = 697
  BYTES
                        = 7
                        = "V0LT"
  UNIT
  MISSING_CONSTANT
                        = 99999.9
                        = "F7.1"
  FORMAT
                        = "V_DY_PIBS Y-DIRECTION DEFLECTION VOLTAGE STANDARD
 DESCRIPTION
                           DEVIATION, IN THE PRIMARY ION BEAM SYSTEM"
END_OBJECT
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 89
                        = "V_TIP_MIN"
  NAME
  DATA TYPE
                        = ASCII REAL
  START BYTE
                        = 705
  BYTES
                        = 7
                        = "V0LT"
  UNIT
 MISSING_CONSTANT
                        = 99999.9
                        = "F7.1"
  FORMAT
                        = "V_TIP TIP VOLTAGE MINIMUM,
  DESCRIPTION
                           IN THE PRIMARY ION SOURCE"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
                        = 90
= "V_TIP_MEAN"
  COLUMN_NUMBER
  NAME
  DATA TYPE
                        = ASCII_REAL
  START_BYTE
                        = 713
  BYTES
                        = 7
                        = "V0LT"
  UNIT
  MISSING_CONSTANT
                        = 99999.9
  FORMAT
                        = "F7.1"
 DESCRIPTION
                        = "V TIP TIP VOLTAGE MEAN,
                           IN THE PRIMARY ION SOURCE"
END_OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                        = 91
                          "V_TIP_MAX"
  NAME
                        = ASCII_REAL
 DATA_TYPE
  START_BYTE
                        = 721
  BYTES
                        = 7
                        = "V0LT"
  UNTT
                        = 99999.9
  MISSING CONSTANT
  FORMAT
                        = "F7.1"
                        = "V_TIP TIP VOLTAGE MAXIMUM,
  DESCRIPTION
                           IN THE PRIMARY ION SOURCE"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN NUMBER
                        = 92
                        = "V_TIP_STD"
  NAME
```

```
DATA TYPE
                       = ASCII REAL
  START_BYTE
                        = 729
  BYTES
                       = "V0LT"
  UNIT
  MISSING_CONSTANT
                       = 99999.9
  FORMAT
                       = "F7.1"
 DESCRIPTION
                       = "V TIP TIP VOLTAGE STANDARD DEVIATION,
                          IN THE PRIMARY ION SOURCE"
END OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                       = 93
                       = "C TIP MIN"
  NAME
 DATA_TYPE
                       = ASCII_REAL
  START_BYTE
                       = 737
  BYTES
                       = 7
                       = "MICROAMPERE"
  UNIT
  MISSING_CONSTANT
                       = 99999.9
                       = "F7.1"
  FORMAT
 DESCRIPTION
                        = "C_TIP TIP CURRENT MINIMUM,
                          IN THE PRIMARY ION SOURCE'
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
 {\tt COLUMN\_NUMBER}
                       = 94
                       = "C_TIP_MEAN"
  NAME
  DATA_TYPE
                       = ASCII_REAL
  START_BYTE
                       = 745
  BYTES
                       = 7
  UNIT
                       = "MICROAMPERE"
 MISSING_CONSTANT
                       = 99999.9
                       = "F7.1"
  FORMAT
  DESCRIPTION
                       = "C_TIP TIP CURRENT MEAN,
                        IN THE PRIMARY ION SOURCE"
                        = COLUMN
END_OBJECT
OBJECT
                       = COLUMN
                       = 95
= "C_TIP_MAX"
  COLUMN_NUMBER
  NAME
  DATA_TYPE
                       = ASCII_REAL
  START_BYTE
                       = 753
  BYTES
                       = 7
                       = "MICROAMPERE"
  UNIT
 MISSING_CONSTANT
                       = 99999.9
  FORMAT
                       = "F7.1"
                       = "C TIP TIP CURRENT MAXIMUM,
 DESCRIPTION
                          IN THE PRIMARY ION SOURCE"
END_OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
  COLUMN NUMBER
                       = "C TIP STD"
  NAME
 DATA_TYPE
                       = ASCII_REAL
  START_BYTE
                       = 761
  BYTES
                       = "MICROAMPERE"
  UNIT
 MISSING_CONSTANT
                       = 99999.9
                       = "F7.1"
  FORMAT
 DESCRIPTION
                        = "C_TIP TIP VOLTAGE STANDARD DEVIATION,
                          IN THE PRIMARY ION SOURCE"
                        = COLUMN
END_OBJECT
OBJECT
                        = COLUMN
                       = 97
  COLUMN_NUMBER
                        = "V_EXT_MIN"
  NAME
  DATA TYPE
                        = ASCII REAL
  START_BYTE
                       = 769
  BYTES
                       = 7
                       = "V0LT"
  UNIT
                       = 99999.9
  MISSING_CONSTANT
                       = "F7.1"
  FORMAT
                        = "V_EXT EXTRACTOR VOLTAGE MINIMUM,
  DESCRIPTION
                          IN THE PRIMARY ION SOURCE"
END_OBJECT
                        = COLUMN
```

```
= COLUMN
OBJECT
 COLUMN NUMBER
                        = 98
                        = "V EXT MEAN"
 NAME
 DATA_TYPE
                        = ASCII_REAL
 START_BYTE
                        = 777
 BYTES
                        = 7
                        = "V0LT"
 UNIT
                        = 99999.9
 MISSING CONSTANT
                         = "F7.1"
 FORMAT
 DESCRIPTION
                         = "V_EXT EXTRACTOR VOLTAGE MEAN,
                            IN THE PRIMARY ION SOURCE"
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
 COLUMN_NUMBER
                        = 99
                         = "V_EXT_MAX"
 NAME
 DATA_TYPE
                         = ASCII_REAL
 START_BYTE
                        = 785
                        = 7
= "V0LT"
 BYTES
 UNIT
 MISSING_CONSTANT
                        = 99999.9
                         = "F7.1"
 FORMAT
                         = "V_EXT EXTRACTOR VOLTAGE MAXIMUM,
 DESCRIPTION
                            IN THE PRIMARY ION SOURCE"
END_OBJECT
                         = COLUMN
OBJECT
                        = COLUMN
 COLUMN_NUMBER
                        = 100
                         = "V EXT STD"
 NAME
 DATA TYPE
                        = ASCII REAL
 START_BYTE
                         = 793
 BYTES
                        = 7
                        = "V0LT"
 UNIT
                        = 99999.9
 MISSING_CONSTANT
 FORMAT
                         = "F7.1"
                           "V EXT EXTRACTOR VOLTAGE STANDARD DEVIATION,
 DESCRIPTION
                            IN THE PRIMARY ION SOURCE"
END_OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
 COLUMN_NUMBER
                         = 101
                        = "C EXT MIN"
 NAME
 DATA_TYPE
                        = ASCII_REAL
 START BYTE
                        = 801
 BYTES
                        = 7
                        = "MICROAMPERE"
 UNIT
 MISSING_CONSTANT
                        = 99999.9
                        = "F7.1"
 FORMAT
                         = "C_EXT EXTRACTOR CURRENT MINIMUM,
 DESCRIPTION
                            IN THE PRIMARY ION SOURCE"
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
 COLUMN_NUMBER
                        = 102
                        = "C_EXT_MEAN"
 NAME
 DATA_TYPE
                        = ASCII_REAL
 START_BYTE
                        = 809
 BYTES
                        = 7
                        = "MICROAMPERE"
 UNIT
 MISSING_CONSTANT
                        = 99999.9
                         = "F7.1"
 FORMAT
                         = "C_EXT EXTRACTOR CURRENT MEAN,
 DESCRIPTION
                            IN THE PRIMARY ION SOURCE"
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
                        = 103
= "C_EXT_MAX"
 COLUMN_NUMBER
 NAME
 DATA TYPE
                        = ASCII_REAL
 \mathsf{STAR}\overline{\mathsf{T}}\_\mathsf{BYTE}
                        = 817
 BYTES
 UNIT
                        = "MICROAMPERE"
 MISSING_CONSTANT
                         = 99999.9
```

```
= "F7.1"
  FORMAT
 DESCRIPTION
                        = "C_EXT EXTRACTOR CURRENT MAXIMUM,
                          IN THE PRIMARY ION SOURCE"
END OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 104
                        = "C_EXT_STD"
  NAME
  DATA TYPE
                        = ASCII REAL
  START_BYTE
                       = 825
  BYTES
                        = 7
  UNIT
                        = "MICROAMPERE"
                       = 99999.9
 MISSING_CONSTANT
                        = "F7.1"
  FORMAT
                        = "C_EXT EXTRACTOR CURRENT STANDARD DEVIATION,
  DESCRIPTION
                          IN THE PRIMARY ION SOURCE"
END OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 105
= "V_HEATER_MIN"
  NAME
                        = ASCII_REAL
  DATA TYPE
  START_BYTE
                        = 833
  BYTES
                       = "V0LT"
 UNIT
 MISSING_CONSTANT
                       = 99999.9
  FORMAT
                        = "F7.1"
 DESCRIPTION
                        = "V HEATER HEATER VOLTAGE MINIMUM,
                           IN THE PRIMARY ION SOURCE"
END OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                        = 106
                        = "V HEATER MEAN"
  NAME
 DATA_TYPE
                        = ASCII_REAL
  START BYTE
                        = 841
  BYTES
                        = 7
                        = "V0LT"
  UNIT
                       = 99999.9
  MISSING_CONSTANT
  FORMAT
                        = "F7.1"
 DESCRIPTION
                        = "V_HEATER HEATER VOLTAGE MEAN,
                           IN THE PRIMARY ION SOURCE"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 107
                        = "V_HEATER_MAX"
  NAME
  DATA_TYPE
                        = ASCII_REAL
  START BYTE
                        = 849
  BYTES
                        = 7
                        = "V0LT"
  UNIT
                       = 99999.9
 MISSING_CONSTANT
                        = "F7.1"
  FORMAT
                        = "V_HEATER HEATER VOLTAGE MAXIMUM,
  DESCRIPTION
                           IN THE PRIMARY ION SOURCE"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 108
                        = "V_HEATER_STD"
  NAME
  DATA TYPE
                        = ASCII_REAL
                        = 857
  START_BYTE
  BYTES
                        = "V0LT"
  UNIT
                        = 99999.9
  MISSING_CONSTANT
  FORMAT
                        = "F7.1"
 DESCRIPTION
                        = "V_HEATER HEATER VOLTAGE STANDARD DEVIATION,
                           IN THE PRIMARY ION SOURCE"
END_OBJECT
                        = COLUMN
                        = COLUMN
OBJECT.
  COLUMN_NUMBER
                        = 109
  NAME
                        = "C HEATER MIN"
 DATA_TYPE
                        = ASCII_REAL
```

```
START BYTE
                        = 865
  BYTES
                        = 7
  UNIT
                        = "AMPERE"
                        = 99999.9
 MISSING_CONSTANT
                        = "F7.1"
  FORMAT
  DESCRIPTION
                        = "C HEATER HEATER CURRENT MINIMUM,
                           IN THE PRIMARY ION SOURCE"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN NUMBER
                        = 110
                        = "C_HEATER_MEAN"
  NAME
                        = ASCII_REAL
  DATA TYPE
  START_BYTE
                        = 873
  BYTES
                          "AMPERE"
  UNIT
                        =
                        = 99999.9
 {\tt MISSING\_CONSTANT}
  FORMAT
                        = "F7.1"
 DESCRIPTION
                        = "C_HEATER HEATER CURRENT MEAN,
                           IN THE PRIMARY ION SOURCE"
END_OBJECT
                        = COLUMN
                        = COLUMN
OBJECT.
  COLUMN NUMBER
                        = 111
                          "C HEATER MAX"
  NAME
 DATA_TYPE
                        = ASCII_REAL
  START_BYTE
                        = 881
  BYTES
                        = 7
                        = "AMPERE"
  UNIT
  MISSING CONSTANT
                        = 99999.9
                        = "F7.1"
  FORMAT
                        = "C_HEATER HEATER CURRENT MAXIMUM,
 DESCRIPTION
                           IN THE PRIMARY ION SOURCE"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 112
                        = "C_HEATER_STD"
  NAME
  DATA_TYPE
                        = ASCII_REAL
  START_BYTE
                        = 889
  BYTES
                        = 7
                        = "AMPERE"
  UNIT
                        = 99999.9
 MISSING_CONSTANT
                        = "F7.1"
  FORMAT
                           "C HEATER HEATER CURRENT STANDARD DEVIATION,
  DESCRIPTION
                           IN THE PRIMARY ION SOURCE"
END_OBJECT
                        = COLUMN
COSIMA SPECTRUM TDC TIMING.FMT:
  OBJECT
                                 = COLUMN
```

```
COLUMN_NUMBER
                               = 1
                               = CHOPPER ON
  NAME
 DATA TYPE
                               = ASCII_REAL
  START BYTE
                               = 1
                               = 9
  BYTES
                               = "NANOSECOND"
 UNIT
                               = "F9.2"
 FORMAT
 DESCRIPTION
                               = "TIME TO DIGITAL UNIT CHOPPER ON TIME"
END OBJECT
                               = COLUMN
0BJECT
                               = COLUMN
  COLUMN NUMBER
                               = CHOPPER OFF
  NAME
  DATA_TYPE
                               = ASCII_REAL
  START_BYTE
                               = 11
                               = 9
  BYTES
                               = "NANOSECOND"
 UNIT
                               = "F9.2"
  FORMAT
 DESCRIPTION
                               = "TIME TO DIGITAL UNIT CHOPPER OFF TIME"
                               = COLUMN
END_OBJECT
OBJECT
                               = COLUMN
  COLUMN_NUMBER
                               = 3
  NAME
                               = BUNCHER_1_ON
 DATA_TYPE
                               = ASCII_REAL
```

```
START BYTE
                               = 21
  BYTES
                               = 9
  UNIT
                               = "NANOSECOND"
                               = "F9.2"
  FORMAT
  DESCRIPTION
                               = "TIME TO DIGITAL UNIT BUNCHER 1 ON TIME"
END OBJECT
                               = COLUMN
OBJECT
                               = COLUMN
  COLUMN_NUMBER
                               = 4
  NAME
                               = BUNCHER 2 ON
  DATA TYPE
                               = ASCII REAL
  START_BYTE
                               = 31
  BYTES
                               = 9
                               = "NANOSECOND"
  UNIT
                               = "F9.2"
  FORMAT
                               = "TIME TO DIGITAL UNIT BUNCHER 2 ON TIME"
  DESCRIPTION
                               = COLUMN
END OBJECT
OBJECT
                               = COLUMN
  COLUMN_NUMBER
  NAME
                               = BUNCHER 3 ON
  DATA_TYPE
                               = ASCII_REAL
  START_BYTE
                               = 41
  BYTES
                               = 9
                               = "NANOSECOND"
  UNTT
                               = "F9.2"
  FORMAT
  DESCRIPTION
                               = "TIME TO DIGITAL UNIT BUNCHER 3 ON TIME"
                               = COLUMN
END_OBJECT
OBJECT
                               = COLUMN
  COLUMN_NUMBER
                               = 6
                               = PIBS_OFF
  NAME
  DATA TYPE
                               = ASCII REAL
  START_BYTE
                               = 51
                               = 9
  BYTES
  UNIT
                               = "NANOSECOND"
                               = "F9.2"
  FORMAT
                               = "TIME TO DIGITAL UNIT PRIMARY ION BEAM
  DESCRIPTION
                                  SYSTEM OFF TIME"
END OBJECT
                               = COLUMN
0BJECT
                               = COLUMN
  COLUMN NUMBER
                               = 7
  NAME
                               = TOF OFF
  DATA_TYPE
                               = ASCII_REAL
  START_BYTE
                               = 61
  BYTES
                               = 9
                               = "NANOSECOND"
  UNTT
                               = "F9.2"
  FORMAT
                                 "TIME TO DIGITAL UNIT TIME OF FLIGHT UNIT
  DESCRIPTION
                                  OFF TIME"
END_OBJECT
                               = COLUMN
```

COSIMA SPECTRUM TDC CALIB.FMT:

```
= COLUMN
OBJECT
  COLUMN_NUMBER
                                = 1
  NAME
                                = TDC CALIBRATION OFFSET
  DATA TYPE
                                = ASCĪI INTEGER
  START_BYTE
                                = 1
  BYTES
                                = 11
                                = "SECOND"
  UNIT
                                = "I11"
  FORMAT
  DESCRIPTION
                                = "OFFSET IN SECONDS FROM THE START OF THE
                                   SPECTRUM MEASUREMENT"
END OBJECT
                                = COLUMN
OBJ<u>E</u>CT
                                = COLUMN
  COLUMN_NUMBER
                                = 2
  NAME
                                = TDC_DELAY_LINE
  DATA_TYPE
START_BYTE
                                = ASCII_INTEGER
                                = 13
                                = 3
= "I3"
  BYTES
  FORMAT
  DESCRIPTION
                                = "TIME TO DIGITAL UNIT DELAY LINE
                                   DAC CONTROL VALUE"
END_OBJECT
                                = COLUMN
0BJECT
                                = COLUMN
  COLUMN NUMBER
                                = 3
```

```
NAME
                               = TDC CALIBRATION MEAN
 DATA_TYPE
                               = ASCII_INTEGER
  START BYTE
                               = 17
 BYTES
                               = 5
                               = "I5"
 FORMAT
 DESCRIPTION
                               = "TIME TO DIGITAL UNIT CHANNEL
                                  CALIBRATION MEAN"
END OBJECT
                               = COLUMN
OBJECT
                               = COLUMN
  COLUMN NUMBER
 NAME
                               = TDC CALIBRATION STD
 DATA_TYPE
                               = ASCII_INTEGER
 START_BYTE
                               = 23
 BYTES
                               = 5
 FORMAT
                               = "I5"
                               = "TIME TO DIGITAL UNIT CHANNEL
 DESCRIPTION
                                  CALIBRATION STANTARD DEVIATION"
END_OBJECT
                               = COLUMN
0BJ<del>E</del>CT
                               = COLUMN
  COLUMN_NUMBER
                               = 5
                               = TDC_CHANNEL_DIFFERENCE
  NAME
 DATA TYPE
                               = ASCII_INTEGER
  START_BYTE
                               = 29
  BYTES
                               = 95
 ITEMS
                               = 16
  ITEM_BYTES
                               = 5
  ITEM_OFFSET
 FORMAT
                               = "16"
                               = "TIME TO DIGITAL UNIT CHANNEL
 DESCRIPTION
                                  DIFFERENCE FROM THE MEAN"
END OBJECT
                               = COLUMN
```

4.3.4 Scan data product

4.3.4.1 General description

With each scan step, the following elements are given:

- · total counts in the three time/mass ranges
- number of ion shots
- total counts
- substrate position
- time/mass range limits
- · varied parameters, step values

Detailed contents of the elements are described in the label example below.

4.3.4.2Label example

```
PDS_VERSION_ID
                                   = PDS3
                                   = "V1.1"
LABEL_REVISION_NOTE
/* FILE FORMAT */
RECORD_TYPE
RECORD_BYTES
                                   = FIXED_LENGTH
                                   = 153
FILE_RECORDS
                                   = 19
LABEL_RECORDS
                                   = 18
/* POINTER TO DATA OBJECTS */
^SCAN_TABLE
/* GENERAL DATA DESCRIPTION PARAMETERS */
FILE_NAME
                                  = "CS_2D8_20100508T104500_SCAN.TAB"
DATA_SET_ID
DATA_SET_NAME
                                   = "R0-CAL-COSIMA-3-V3.0"
                                   = "ROSETTA-ORBITER CAL COSIMA 3 V3.0"
                                   = "CS_2D8_20100508T104500_SCAN"
PRODUCT_ID
PRODUCT_CREATION_TIME
PRODUCT_TYPE
                                   = 201\overline{0} - 08 - 28T15:13:27
                                   = "REFDR"
                                   = "3"
PROCESSING_LEVEL_ID
MISSION ID
                                   = "ROSETTA"
                                   = "INTERNATIONAL ROSETTA MISSION"
MISSION_NAME
```

```
MISSION PHASE NAME
                                  = "CRUISE 5"
                                   = "R0"
INSTRUMENT_HOST_ID
INSTRUMENT_HOST_NAME INSTRUMENT_ID
                                  = "ROSETTA-ORBITER"
                                  = "COSIMA"
                                  = "COMETARY SECONDARY ION MASS ANALYZER"
INSTRUMENT_NAME
INSTRUMENT_TYPE
INSTRUMENT_MODE_ID
INSTRUMENT_MODE_DESC
                                  = "MASS SPECTROMETER"
                                  = "SPECTRUM"
                                  = "TIME OF FLIGHT MASS SPECTRUM MEASUREMENT"
                                   = "CALIBRATION"
TARGET NAME
TARGET TYPE
                                  = "CALIBRATION"
START_TIME
                                   = 2010-05-08T10:45:00
STOP_TIME
                                   = 2010-05-08T10:59:19
SPACECRAFT_CLOCK_START_COUNT
                                   = "1/0231936259.28265"
                                   = "1/0231937118.28261"
SPACECRAFT_CLOCK_STOP_COUNT
SC_SUN_POSITION_VECTOR
SC_TARGET_POSITION_VECTOR
SC_TARGET_VELOCITY_VECTOR
SPACECRAFT_ALTITUDE
                                   = "N/A"
                                   = "N/A"
                                   = "N/A"
                                   = "N/A"
                                   = "N/A"
SUB_SPACECRAFT_LATITUDE
                                   = "N/A"
SUB_SPACECRAFT_LONGITUDE
                                   = "FMI"
PRODUCER_ID
                                   = "JOHAN SILEN"
PRODUCER_FULL_NAME
                                   = "FINNISH METEOROLOGICAL INSTITUTE"
PRODUCER_INSTITUTION_NAME
DATA_QUALITY_ID
DATA_QUALITY_DESC
                                   = -1
                                   = "-1 = not checked"
                                   = "2D8"
= "Silver, blank"
ROSETTA:COSIMA_SUBSTRATE_ID
ROSETTA:COSIMA_SUBSTRATE_DESC
                                   = "NEGATIVE"
ROSETTA: COSIMA SPECTRUM POL
OBJECT
                                   = SCAN TABLE
                                   = SCAN DATA
  NAME
  INTERCHANGE_FORMAT
                                   = ASCII
                                   = 17
  COLUMNS
  ROW_BYTES
                                   = 153
  ^STRUCTURE
                                   = "COSIMA_SCAN_DATA.FMT"
                                   = "COSIMA SCAN DATA"
  DESCRIPTION
                                   = SCAN_TABLE
END OBJECT
END
COSIMA SCAN DATA.FMT
OBJECT
                          = COLUMN
  COLUMN_NUMBER
                          = 1
  NAME
                          = WINDOW 1 COUNT
  DATA TYPE
                         = ASCII_INTEGER
  START_BYTE
                          = 1
  BYTES
                          = 11
  {\tt MISSING\_CONSTANT}
                          = -9999999999
                          = "I11"
  FORMAT
  DESCRIPTION
                          = "COUNT OF THE EVENTS
                             INSIDE THE FIRST TIME(MASS) WINDOW"
END_OBJECT
                          = COLUMN
OBJECT
                          = COLUMN
  COLUMN_NUMBER
                          = 2
                          = WINDOW_2_COUNT
  NAME
  DATA TYPE
                          = ASCII INTEGER
  START_BYTE
                          = 13
  BYTES
                          = 11
  MISSING_CONSTANT
                          = -9999999999
                          = "I11"
  FORMAT
                          = "COUNT OF THE EVENTS
  DESCRIPTION
                             INSIDE THE SECOND TIME(MASS) WINDOW"
END_OBJECT
                          = COLUMN
OBJECT
                          = COLUMN
  COLUMN_NUMBER
                          = 3
  NAME
                          = WINDOW_3_COUNT
  DATA TYPE
                          = ASCII_INTEGER
  START_BYTE
                          = 25
  BYTES
                          = 11
```

MISSING CONSTANT

= -9999999999

```
= "I11"
  FORMAT
 DESCRIPTION
                        = "COUNT OF THE EVENTS
                           INSIDE THE THIRD TIME(MASS) WINDOW"
END OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
 COLUMN_NUMBER
                        = 4
  NAME
                       = SPECTRUM SHOTS
  DATA TYPE
                        = ASCII_INTEGER
  START_BYTE
                       = 37
  BYTES
                       = 11
  MISSING_CONSTANT
                       = -9999999999
                       = "I11"
  FORMAT
 DESCRIPTION
                        = "NUMBER OF INDIUM ION SHOTS USED"
END OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 5
                       = TOTAL_COUNT
  NAME
 DATA_TYPE
START_BYTE
                        = ASCII_INTEGER
                       = 49
  BYTES
                       = 11
  MISSING_CONSTANT
                       = -999999999
                        = "I11"
  FORMAT
                       = "TOTAL COUNT OF EVENTS DURING ACQUISITION"
 DESCRIPTION
                        = COLUMN
END_OBJECT
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 6
  NAME
                        = SUBSTRATE X
  DATA TYPE
                       = ASCII_INTEGER
  START_BYTE
                       = 61
  BYTES
                        = 5
                       = "MICROMETER"
  UNIT
 MISSING_CONSTANT
                        = -9999
  FORMAT
                        = "I5"
                        = "SUBSTRATE X-COORDINATE IN MICROMETERS,
 DESCRIPTION
                           ZERO IS AT LEFT"
END_OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                        = 7
                       = SUBSTRATE Y
  NAME
 DATA_TYPE
                        = ASCII_INTEGER
  START BYTE
                       = 67
  BYTES
                       = 5
                       = "MICROMETER"
  UNIT
  MISSING_CONSTANT
                        = -9999
                       = "I5"
  FORMAT
 DESCRIPTION
                        = "SUBSTRATE Y-COORDINATE IN MICROMETERS,
                           ZERO IS AT BOTTOM"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 8
                        = WINDOW_1_START
  NAME
 DATA_TYPE
                        = ASCII_INTEGER
  START BYTE
                       = 73
                        = 6
  BYTES
 MISSING_CONSTANT
                        = -1
                        = "16"
  FORMAT
  DESCRIPTION
                        = "START BIN FOR THE FIRST TIME(MASS) WINDOW"
END_OBJECT
                        = COLUMN
                        = COLUMN
OBJECT.
  COLUMN NUMBER
                        = 9
  NAME
                        = WINDOW_1_STOP
 DATA_TYPE
                        = ASCII_INTEGER
  START_BYTE
                        = 80
  BYTES
                        = 6
 MISSING_CONSTANT
                       = -1
= "I6"
  FORMAT
                       = "STOP BIN FOR THE FIRST TIME(MASS) WINDOW"
  DESCRIPTION
                        = COLUMN
END_OBJECT
```

```
OBJECT
                         = COLUMN
  COLUMN NUMBER
                         = 10
  NAME
                         = WINDOW_2_START
  DATA_TYPE
                         = ASCII_INTEGER
  START_BYTE
                         = 87
  BYTES
                         = 6
  MISSING_CONSTANT
                         = -1
                         = "16"
  FORMAT
                         = "START BIN FOR THE SECOND TIME(MASS) WINDOW"
  DESCRIPTION
                         = COLUMN
END OBJECT
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                         = 11
                         = WINDOW 2 STOP
  DATA TYPE
                         = ASCII_INTEGER
  START_BYTE
                         = 94
  BYTES
                         = 6
  {\tt MISSING\_CONSTANT}
                         = -1
                         = "16"
  FORMAT
                         = "STOP BIN FOR THE SECOND TIME(MASS) WINDOW"
  DESCRIPTION
                         = COLUMN
END_OBJECT
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                         = 12
                         = WINDOW_3_START
  NAME
  DATA_TYPE
                         = ASCII_INTEGER
  START_BYTE
                         = 101
  BYTES
                         = 6
  MISSING CONSTANT
                         = -1
                         = "I6"
  FORMAT
                         = "START BIN FOR THE THIRD TIME(MASS) WINDOW"
  DESCRIPTION
END_OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
  COLUMN NUMBER
                         = 13
                         = WINDOW 3 STOP
  NAME
  DATA_TYPE
                         = ASCII INTEGER
  START_BYTE
                         = 108
  BYTES
                         = 6
  {\tt MISSING\_CONSTANT}
                         = -1
= "I6"
  FORMAT
  DESCRIPTION
                         = "STOP BIN FOR THE THIRD TIME(MASS) WINDOW"
                         = COLUMN
END_OBJECT
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                         = 14
  NAME
                         = OUTER_PARAMETER
  DATA TYPE
                         = CHARACTER
                         = 116
  START_BYTE
  BYTES
                         = 10
                            "UNKNOWN"
  MISSING_CONSTANT
                         = "A10"
  FORMAT
  DESCRIPTION
                            "THE VARIED PARAMETER DURING THE SCAN.
                             THE POSSIBLE VALUES ARE
                                            TIME OF FLIGHT 1 VOLTAGE TIME OF FLIGHT 2 VOLTAGE
                             T0F1
                             T0F2
                                            TIME OF FLIGHT 3 VOLTAGE
                             T0F3
                                            POST ACCELERATION VOLTAGE
                             PΑ
                             DET
                                            DETECTOR VOLTAGE
                             DX TOF
                                            TOF X DEFLECTOR VOLTAGE
                                            TOF Y DEFLECTOR VOLTAGE
                             DY_T0F
                             L1
                                            PIBS LENS 1 VOLTAGE
                                            PIBS LENS 2 VOLTAGE
                             L2
                                            BEAM SWITCH 1 VOLTAGE
                             BS1
                             BS2
                                            BEAM SWITCH 2 VOLTAGE
                             CB
                                            CHOPPER BUNCHER VOLTAGE
                                            PIBS X DEFLECTOR VOLTAGE PIBS Y DEFLECTOR VOLTAGE
                             DX_PIBS
                             DY_PIBS
                             TM\overline{U}X
                                            TMU X AXIS MOVEMENT
                                            TMU Y AXIS MOVEMENT
                             TMU_Y
                             TMU CLEAN X
                                            TMU X AXIS MOVEMENT
                                            FOR CLEANING
                             TMU_CLEAN_Y
                                            TMU Y AXIS MOVEMENT
```

```
FOR CLEANING
                             NOP
                                            NO OPERATION"
END OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  COLUMN NUMBER
                            15
  NAME
                         = OUTER STEP
  DATA_TYPE
                         = ASCII_INTEGER
  START_BYTE
                         =
                           128
  BYTES
                         = 5
                         = -9999
  MISSING_CONSTANT
                         = "I5"
  FORMAT
  DESCRIPTION
                            "RAW VALUE OF THE PARAMETER STEP, SEE
                             MATCHING HK DATA FOR CALIBRATED VALUE"
                            COLUMN
END OBJECT
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                            16
                         = INNER PARAMETER
  NAME
  DATA_TYPE
                         = CHARACTER
  START_BYTE
                         = 135
  BYTES
                         = 10
                            "UNKNOWN"
  MISSING_CONSTANT
                         =
                            "A10"
  FORMAT
  DESCRIPTION
                            "THE VARIED PARAMETER DURING THE SCAN.
                             THE POSSIBLE VALUES ARE
                             T0F1
                                            TIME OF FLIGHT 1 VOLTAGE
                                            TIME OF FLIGHT 2 VOLTAGE
                             T0F2
                             T0F3
                                            TIME OF FLIGHT 3 VOLTAGE
                             PA
                                            POST ACCELERATION VOLTAGE
                             DET
                                            DETECTOR VOLTAGE
                             DX_T0F
                                            TOF X DEFLECTOR VOLTAGE TOF Y DEFLECTOR VOLTAGE
                             DY_TOF
                             L1
                                            PIBS LENS 1 VOLTAGE
                             L2
                                            PIBS LENS 2 VOLTAGE
                             BS1
                                            BEAM SWITCH 1 VOLTAGE
                             BS2
                                            BEAM SWITCH 2 VOLTAGE
                                            CHOPPER BUNCHER VOLTAGE
                             CB
                             DX PIBS
                                            PIBS X DEFLECTOR VOLTAGE
                             DY PIBS
                                            PIBS Y DEFLECTOR VOLTAGE
                             TMU_X
                                            TMU X AXIS MOVEMENT
                                            TMU Y AXIS MOVEMENT
                             TMU Y
                                            TMU X AXIS MOVEMENT
                             TMU_CLEAN_X
                                            FOR CLEANING
                             TMU CLEAN Y
                                            TMU Y AXIS MOVEMENT
                                            FOR CLEANING
                             NOP
                                            NO OPERATION"
END_OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
  COLUMN NUMBER
                           17
  NAME
                         = INNER STEP
  \mathsf{DATA} \_\mathsf{TYPE}
                         = ASCII_INTEGER
  START_BYTE
                         = 147
  BYTES
                         = 5
                         = -9999
= "I5"
  MISSING_CONSTANT
  FORMAT
  DESCRIPTION
                            "RAW VALUE OF THE PARAMETER STEP, SEE
                             MATCHING HK DATA FOR CALIBRATED VALUE"
END_OBJECT
                         = COLUMN
```

4.3.5 Scan housekeeping data product

4.3.5.1 General description

With each scan step, housekeeping data is associated. The housekeeping product has the following elements:

- Voltages, currents and temperatures means of the instrument during spectrum measurement
- TDC unit timing parameters
- TDC unit calibration results

4.3.5.2Label example

```
PDS VERSION ID
                                      = PDS3
LABEL REVISION NOTE
                                      = "V1.1"
/* FILE FORMAT */
RECORD TYPE
                                      = FIXED LENGTH
RECORD BYTES
                                      = 897
FILE_RECORDS
                                         10
LABEL_RECORDS
/* POINTER TO DATA OBJECT */
                                           5
^HK_TABLE
^TDC_TIMING_TABLE
^TDC_CALIBRATION_TABLE
                                           6
                                           8
/* GENERAL DATA DESCRIPTION PARAMETERS */
FILE NAME
                                     = "CS_2D8_20100508T104500_SCHK.TAB"
                                      = "RO-CAL-COSIMA-3-V3.0"
DATA_SET_ID
DATA SET NAME
                                      = "ROSETTA-ORBITER CAL COSIMA 3 V3.0"
PRODUCT ID
                                     = "CS_2D8_20100508T104500_SCHK"
PRODUCT_CREATION_TIME
                                      = 201\overline{0} - 08 - 28T15 : 13 : 27
PRODUCT_TYPE
PROCESSING_LEVEL_ID
                                      = "ANCDR"
                                      = "6"
                                      = "ROSETTA"
MISSION_ID
                                      = "INTERNATIONAL ROSETTA MISSION"
MISSION NAME
MISSION PHASE NAME
                                     = "CRUISE 5"
INSTRUMENT_HOST_ID
                                     = "R0"
INSTRUMENT_HOST_NAME INSTRUMENT_ID
                                     = "ROSETTA-ORBITER"
                                     = "COSIMA"
INSTRUMENT_NAME
INSTRUMENT_TYPE
INSTRUMENT_MODE_ID
                                     = "COMETARY SECONDARY ION MASS ANALYZER"
                                     = "MASS SPECTROMETER"
                                     = "SPECTRUM"
INSTRUMENT MODE DESC
                                     = "TIME OF FLIGHT MASS SPECTRUM MEASUREMENT"
                                     = "CALIBRATION"
TARGET_NAME
TARGET_TYPE
START_TIME
STOP_TIME
                                     = "CALIBRATION"
                                      = 2010-05-08T10:45:00
                                      = 2010-05-08T10:59:19
SPACECRAFT_CLOCK_START_COUNT
SPACECRAFT_CLOCK_STOP_COUNT
                                      = "1/0231936259.28265"
                                      = "1/0231937118.28261"
SC SUN POSĪTION VECTOR
                                      = "N/A"
SC_TARGET_POSITION_VECTOR
                                     = "N/A"
                                     = "N/A"
SC_TARGET_VELOCITY_VECTOR
SPACECRAFT_ALTITUDE
                                     = "N/A"
SUB_SPACECRAFT_LATITUDE
SUB_SPACECRAFT_LONGITUDE
                                     = "N/A"
                                     = "N/A"
                                     = "FMI"
PRODUCER ID
PRODUCER_FULL_NAME
                                     = "JOHAN SILEN"
PRODUCER_INSTITUTION_NAME
                                     = "FINNISH METEOROLOGICAL INSTITUTE"
DATA_QUALITY_ID DATA QUALITY DESC
                                     = -1
                                     = "-1 = not checked"
ROSETTA:COSIMA_SUBSTRATE_ID
ROSETTA:COSIMA_SUBSTRATE_DESC
                                     = "2D8"
= "Silver, blank"
ROSETTA: COSIMA SPECTRUM POL
                                      = "NEGATIVE"
OBJECT
                                      = HK_TABLE
                                      = HOUSEKEEPING
  NAME
  INTERCHANGE_FORMAT
                                      = ASCII
  ROWS
  COLUMNS
                                      = 112
  ROW BYTES
                                      = 897
  ^STRUCTURE
                                      = "COSIMA_SPECTRUM_HK.FMT"
  DESCRIPTION
                                        "COSIMA SPECTRUM HOUSEKEEPING INFORMATION,
                                         INCLUDING VOLTAGES, CURRENTS AND
                                         TEMPERATUES"
END OBJECT
                                      = HK TABLE
                                      = TDC TIMING TABLE
OBJECT
                                      = TDC TIMING
  NAME
  INTERCHANGE FORMAT
                                      = ASC\overline{I}I
  ROWS
                                      = 1
  COLUMNS
                                      = 7
  ROW_BYTES
                                      = 897
```

```
^STRUCTURE
                                 = "COSIMA_SPECTRUM_TDC_TIMING.FMT"
                                 = "TIME TO DIGITAL UNIT TIMING PARAMETERS"
  DESCRIPTION
END OBJECT
                                 = TDC TIMING TABLE
OBJECT
                                 = TDC_CALIBRATION_TABLE
                                 = TDC CALIBRATION
  INTERCHANGE FORMAT
                                 = ASC\overline{I}I
  ROWS
                                 = 3
  COLUMNS
                                 = 5
  ROW BYTES
                                 = 897
                                 = "COSIMA_SPECTRUM_TDC_CALIB.FMT"
  ^STRUCTURE
                                 = "TIME TO DIGITAL UNIT CALIBRATION RESULTS"
  DESCRIPTION
END_OBJECT
                                 = TDC_CALIBRATION_TABLE
END
```

4.3.6 Heating data product

4.3.6.1 General description

The substrate heating curve is given

Detailed contents of the elements are described in the label example below.

4.3.6.2Label example

```
PDS VERSION ID
                                     = PDS3
LABEL REVISION NOTE
                                     = "V1.1"
/* FILE FORMAT */
RECORD TYPE
                                     = FIXED LENGTH
RECORD_BYTES
                                     = 23
FILE_RECORDS
                                     = 137
LABEL_RECORDS
                                     = 125
/* POINTER TO DATA OBJECTS */
^HEATING_SETUP_TABLE
                                     = 126
^HEATING TABLE
                                     = 127
/* GENERAL DATA DESCRIPTION PARAMETERS */
FILE_NAME
                                     = "CS_2D8_20090930T051206_HEAT.TAB"
DATA_SET_ID
DATA_SET_NAME
                                     = "R0-CAL-COSIMA-3-V2.0"
                                     = "ROSETTA-ORBITER CAL COSIMA 3 V2.0"
PRODUCT ID
                                     = "CS_2D8_20090930T051206_HEAT"
PRODUCT_CREATION_TIME
PRODUCT_TYPE
                                     = 201\overline{0} - 07 - 18T09 : 23 : 10
                                     = "REFDR"
                                     = "3"
PROCESSING_LEVEL_ID
MISSION ID
                                     = "ROSETTA"
MISSION_NAME
                                    = "INTERNATIONAL ROSETTA MISSION"
                                    = "EARTH SWING-BY 3"
MISSION_PHASE_NAME
INSTRUMENT_HOST_ID
INSTRUMENT_HOST_NAME
                                     = "R0"
                                    = "ROSETTA-ORBITER"
                                    = "COSIMA"
INSTRUMENT_ID
INSTRUMENT_NAME INSTRUMENT_TYPE
                                    = "COMETARY SECONDARY ION MASS ANALYZER"
                                    = "MASS SPECTROMETER"
                                    = "CHEMISTRY"
INSTRUMENT_MODE_ID
INSTRUMENT_MODE_DESC
TARGET_NAME
                                    = "SUBSTRATE HEATING"
                                     = "CALIBRATION"
TARGET_TYPE
START_TIME
STOP_TIME
                                     = "CALIBRATION"
                                     = 2009-09-30T05:12:06
                                     = 2009-09-30T05:22:10
SPACECRAFT_CLOCK_START_COUNT
                                     = ""
SPACECRAFT_CLOCK_STOP_COUNT
SC_SUN_POSITION_VECTOR
                                     = "N/A"
                                     = "N/A"
SC_TARGET_POSITTON_VECTOR
SC_TARGET_VELOCITY_VECTOR
SPACECRAFT_ALTITUDE
                                     = "N/A"
                                     = "N/A"
                                     = "N/A"
SUB_SPACECRAFT_LATITUDE
SUB_SPACECRAFT_LONGITUDE
PRODUCER_ID
                                     = "N/A"
                                     = "FMI"
                                     = "JOHAN SILEN"
PRODUCER_FULL_NAME
PRODUCER_INSTITUTION_NAME
                                     = "FINNISH METEOROLOGICAL INSTITUTE"
DATA_QUALITY_ID
DATA_QUALITY_DESC
                                     = -1
                                     = "-1 = not checked"
ROSETTA:COSIMA_SUBSTRATE_ID
ROSETTA:COSIMA_SUBSTRATE_DESC
                                     = "2D8"
                                     = "Silver, blank"
```

```
OBJECT
                                = HEATING_SETUP_TABLE
  NAME
                                = HEATING_SETUP
  INTERCHANGE FORMAT
                                = ASCII
                                = 1
  ROWS
  COLUMNS
                                = 1
  ROW BYTES
                                = 23
                                = "COSIMA_HEATING_SETUP.FMT"
  ^STRUCTURE
                                = "COSIMA SUBSTRATE HEATING SETUP"
  DESCRIPTION
                                = HEATING_SETUP_TABLE
END OBJECT
OBJECT
                                = HEATING_TABLE
                                = HEATING_POINTS
  NAME
  INTERCHANGE_FORMAT
                                = ASCII
  ROWS
                                = 12
  COLUMNS
                                = 3
                                = 23
  ROW BYTES
                                = "COSIMA_HEATING_DATA.FMT"
  ^STRUCTURE
                                = "COSIMA SUBSTRATE HEATING DATA POINTS"
  DESCRIPTION
                                = HEATING_TABLE
END_OBJECT
END
COSIMA_HEATING_SETUP.FMT
                        = COLUMN
  COLUMN_NUMBER
                        = 1
                       = HEAT_TIME
  NAME
  DATA_TYPE
                       = ASCII_INTEGER
  START_BYTE
                       = 1
  BYTES
                       = 9
  MISSING CONSTANT
                       = -999999999
                       = "SECOND"
  UNIT
                       = "19"
  FORMAT
                       = "HEATING TIME IN SECONDS"
  DESCRIPTION
END_OBJECT
                       = COLUMN
OBJECT
                       = COLUMN
  COLUMN_NUMBER
                       = 2
                       = HEAT_LEVEL
  NAME
  DATA_TYPE
                       = ASCII_INTEGER
  START_BYTE
                       = 13
                       = 1
  BYTES
 MISSING_CONSTANT
                        = 9
                        = "I1"
  FORMAT
 DESCRIPTION
                        = "HEAT_SETUP
                           0 =
                                66 C
                               77 C
                           1 =
                           2 = 86 C
                           3 = 94 \text{ C}
                           4 = 104 C
                           5 = 113 C
                           6 = 122 C
                           7 = 132 C"
END_OBJECT
                        = COLUMN
COSIMA_HEATING_DATA.FMT
OBJECT
            = COLUMN
COLUMN NUMBER = 1
             = HEAT_TIME
NAME
DATA TYPE
              = ASCII_INTEGER
START_BYTE
                = 1
BYTES
             = 9
             = "SECOND"
UNIT
FORMAT
              = "I9"
DESCRIPTION
                = "HEATING TIME STEP IN SECONDS"
END_OBJECT
                = COLUMN
OBJECT
              = COLUMN
COLUMN NUMBER
                  = 2
             = TMU_2_TEMPERATURE
NAME
              = ASCII_REAL
DATA TYPE
START\_BYTE
                = 11
BYTES
             = 5
MISSING_CONSTANT = 999.9
```

```
UNIT = "DEGREE CELSIUS"
```

FORMAT = "F5.1"

DESCRIPTION = "T_TMU2 TARGET MANIPULATOR TEMPERATURE

AT THE CHEMISTRY(HEATING) STATION"

END_OBJECT = COLUMN

OBJECT = COLUMN COLUMN_NUMBER = 3

NAME = TMU_1_TEMPERATURE DATA_TYPE = ASCII_REAL

START_BYTE = 17
BYTES = 5
MISSING_CONSTANT = 999.9
UNIT = "DEGREE CELSIUS"
FORMAT = "F5.1"

DESCRIPTION = "T TMU1 TARGET MANIPULATOR TEMPERATURE

AT THE SUBSTRATE STORAGE"

END_OBJECT = COLUMN

4.3.7 Cleaning data product

4.3.7.1 General description

The cleaning product contains the following elements:

- time used
- · emitter tip current housekeeping data

Detailed contents of the elements are described in the label example below.

Label example

```
PDS VERSION ID
                                    = PDS3
LABEL_REVISTON_NOTE
                                    = "V1.1"
/* FILE FORMAT */
RECORD_TYPE
                                    = FIXED LENGTH
RECORD BYTES
                                    = 45
FILE_RECORDS
                                    = 131185
LABEL_RECORDS
                                    = 112
/* POINTER TO DATA OBJECTS */
^CLEANING_TABLE
                                    = 113
/* GENERAL DATA DESCRIPTION PARAMETERS */
                                   = "CS_2D8_20070927T182348_CLEA.TAB"
FILE NAME
                                    = "RO-CAL-COSIMA-3-V2.0"
DATA_SET_ID
DATA_SET_NAME
PRODUCT_ID
                                    = "ROSETTA-ORBITER CAL COSIMA 3 V2.0"
                                    = "CS_2D8_20070927T182348_CLEA.TAB"
PRODUCT_CREATION_TIME
PRODUCT_TYPE
PROCESSING_LEVEL_ID
                                    = 2008-11-12T09:15:39
                                    = "REFDR"
                                    = "3"
                                    = "ROSETTA"
MISSION_ID
MISSION NAME
                                    = "INTERNATIONAL ROSETTA MISSION"
                                   = "EARTH SWING-BY 2"
MISSION_PHASE_NAME
                                    = "R0"
INSTRUMENT_HOST_ID
INSTRUMENT_HOST_NAME INSTRUMENT ID
                                   = "ROSETTA-ORBITER"
                                   = "COSIMA"
                                   = "COMETARY SECONDARY ION MASS ANALYZER"
INSTRUMENT_NAME
INSTRUMENT_TYPE
INSTRUMENT_MODE_ID
                                   = "MASS SPECTROMETER"
                                   = "CLEANING"
                                   = "SUBSTRATE CLEANING WITH ION BEAM"
INSTRUMENT_MODE_DESC
TARGET_NAME
TARGET_TYPE
START_TIME
STOP_TIME
                                    = "CALIBRATION"
                                    = "CALIBRATION"
                                    = 2007-09-27T18:23:48
                                    = 2007 - 09 - 27T18 : 33 : 53
SPACECRAFT_CLOCK_START_COUNT
                                    = "1/0149538196.41251"
                                   = "1/0149538801.41245"
SPACECRAFT_CLOCK_STOP_COUNT
SC_SUN_POSITION_VECTOR
SC_TARGET_POSITION_VECTOR
                                    = "N/A"
                                    = "N/A"
                                    = "N/A"
SC_TARGET_VELOCITY_VECTOR
```

```
SPACECRAFT ALTITUDE
                                  = "N/A"
                                  = "N/A"
SUB_SPACECRAFT_LATITUDE
SUB_SPACECRAFT_LONGITUDE
                                  = "N/A"
                                  = "FMI"
PRODUCER ID
                                  = "JOHAN SILEN"
PRODUCER_FULL_NAME
PRODUCER_INSTITUTION_NAME
                                  = "FINNISH METEOROLOGICAL INSTITUTE"
DATA_QUALITY_ID
DATA_QUALITY_DESC
                                  = -1
                                  = "-1 = not checked"
                                  = "2D8"
ROSETTA: COSIMA SUBSTRATE ID
ROSETTA:COSIMA_SUBSTRATE_DESC
ROSETTA:COSIMA_SUBSTRATE_X
                                  = "Silver, blank"
                                  = 5000
ROSETTA: COSIMA_SUBSTRATE_Y
                                  = 5000
                                  = CLEANING_TABLE
OBJECT
                                  = CLEANING
  INTERCHANGE FORMAT
                                  = ASCII
                                  = 1
  ROWS
  COLUMNS
                                  = 5
  ROW BYTES
                                  = 45
                                  = "COSIMA_CLEANING.FMT"
= "COSIMA_SUBSTRATE_CLEANING"
  ^STRUCTURE
  DESCRIPTION
END_OBJECT
                                  = CLEANING_TABLE
END
COSIMA_CLEANING.FMT
                         = COLUMN
OBJECT
  COLUMN_NUMBER
                         = 1
                         = CLEANING TIME
  NAME
  DATA TYPE
                         = ASCII_INTEGER
  START_BYTE
                         = 1
  BYTES
                         = 11
  MISSING_CONSTANT
                         = 9999999999
                         = "SECOND"
  UNTT
                         = "I11"
  FORMAT
                         = "SUBSTRATE CLEANIG TIME WITH INDIUM BEAM"
  DESCRIPTION
                         = COLUMN
END OBJECT
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                         = 2
                         = "C TIP MIN"
  NAME
  DATA TYPE
                         = ASCII REAL
  START_BYTE
                         = 13
                         = 7
  BYTES
                         = "MICROAMPERE"
  UNIT
  {\tt MISSING\_CONSTANT}
                         = 99999.9
                         = "F7.1"
  FORMAT
  DESCRIPTION
                         = "C TIP TIP CURRENT MINIMUM,
                             IN THE PRIMARY ION SOURCE'
END OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                         = 3
  NAME
                         = "C TIP MEAN"
  DATA_TYPE
START_BYTE
                         = ASCII_REAL
                         = 21
  BYTES
  UNIT
                         = "MICROAMPERE"
  MISSING_CONSTANT
                         = 99999.9
  FORMAT
                         = "F7.1"
  DESCRIPTION
                         = "C_TIP TIP CURRENT MEAN,
                             IN THE PRIMARY ION SOURCE"
END OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
  COLUMN_NUMBER
                         = 4
                         = "C_TIP_MAX"
  NAME
  DATA_TYPE
                         = ASCII_REAL
  START BYTE
                         = 29
  BYTES
                         = 7
                         = "MICROAMPERE"
  UNIT
                         = 99999.9
  MISSING_CONSTANT
                         = "F7.1"
  FORMAT
                         = "C_TIP TIP CURRENT MAXIMUM,
  DESCRIPTION
```

```
IN THE PRIMARY ION SOURCE"
END OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
 COLUMN_NUMBER
                         = 5
                         = "C TIP STD"
 NAME
 DATA TYPE
                        = ASCII_REAL
 START_BYTE
                        = 37
 BYTES
                        = "MICROAMPERE"
 UNIT
 {\tt MISSING\_CONSTANT}
                        = 99999.9
 FORMAT
                         = "F7.1"
                           "C TIP TIP VOLTAGE STANDARD DEVIATION,
 DESCRIPTION
                            IN THE PRIMARY ION SOURCE"
END OBJECT
                         = COLUMN
```

4.3.8 Cleaning housekeeping data product

4.3.8.1 General description

With each cleaning operationhousekeeping data is associated. The housekeeping product has the following elements:

Voltages, currents and temperatures of the instrument during spectrum measurement
 Detailed contents of the elements are described in the label example below.

4.3.8.2Label example

```
PDS VERSION ID
                                    = PDS3
LABEL_REVISION_NOTE
                                    = "V1.1"
/* FILE FORMAT */
RECORD_TYPE
RECORD_BYTES
                                    = FIXED LENGTH
                                    = 897
FILE RECORDS
                                    = 11
LABEL RECORDS
                                    = 5
/* POINTER TO DATA OBJECT */
^HK_TABLE
/* GENERAL DATA DESCRIPTION PARAMETERS */
FILE_NAME
                                  = "CS 2D8 20070927T182348 CLHK.TAB"
DATA_SET_ID
DATA_SET_NAME
                                    = "RO-CAL-COSIMA-3-V2.0"
                                   = "ROSETTA-ORBITER CAL COSIMA 3 V2.0"
                                   = "CS_2D8_20070927T182348_CLHK"
PRODUCT_ID
PRODUCT_CREATION_TIME
PRODUCT_TYPE
                                   = 2008 - 11 - 12T09 : 15 : 38
                                   = "ANCDR"
                                   = "6"
PROCESSING LEVEL ID
MISSION_ID
                                   = "ROSETTA"
                                   = "INTERNATIONAL ROSETTA MISSION"
MISSION NAME
                                  = "EARTH SWING-BY 2"
MISSION_PHASE_NAME
INSTRUMENT_HOST_ID INSTRUMENT_HOST_NAME
                                   = "R0"
                                   = "ROSETTA-ORBITER"
INSTRUMENT ID
                                  = "COSIMA"
INSTRUMENT_NAME
INSTRUMENT_TYPE
                                   = "COMETARY SECONDARY ION MASS ANALYZER"
                                  = "MASS SPECTROMETER"
INSTRUMENT MODE ID
                                  = "CLEANING"
INSTRUMENT_MODE_DESC
                                   = "SUBSTRATE CLEANING WITH ION BEAM"
                                   = "CALIBRATION"
TARGET_NAME
TARGET_TYPE
START_TIME
STOP_TIME
                                   = "CALIBRATION"
                                   = 2007-09-27T18:23:48
                                   = 2007-09-27T18:33:53
SPACECRAFT_CLOCK_START_COUNT
                                   = "1/0149538196.41251"
SPACECRAFT_CLOCK_STOP_COUNT
SC_SUN_POSITION_VECTOR
                                   = "1/0149538801.41245"
                                   = "N/A"
SC_TARGET_POSITION_VECTOR
                                   = "N/A"
SC_TARGET_VELOCITY_VECTOR
SPACECRAFT_ALTITUDE
                                   = "N/A"
                                   = "N/A"
                                   = "N/A"
SUB SPACECRAFT LATITUDE
SUB_SPACECRAFT_LONGITUDE
                                   = "N/A"
                                   = "FMI"
PRODUCER ID
                                   = "JOHAN SILEN"
PRODUCER_FULL_NAME
PRODUCER_INSTITUTION_NAME
                                   = "FINNISH METEOROLOGICAL INSTITUTE"
                                    = -1
DATA_QUALITY_ID
```

```
DATA_QUALITY DESC
                                     = "-1 = not checked"
ROSETTA:COSIMA_SUBSTRATE_ID
ROSETTA:COSIMA_SUBSTRATE_DESC
ROSETTA:COSIMA_SUBSTRATE_X
                                     = "2D8"
                                     = "Silver, blank"
                                     = 5000
ROSETTA: COSIMA_SUBSTRATE_Y
                                     = 5000
OBJECT
                                     = HK TABLE
                                     = HOUSEKEEPING
  NAME
  INTERCHANGE FORMAT
                                     = ASCII
  ROWS
                                     = 1
  COLUMNS
                                     = 112
  ROW_BYTES
                                     = 897
  ^STRUCTURE
                                     = "COSIMA_SPECTRUM_HK.FMT"
  DESCRIPTION
                                     = "COSIMA SPECTRUM HOUSEKEEPING INFORMATION,
                                         INCLUDING VOLTAGES, CURRENTS AND
                                         TEMPERATUES"
END OBJECT
                                     = HK TABLE
```

4.3.9 COSISCOPE image product

4.3.9.1 General description

COSISCOPE image contains an image of target substrate in FITS format. P or M in the end of the product ID corresponds to the led illumination from Plus side (right) or Minus side (left).

4.3.9.2 Label example

```
PDS VERSION ID
                                    = PDS3
LABEL_REVISION_NOTE
                                    = "V1.1"
/* FILE FORMAT */
RECORD_TYPE
                                    = FIXED_LENGTH
RECORD BYTES
                                    = 2880
FILE RECORDS
                                    = 730
/* POINTER TO DATA OBJECTS */
^COSISCOPE_FITS_HEADER
                                    = ("CS 2D8 20080722T171038 IM M.LBL",1<BYTES>)
                                = ("CS_2D8_20080722T171038_IM_M.LBL",2881<BYTES>)
^COSISCOPE FITS IMAGE
/* GENERAL DATA DESCRIPTION PARAMETERS */
FILE_NAME
                                    = "CS_2D8_20080722T171038_IM_M.LBL"
                                    = "RO-CAL-COSIMA-3-V2.0"
DATA_SET_ID
DATA_SET_NAME
                                    = "ROSETTA-ORBITER CAL COSIMA 3 V2.0"
PRODUCT ID
                                    = "CS_2D8_20080722T171038_IM_M"
PRODUCT_CREATION_TIME
PRODUCT_TYPE
                                    = 201\overline{0} - 07 - 18T09:22:20
                                    = "REFDR"
                                    = "3"
PROCESSING_LEVEL_ID
                                    = "ROSETTA"
MISSION_ID
                                    = "INTERNATIONAL ROSETTA MISSION"
MISSION_NAME
MISSION PHASE NAME
                                   = "STEINS FLY-BY"
                                   = "R0"
INSTRUMENT_HOST_ID
INSTRUMENT_HOST_NAME
INSTRUMENT_ID
                                   = "ROSETTA-ORBITER"
                                   = "COSIMA"
INSTRUMENT_NAME
INSTRUMENT_TYPE
INSTRUMENT_MODE_ID
                                   = "COMETARY SECONDARY ION MASS ANALYZER"
                                   = "MASS SPECTROMETER"
                                   = "IMAGE"
INSTRUMENT_MODE_DESC
                                   = "COSISCOPE IMAGING"
                                    = "CALIBRATION"
TARGET_NAME
TARGET TYPE
                                    = "CALIBRATION"
START_TIME
STOP_TIME
                                    = 2008-07-22T17:10:38
                                    = 2008-07-22T17:14:16
SPACECRAFT_CLOCK_START_COUNT
SPACECRAFT_CLOCK_STOP_COUNT
                                    = ""
                                    = "N/A"
SC_SUN_POSITION_VECTOR
SC_TARGET_POSITION_VECTOR
SC_TARGET_VELOCITY_VECTOR
SPACECRAFT_ALTITUDE
                                    = "N/A"
                                    = "N/A"
                                    = "N/A"
SUB_SPACECRAFT LATITUDE
                                   = "N/A"
SUB_SPACECRAFT_LONGITUDE
                                   = "N/A"
                                   = "FMI"
PRODUCER_ID
                                   = "JOHAN SILEN"
PRODUCER FULL NAME
PRODUCER_INSTITUTION_NAME
                                   = "FINNISH METEOROLOGICAL INSTITUTE"
DATA_QUALITY_ID
                                   = -1
DATA_QUALITY_DESC
                                    = "-1 = not checked"
```

```
ROSETTA: COSIMA SUBSTRATE ID
                                 = "2D8"
ROSETTA:COSIMA SUBSTRATE DESC = "Silver, blank"
OBJECT
                                 = COSISCOPE FITS HEADER
  BYTES
                                 = 2880
  HEADER TYPE
                                 = FITS
  INTERCHANGE_FORMAT
                                 = BINARY
 RECORDS
                                 = 1
  DESCRIPTION
                                 = "COSISCOPE FITS IMAGE HEADER"
END OBJECT
                                 = COSISCOPE FITS HEADER
OBJECT
                                 = COSISCOPE_FITS_IMAGE
  LINES
                                 = 1024
  LINE_SAMPLES
                                 = 1024
 SAMPLE_TYPE
SAMPLE_BITS
                                = MSB INTEGER
                                = 16
  AXIS_ORDER_TYPE
                                = "FIRST INDEX FASTEST"
                                 = "UP"
  LINE_DISPLAY_DIRECTION
  SAMPLE DISPLAY DIRECTION
                                = "RIGHT"
 MISSING_CONSTANT
                                = -1
                                 = "COSISCOPE FITS IMAGE OF THE SUBSTRATE"
  DESCRIPTION
END OBJECT
                                 = COSISCOPE_FITS_IMAGE
END
```

4.3.10 COSISCOPE dust grain list product

4.3.10.1General description

COSISCOPE dust grain list can be associated with a Cosiscope image product, or it can be selfstanding. Dust grain list product contains a list of dust grains (also called features) found on a target substrate.

4.3.10.2Label template

```
= PDS3
PDS VERSION ID
LABEL_REVISION_NOTE
                                    = "V1.0"
/* FILE FORMAT */
RECORD_TYPE
                                    = FIXED_LENGTH
RECORD BYTES
                                    = 37
FILE_RECORDS
                                    = 6542
LABEL_RECORDS
                                     = 78
/* POINTER TO DATA OBJECT */
^FEATURE_TABLE
                                    = 79
/* GENERAL DATA DESCRIPTION PARAMETERS */
FILE_NAME
                                    = "CS_2D8_20070927T175457_GR__.TAB"
                                    = "RO-CAL-COSIMA-3-V2.0"
DATA_SET_ID
DATA_SET_NAME
                                    = "ROSETTA-ORBITER CAL COSIMA 3 V2.0"
PRODUCT_ID
PRODUCT_CREATION_TIME
                                    = "CS_2D8_20070927T175457_GR_
                                    = 2008-11-12T09:15:37
PRODUCT TYPE
                                    = "REFDR"
                                    = "3"
PROCESSING_LEVEL_ID
                                    = "ROSETTA"
MISSION ID
MISSION NAME
                                   = "INTERNATIONAL ROSETTA MISSION"
MISSION PHASE NAME
                                   = "EARTH SWING-BY 2"
                                    = "R0"
INSTRUMENT_HOST_ID
INSTRUMENT_HOST_NAME
                                   = "ROSETTA-ORBITER"
INSTRUMENT_ID
INSTRUMENT_NAME
                                    = "COSIMA"
                                    = "COMETARY SECONDARY ION MASS ANALYZER"
INSTRUMENT_TYPE
INSTRUMENT_MODE_ID
INSTRUMENT_MODE_DESC
                                   = "MASS SPECTROMETER"
                                   = "IMAGE"
                                    = "COSISCOPE IMAGING"
TARGET NAME
                                    = "CALIBRATION"
TARGET_TYPE
START_TIME
STOP_TIME
                                    = "CALIBRATION"
                                    = 2007-09-27T17:54:57
                                    = 2007-09-27T17:55:20
SPACECRAFT_CLOCK_START_COUNT
SPACECRAFT_CLOCK_STOP_COUNT
                                    = "1/0149536465.41269"
                                   = "1/0149536488.41269"
                                   = "N/A"
SC_SUN_POSTTION_VECTOR
SC_TARGET_POSITION_VECTOR
SC_TARGET_VELOCITY_VECTOR
                                    = "N/A"
                                    = "N/A"
```

```
SPACECRAFT ALTITUDE
                                 = "N/A"
                                 = "N/A"
SUB_SPACECRAFT_LATITUDE
                                 = "N/A"
SUB_SPACECRAFT_LONGITUDE
PRODUCER ID
                                 = "FMI"
                                 = "JOHAN SILEN"
PRODUCER_FULL_NAME
PRODUCER_INSTITUTION_NAME
                                 = "FINNISH METEOROLOGICAL INSTITUTE"
DATA_QUALITY_ID
DATA_QUALITY_DESC
                                 = -1
                                 = "-1 = not checked"
                                 = "2D8"
ROSETTA: COSIMA SUBSTRATE ID
                                 = "Silver, blank"
ROSETTA: COSIMA SUBSTRATE DESC
OBJECT
                                 = FEATURE_TABLE
  NAME
                                 = FEATURES
  INTERCHANGE_FORMAT
                                 = ASCII
  ROWS
                                 = 6464
  COLUMNS
                                 = 6
  ROW BYTES
                                 = 37
  ^STRUCTURE
                                  = "COSISCOPE_GRAINS.FMT"
  DESCRIPTION
                                 = "COSISCOPE GENERATED LIST OF PROMINENT
                                    FEATURES IN THE SUBSTRATE IMAGE. THE
                                    SUBSTRATE HAS AREA OF 10000X10000
                                    MICROMETERS."
END_OBJECT
                                 = FEATURE_TABLE
END
```

COSISCOPE GRAINS.FMT:

```
= COLUMN
OBJECT
  COLUMN_NUMBER
                                = 1
  NAME
                                = X LEFT
  DATA_TYPE
START_BYTE
                                = ASCII_INTEGER
                                = 1
  BYTES
  UNIT
                                = "MICROMETER"
  FORMAT
                                = 16
  DESCRIPTION
                                = "FEATURE LOWER LEFT X-COORDINATE"
END_OBJECT
                                = COLUMN
OBJECT
                                = COLUMN
  COLUMN NUMBER
                                = Y BOTTOM
  NAME
  DATA_TYPE
                                = ASCII_INTEGER
  START_BYTE
  BYTES
                                = 6
                                = "MICROMETER"
  UNIT
  FORMAT
                                = 16
  DESCRIPTION
                                = "FEATURE LOWER LEFT Y-COORDINATE"
END OBJECT
                                = COLUMN
OBJ<u>E</u>CT
                                = COLUMN
  COLUMN_NUMBER
                                = 3
                                = X_RIGHT
  NAME
  DATA TYPE
                                = ASCII_INTEGER
  START_BYTE
                                = 15
  BYTES
                                = 6
  UNIT
                                = "MICROMETER"
  FORMAT
                                = 16
                                = "FEATURE UPPER RIGHT X-COORDINATE"
  DESCRIPTION
END OBJECT
                                = COLUMN
OBJECT
                                = COLUMN
  COLUMN NUMBER
                                = 4
  NAME
                                = Y TOP
  DATA_TYPE
START_BYTE
                                = ASCII INTEGER
                                = 22
  BYTES
  UNIT
                                = "MICROMETER"
  FORMAT
                                = 16
  DESCRIPTION
                                = "FEATURE UPPER RIGHT Y-COORDINATE"
END_OBJECT
                                = COLUMN
0BJECT
                                = COLUMN
  COLUMN_NUMBER
                                = 5
  NAME
                                = QUALITY PX
  DATA_TYPE
                                = ASCII_INTEGER
  START BYTE
                                = 29
                                = 3
  BYTES
```

```
FORMAT
                              = I3
 MISSING_CONSTANT
                              = 0
 DESCRIPTION
                              = "FEATURE QUALITY FROM +X-SIDE LED
                                 ILLUMINATION. THE QUALITY FROM 0 TO 255
                                 IS MAINLY RELATED TO THE CONTRAST FROM
                                 THE BACKGROUND"
                              = COLUMN
END OBJECT
OBJECT
                              = COLUMN
  COLUMN NUMBER
  NAME
                              = OUALITY MX
  DATA_TYPE
                              = ASCII INTEGER
  START_BYTE
                              = 33
  BYTES
                              = 3
 FORMAT
                              = I3
 MISSING CONSTANT
 DESCRIPTION
                              = "FEATURE OUALITY FROM -X-SIDE LED
                                 ILLUMINATION. THE QUALITY FROM 0 TO 255
                                 IS MAINLY RELATED TO THE CONTRAST FROM
                                 THE BACKGROUND"
END_OBJECT
                              = COLUMN
```

4.3.11 COSISCOPE housekeeping product

4.3.11.1General information

With each Cosicope grain list, housekeeping data is associated. If the grain list has a corresponding Cosicope image, the housekeeping data applies also to that image. The Cosicope housekeeping product has the following elements:

- Cosiscope temperatures
- Substrate positioning information
- Imaging information

Detailed description of the Cosiscope housekeeping product is given in the label example.

4.3.11.2Label example

```
PDS VERSION ID
                                    = PDS3
LABEL REVISION NOTE
                                    = "V1.0"
RELEASE ID
                                    = 0001
REVISION_ID
                                    = 0000
/* FILE FORMAT */
RECORD_TYPE
                                    = FIXED_LENGTH
RECORD BYTES
                                    = 334
FILE_RECORDS
LABEL RECORDS
                                    = 10
                                       9
/* POINTER TO DATA OBJECT */
^COSISCOPE_HK_TABLE
                                    = 10
/* GENERAL DATA DESCRIPTION PARAMETERS */
FILE_NAME
DATA_SET_ID
                                   = "CS_2D8_20070927T175457_G_HK.TAB"
                                    = "RO-CAL-COSIMA-3-V2.0"
DATA SET NAME
                                    = "ROSETTA-ORBITER CAL COSIMA 3 V2.0"
PRODUCT_ID
PRODUCT_CREATION_TIME
                                    = "CS_2D8_20070927T175457_G_HK"
                                    = 2008 - 11 - 12T09:15:37
PRODUCT_TYPE
                                    = "ANCDR"
                                   = "6"
PROCESSING_LEVEL_ID
                                   = "ROSETTA"
MISSION_ID
                                   = "INTERNATIONAL ROSETTA MISSION"
MISSION NAME
                                   = "EARTH SWING-BY 2"
MISSION PHASE NAME
                                   = "R0"
INSTRUMENT_HOST_ID
                                   = "ROSETTA-ORBITER"
INSTRUMENT_HOST_NAME
INSTRUMENT_ID
INSTRUMENT_NAME
                                   = "COSIMA"
                                   = "COMETARY SECONDARY ION MASS ANALYZER"
                                   = "MASS SPECTROMETER"
INSTRUMENT TYPE
INSTRUMENT_MODE_ID
INSTRUMENT_MODE_DESC
                                   = "IMAGE"
                                   = "COSISCOPE IMAGING"
                                   = "CALIBRATION"
TARGET_NAME
TARGET_TYPE
START_TIME
STOP_TIME
                                   = "CALIBRATION"
                                   = 2007-09-27T17:54:57
                                    = 2007 - 09 - 27T17 : 55 : 20
```

```
= "1/0149536465.41269"
SPACECRAFT_CLOCK_START_COUNT
                                 = "1/0149536488.41269"
SPACECRAFT_CLOCK_STOP_COUNT
SC_SUN_POSITION_VECTOR
SC_TARGET_POSITION_VECTOR
                                 = "N/A"
                                = "N/A"
SC_TARGET_POSITION_VECTOR = "N/A"

SC_TARGET_VELOCITY_VECTOR = "N/A"

SCACECCRAFT_ALTITUDE = "N/A"
SPACECRAFT ALTITUDE
                                 = "N/A"
SUB_SPACECRAFT_LATITUDE
                                 = "N/A"
                                = "N/A"
SUB_SPACECRAFT_LONGITUDE
                                 = "FMI"
PRODUCER ID
                                = "JOHAN SILEN"
PRODUCER FULL NAME
PRODUCER_INSTITUTION_NAME
                                = "FINNISH METEOROLOGICAL INSTITUTE"
DATA_QUALITY_ID
DATA_QUALITY_DESC
                                 = -1
                                = "-1 = not checked"
ROSETTA: COSIMA_SUBSTRATE_ID
                                 = "2D8"
ROSETTA:COSIMA SUBSTRATE DESC = "Silver, blank"
                                 = COSISCOPE_HK_TABLE
OBJECT
  NAME
                                  = COSISCOPE_HOUSEKEEPING
  INTERCHANGE_FORMAT
                                 = ASCII
  ROWS
                                 = 1
  COLUMNS
                                 = 55
  ROW BYTES
                                 = 334
                                 = "COSISCOPE_HK.FMT"
  ^STRUCTURE
                                 = "COSISCOPE HOUSEKEEPING INFORMATION"
  DESCRIPTION
END_OBJECT
                                 = COSISCOPE_HK_TABLE
END
COSISCOPE HK.FMT:
OBJECT.
                         = COLUMN
  COLUMN_NUMBER
                        = 1
  NAME
                         = "T1
                               SCOPE MIN"
  DATA TYPE
                        = ASCĪI_REAL
  START_BYTE
                        = 1
  BYTES
                        = 7
                        = "DEGREE KELVIN"
  UNIT
 MISSING_CONSTANT = 999.9
FORMAT = "F7.1"
                        = "F7.1"
  DESCRIPTION
                        = "T1 SCOPE COSISCOPE TEMPERATURE MINIMUM AT CAMERA"
                        = COL\overline{U}MN
END OBJECT
OBJECT
                        = COLUMN
                  = 2
= "T
= AS
  COLUMN_NUMBER
  NAME
                        = "T1 SCOPE MEAN"
  DATA TYPE
                        = ASCĪI_REAL
  START_BYTE
                       = 9
  BYTES
                        = 7
                        = "DEGREE KELVIN"
  UNIT
 MISSING_CONSTANT = 999.9
                        = "F7.1"
  FORMAT
  DESCRIPTION
                        = "T1_SCOPE COSISCOPE TEMPERATURE MEAN AT CAMERA"
                         = COL\overline{U}MN
END_OBJECT
OBJECT
                        = COLUMN
  COLUMN NUMBER
                        = 3
  NAME
                        = "T1_SCOPE_MAX"
  DATA TYPE
                        = ASCĪI_REAL
  START_BYTE
                        = 17
  BYTES
                        = 7
                        = "DEGREE KELVIN"
  UNIT
                        = 999.9
  MISSING_CONSTANT
  FORMAT
                        = "F7.1"
  DESCRIPTION
                        = "T1 SCOPE COSISCOPE TEMPERATURE MAXIMUM AT CAMERA"
                         = COL\overline{U}MN
END_OBJECT
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                         = 4
                         = "T1_SCOPE_STD"
  NAME
  DATA TYPE
                        = ASCĪI_REAL
  START_BYTE
                        = 25
  BYTES
                        = "DEGREE KELVIN"
  UNIT
```

MISSING_CONSTANT

= 999.9

```
= "F7.1"
  FORMAT
 DESCRIPTION
                        = "T1_SCOPE COSISCOPE TEMPERATURE STANDARD DEVIATION
                           AT CAMERE"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 5
                        = "T3 SCOPE_MIN"
  NAME
 DATA_TYPE
                        = ASCII_REAL
  START_BYTE
                       = 33
  BYTES
                        = 7
                        = "DEGREE KELVIN"
  UNIT
 MISSING_CONSTANT
                       = 999.9
                        = "F7.1"
  FORMAT
                        = "T3 SCOPE COSISCOPE TEMPERATURE MINIMUM AT CDPU"
  DESCRIPTION
                        = COL\overline{U}MN
END_OBJECT
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 6
                        = "T3_SCOPE_MEAN"
  NAME
  DATA_TYPE
                        = ASCII_REAL
 START_BYTE
                        = 41
  BYTES
                        = 7
                        = "DEGREE KELVIN"
  UNIT
 MISSING_CONSTANT
                       = 999.9
                        = "F7.1"
  FORMAT
                        = "T3_SCOPE COSISCOPE TEMPERATURE MEAN AT CDPU"
  DESCRIPTION
                        = COL\overline{U}MN
END_OBJECT
OBJECT
                        = COLUMN
 COLUMN_NUMBER
                        = 7
                        = "T3_SCOPE_MAX"
  NAME
  DATA_TYPE
                        = ASCII_REAL
  START_BYTE
                       = 49
                        = 7
  BYTES
                        = "DEGREE KELVIN"
  UNIT
 MISSING_CONSTANT
                       = 999.9
                        = "F7.1"
  FORMAT
                        = "T3_SCOPE COSISCOPE TEMPERATURE MAXIMUM AT CDPU"
 DESCRIPTION
END_OBJECT
                        = COL\overline{U}MN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 8
                        = "T3 SCOPE STD"
  NAME
  DATA TYPE
                        = ASCII REAL
  START_BYTE
                       = 57
 BYTES
                        = 7
                        = "DEGREE KELVIN"
  UNIT
 MISSING_CONSTANT
                        = 999.9
                        = "F7.1"
  FORMAT
                        = "T3_SCOPE COSISCOPE TEMPERATURE STANDARD DEVIATION
 DESCRIPTION
                           AT CDPU"
END_OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
                        = 9
= "T4_SCOPE_MIN"
  COLUMN_NUMBER
  NAME
  DATA TYPE
                        = ASCII_REAL
  START_BYTE
                        = 65
  BYTES
                        = 7
                        = "DEGREE KELVIN"
  UNIT
 MISSING_CONSTANT
                        = 999.9
                        = "F7.1"
  FORMAT
                        = "T4 SCOPE COSISCOPE TEMPERATURE MINIMUM AT OPTICS"
  DESCRIPTION
                        = COL\overline{U}MN
END_OBJECT
OBJECT
                        = COLUMN
                        = 10
= "T4_SCOPE_MEAN"
  COLUMN_NUMBER
  NAME
                        = ASCĪI_REAL
  DATA TYPE
  START_BYTE
                        = 73
  BYTES
                        = 7
                        = "DEGREE KELVIN"
 MISSING_CONSTANT
                        = 999.9
```

```
FORMAT
                        = "F7.1"
 DESCRIPTION
                        = "T4_SCOPE COSISCOPE TEMPERATURE MEAN AT OPTICS"
END OBJECT
                        = COL\overline{U}MN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                          11
                           "T4 SCOPE MAX"
  NAME
                        =
 DATA_TYPE
                        = ASCĪI_REAL
  START BYTE
                        = 81
  BYTES
                        = 7
                        = "DEGREE KELVIN"
  UNIT
  MISSING_CONSTANT
                        = 999.9
  FORMAT
                        = "F7.1"
                        = "T4 SCOPE COSISCOPE TEMPERATURE MAXIMUM AT OPTICS"
  DESCRIPTION
END OBJECT
                        = COL\overline{U}MN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                          12
                           "T4 SCOPE STD"
                        =
  NAME
 DATA_TYPE
START_BYTE
                        = ASCĪI_REAL
                        = 89
  BYTES
                        = 7
                        = "DEGREE KELVIN"
  UNIT
  MISSING CONSTANT
                        = 999.9
                        = "F7.1"
  FORMAT
                        = "T4_SCOPE COSISCOPE TEMPERATURE STANDARD DEVIATION
 DESCRIPTION
                            AT OPTICS"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
 COLUMN_NUMBER
                        = 13
                        = MODE
  NAME
  DATA_TYPE
                        = ASCII_INTEGER
  START_BYTE
                        = 97
 BYTES
                        = 1
  FORMAT
                        = "I1"
                        = "0 = ONLY GRAINS INFORMATION.
 DESCRIPTION
                            1 = ONE OR TWO COMPRESSED IMAGES ARE ALSO
                                GENERATED DEPENDING ON THE COMMAND WORD"
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
 COLUMN_NUMBER
                        = 14
                        = CCD CLEAN
  NAME
  DATA TYPE
                        = ASCII INTEGER
  START_BYTE
  BYTES
                        = 1
                        = "I1"
  FORMAT
  DESCRIPTION
                           "NUMBER OF ADDITIONAL CLEAN IMAGES WHICH HAVE BEEN
                            PROGRAMMED TO GET RID OF ACCUMULATED CHARGES ON
                            THE CCD. NOMINAL IS 0 FROM -20 CELSIUS DEGREE TO
                            +25 CELSIUS DEGREE OPERATING TEMPERATURE"
END_OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                        = 15
  NAME
                        = DARK
  DATA TYPE
                        = ASCII_INTEGER
  START_BYTE
                        = 101
  BYTES
                        = "I1"
  FORMAT
  DESCRIPTION
                        = "0=NO DARK CURRENT SUBTRACTION,
                            1=DARK CURRENT SUBTRACTION
                            THIS PARAMETER DEFINES WHETHER A DARK CURRENT IMAGE
                            WAS TO BE SUBTRACTED FROM THE COSISCOPE IMAGE
                            BEFORE THE IMPLEMENTATION OF THE GRAIN SEACH
                            ALGORITHM AND (IF REQUIRED BY THE COMMAND)
                            THE TRANSMISSION OF THE IMAGE(S)"
END_OBJECT
                         = COLUMN
                        = COLUMN
OBJECT.
  COLUMN_NUMBER
                        = 16
  NAME
                        = DETECTION
 DATA_TYPE
                        = ASCII_INTEGER
```

```
START BYTE
                         = 103
  BYTES
                         = 1
  FORMAT
                         = "I1"
 DESCRIPTION
                         = "0 = GRAINS ARE SEARCHED FOR AS POSITIVE ALBEDO
                                CONTRASTS
                                EACH LINE (TOWARDS THE LED) IS FIRST
                                DIFFERENTIATED, THEN GRAINS ARE SEARCHED FOR
                                AS PEAKS IN THE DIFFERENTIALS"
END OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
  COLUMN_NUMBER
                         = 17
                         = THRESHOLD
  NAME
 DATA_TYPE
                         = ASCII_INTEGER
  START_BYTE
                         = 105
 BYTES
                        = 1
                         = "I1"
  FORMAT
                         = "THE DETECTION LEVEL (0 TO 7) DEFINE THE FACTOR
  DESCRIPTION
                            ABOVE THE BACKGROUND, WHICH CONSTITUTES A DETECTION
                            FOR VALUES 1 TO 7 FACTORS 5,6,7,8,10,12,16.
                            A VALUE OF 0 GENERATES A TEST IMAGE WHICH IS
                            PROCESSED NOMINALLY."
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  {\tt COLUMN\_NUMBER}
                         = 18
                         = PACKING
  DATA TYPE
                        = ASCII_INTEGER
  START_BYTE
                        = 107
  BYTES
                         = "I1"
  FORMAT
 DESCRIPTION
                         = "IMAGE COMPRESSION MODE (0 TO 3)
                            0: BIT-PACKING (10 BITS / PIXELS
                            1: REVERSIBLE COMPRESSION
                            2: WAVELET COMPRESSION, 1 BIT/PIXEL 3: WAVELET COMPRESSION, 2 BITS/PIXEL"
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                        = 19
                         = MINUS_X_LED
  NAME
  DATA_TYPE
                        = ASCII_INTEGER
  START BYTE
                        = 109
 BYTES
                        = 1
  FORMAT
                        = "I1"
                        = "0,1,2,4 =NO -X LED USED, 3,5,6,7=-X LED USED"
 DESCRIPTION
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                        = 20
                         = PLUS X LED
  DATA TYPE
                        = ASCIT_INTEGER
  START_BYTE
                        = 111
  BYTES
                        = "I1"
  FORMAT
                         = "0,1,2,4=NO +X LED USED, 3,5,6,7=+X LED USED"
  DESCRIPTION
END_OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
  COLUMN_NUMBER
                         = 21
                        = PLUS_X_LED_ACQ_TIME
  NAME
 DATA_TYPE
                         = ASCIT_INTEGER
  START_BYTE
                        = 113
  BYTES
                        = 5
                         = "MILLISECOND"
  UNTT
                         = "15"
  FORMAT
                         = "PLUS X LED ACQUISITION TIME IN MS, DEFAULT 300 MS"
  DESCRIPTION
END_OBJECT
                         = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 22
  NAME
                        = MINUS X LED ACQ TIME
  DATA TYPE
                        = ASCII INTEGER
  START_BYTE
                        = 119
```

```
BYTES
                      = 5
                      = "MILLISECOND"
 UNIT
                      = "I5"
 FORMAT
                      = "MINUS X LED ACQUISITION TIME IN MS, DEFAULT 300 MS"
 DESCRIPTION
                      = COLUMN
END_OBJECT
                      = COLUMN
OBJECT
 COLUMN_NUMBER
                      = 23
                  = PLUS_X_LED_BIAS
= ASCII_INTEGER
 NAME
 DATA TYPE
 START_BYTE
                      = 125
 BYTES
                      = 3
                      = "I3"
 FORMAT
                      = "PLUS X LED BIAS"
 DESCRIPTION
END OBJECT
                      = COLUMN
OBJECT
                      = COLUMN
                = 24
= MINUS_X_LED_BIAS
= ASCII_INTEGER
 COLUMN_NUMBER
 NAME
 DATA_TYPE
START_BYTE
 BYTES
                      = 3
                      = "I3"
 FORMAT
                      = "MINUS X LED BIAS"
 DESCRIPTION
                      = COLUMN
END_OBJECT
OBJECT
                      = COLUMN
                = 25
= PLI
 COLUMN_NUMBER
                      = PLUS_X_LED_GAIN
 NAME
 DATA_TYPE
                      = ASCIT_INTEGER
                     = 133
 START_BYTE
 BYTES
                     = 3
 FORMAT
                      = "I3"
                    = "PLUS X LED GAIN"
 DESCRIPTION
                      = COLUMN
END_OBJECT
OBJECT
                     = COLUMN
 COLUMN_NUMBER = 26
                      = MINUS_X_LED_GAIN
 NAME
                     = ASCII_INTEGER
 DATA TYPE
 START_BYTE
                     = 137
 BYTES
                      = 3
                     = "I3"
 FORMAT
                    = "MINUS X LED GAIN"
 DESCRIPTION
END OBJECT
                      = COLUMN
OBJECT
                      = COLUMN
 COLUMN_NUMBER
                      = 27
                     = PLUS_X_CAL_QUALITY
 NAME
                     = ASCII_INTEGER
 DATA_TYPE
 START BYTE
                      = 141
                     = 5
 BYTES
                      = "I5"
 FORMAT
 MISSING_CONSTANT
                      = 43960
 DESCRIPTION
                      = "PLUS X LED CALIBRATION STRIP POSITION QUALITY"
                      = COLUMN
END_OBJECT
                      = COLUMN
OBJECT
 COLUMN_NUMBER
                      = 28
                      = PLUS_X_AX
 NAME
 DATA TYPE
                     = ASCIT_INTEGER
                     = 147
 START_BYTE
 BYTES
                      = 5
                      = "I5"
 FORMAT
 MISSING_CONSTANT
                      = 43960
 DESCRIPTION
                      = "PLUS X LED A DOT X POSITION"
END_OBJECT
                      = COLUMN
OBJECT
                      = COLUMN
 COLUMN_NUMBER
                      = 29
                      = PLUS_X_AY
 NAME
 DATA_TYPE
                      = ASCII_INTEGER
 START BYTE
                      = 153
                      = 5
 BYTES
```

```
= "I5"
  FORMAT
 MISSING CONSTANT
                        = 43960
  DESCRIPTION
                        = "PLUS X LED A DOT Y POSITION"
END OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 30
                        = PLUS_X_BX
  NAME
  DATA TYPE
                        = ASCII_INTEGER
  START_BYTE
                        = 159
 BYTES
                        = 5
                        = "I5"
  FORMAT
 MISSING CONSTANT
                        = 43960
                        = "PLUS X LED B DOT X POSITION"
 DESCRIPTION
END OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
  COLUMN_NUMBER
                         = 31
                        = PLUS_X_BY
  NAME
 DATA_TYPE
START_BYTE
                        = ASCIT_INTEGER
                        = 165
                        = 5
= "I5"
  BYTES
  FORMAT
  MISSING CONSTANT
                         = 43960
 DESCRIPTION
                        = "PLUS X LED B DOT Y POSITION"
                         = COLUMN
END_OBJECT
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                        = 32
                        = PLUS_X_LABEL
= ASCII_INTEGER
  NAME
  DATA TYPE
  START_BYTE
                         = 171
  BYTES
                         = 5
                        = "I5"
  FORMAT
 MISSING_CONSTANT
                         = 43960
                         = "PLUS X LED SUBSTRATE LABEL
  DESCRIPTION
                            THE SUBSTRATE ID:S MATCH THE SUBSTRATE LABELS
                            IN THE REFERENCE STRIP WITH THE FOLLOWING TABLE:
                            1C1 = 63
                            2C1 = 95
                            3C1 = 111
                            1C2 = 119
                            2C2 = 123
                            3C2 = 125
                            1C3 = 126
                            2C3 = 159
                            3C3 = 175
                            1C4 = 183
                            2C4 = 187
                            3C4 = 189
                            1C5 = 190
                            2C5 = 207
                            3C5 = 215
                            1C6 = 219
                            2C6 = 221
                            3C6 = 222
                            1C7 = 231
                            2C7 = 235
                            3C7 = 237
                            1C8 = 238
                            2C8 = 243
                            3C8 = 245
                            109 = 246
                            2C9 = 249
                            3C9 = 250
                            1CA = 252
                            2CA = 287
                            3CA = 303
                            1CB = 311
                            2CB = 315
                            3CB = 317
                            1CC = 318
                            2CC = 335
                            3CC = 343
```

```
1CD = 347
                            2CD = 349
                            3CD = 350
                            1CE = 359
                            2CE = 363
                            3CE = 365
                            1CF = 366
                            2CF = 371
3CF = 373
                            1D0 = 374
                            2D0 = 377
                            3D0 = 378
                            1D1 = 380
                            2D1 = 399
                            3D1 = 407
                            1D2 = 411
                            2D2 = 413
                            3D2 = 414
                            1D3 = 423
                            2D3 = 427
                            3D3 = 429
                            1D4 = 430
                            2D4 = 435
                            3D4 = 437
                            1D5 = 438
                            2D5 = 441
                            3D5 = 442
                            1D6 = 444
                            2D6 = 455
                            3D6 = 459
                            1D7 = 461
                            2D7 = 462
                            3D7 = 467
                            1D8 = 469
                            2D8 = 470
                            3D8 = 473"
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                         = 33
                         = PLUS_X_SUBST_QUALITY
= ASCII_INTEGER
  NAME
  DATA_TYPE
  START_BYTE
                        = 177
                        = 5
= "I5"
  BYTES
  FORMAT
  MISSING CONSTANT
                        = 43960
                         = "PLUS X LED SUBSTRACE POSITION QUALITY"
  DESCRIPTION
END_OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
  COLUMN NUMBER
                         = 34
                        = PLUS_X_CX
= ASCII_INTEGER
  NAME
  DATA_TYPE
  START_BYTE
                         = 183
  BYTES
  FORMAT
                         = "I5"
  MISSING_CONSTANT
                        = 43960
  DESCRIPTION
                         = "PLUS X LED C DOT X POSITION"
END_OBJECT
                         = COLUMN
                         = COLUMN
OBJECT
  COLUMN_NUMBER
                         = 35
                         = PLUS_X_CY
  NAME
  DATA TYPE
                        = ASCIT_INTEGER
  START_BYTE
                         = 189
  BYTES
  FORMAT
                        = "I5"
  MISSING_CONSTANT
                         = 43960
                         = "PLUS X LED C DOT Y POSITION"
  DESCRIPTION
END_OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                         = 36
  NAME
                         = PLUS_X_DX
```

```
DATA TYPE
                        = ASCII_INTEGER
  START_BYTE
                        = 195
  BYTES
                        = 5
                        = "I5"
  FORMAT
 MISSING_CONSTANT
                        = 43960
  DESCRIPTION
                        = "PLUS X LED D DOT X POSITION"
                        = COLUMN
END_OBJECT
OBJECT
                        = COLUMN
  COLUMN NUMBER
                       = 37
                       = PLUS X DY
  NAME
  DATA_TYPE
                       = ASCII_INTEGER
  START_BYTE
                       = 201
 BYTES
                        = 5
                        = "I5"
  FORMAT
                       = 43960
 MISSING CONSTANT
                       = "PLUS X LED D DOT Y POSITION"
 DESCRIPTION
END_OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                       = 38
                       = PLUS_X_TARGET_LABEL
= ASCII_INTEGER
  NAME
 DATA_TYPE
  START BYTE
                       = 207
  BYTES
                       = 5
                       = "I5"
  FORMAT
 MISSING_CONSTANT
                       = 43960
 DESCRIPTION
                       = "PLUS X LED TARGET LABEL (N/A WITH FLIGHT TARGETS)"
                        = COLUMN
END_OBJECT
                       = COLUMN
OBJECT
  COLUMN_NUMBER
                       = 39
  NAME
                       = MINUS_X_CAL_QUALITY
                       = ASCII_INTEGER
  DATA TYPE
  START_BYTE
                       = 213
  BYTES
                       = "I5"
 FORMAT
                       = 43960
 MISSING_CONSTANT
                       = "MINUS X LED CALIBRATION STRIP POSITION QUALITY"
  DESCRIPTION
END_OBJECT
                        = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                       = 40
                       = MINUS_X_AX
  NAME
  DATA TYPE
                       = ASCII INTEGER
  START_BYTE
                       = 219
                       = 5
= "I5"
  BYTES
  FORMAT
 MISSING CONSTANT
                       = 43960
                        = "MINUS X LED A DOT X POSITION"
 DESCRIPTION
END OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                        = 41
                       = MINUS X AY
  NAME
 DATA_TYPE
START_BYTE
                       = ASCII_INTEGER
                       = 225
  BYTES
                        = "I5"
  FORMAT
  MISSING_CONSTANT
                        = 43960
 DESCRIPTION
                       = "MINUS X LED A DOT Y POSITION"
                        = COLUMN
END_OBJECT
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                        = 42
                        = MINUS_X_BX
  NAME
  DATA TYPE
                       = ASCII_INTEGER
  START_BYTE
                        = 231
  BYTES
                        = 5
                       = "I5"
  FORMAT
                       = 43960
 MISSING CONSTANT
 DESCRIPTION
                        = "MINUS X LED B DOT X POSITION"
END OBJECT
                        = COLUMN
```

```
OBJECT
                         = COLUMN
  COLUMN_NUMBER
                         = 43
                         = MINUS X BY
  NAME
  DATA TYPE
                         = ASCII_INTEGER
  START_BYTE
                         = 237
                         = 5
= "I5"
  BYTES
  FORMAT
  MISSING_CONSTANT
                         = 43960
                         = "MINUS X LED B DOT Y POSITION"
  DESCRIPTION
END OBJECT
                         = COLUMN
OBJECT
                         = COLUMN
  {\tt COLUMN\_NUMBER}
                         = 44
                         = MINUS_X_LABEL
  NAME
  DATA TYPE
                         = ASCII_INTEGER
  START_BYTE
                         = 243
  BYTES
                         = 5
                         = "15"
  FORMAT
  MISSING CONSTANT
                         = 43960
  DESCRIPTION
                         = "MINUS X LED SUBSTRATE LABEL
                             THE SUBSTRATE ID:S MATCH THE SUBSTRATE LABELS
                             IN THE REFERENCE STRIP WITH THE FOLLOWING TABLE:
                             1C1 = 63
                             2C1 = 95
                             3C1 = 111
                             1C2 = 119
                             2C2 = 123
                             3C2 = 125
                             1C3 = 126
                             2C3 = 159
                             3C3 = 175
                             1C4 = 183
                             2C4 = 187
                             3C4 = 189
                             1C5 = 190
                             2C5 = 207
                             3C5 = 215
                             1C6 = 219
                             2C6 = 221
                             3C6 = 222
                             1C7 = 231
2C7 = 235
                             3C7 = 237
                             108 = 238
                             2C8 = 243
                             3C8 = 245
                             1C9 = 246
                             2C9 = 249
                             3C9 = 250
                             1CA = 252
                             2CA = 287
                             3CA = 303
                             1CB = 311
                             2CB = 315
                             3CB = 317
                             1CC = 318
2CC = 335
                             3CC = 343
                             1CD = 347
                             2CD = 349
                             3CD = 350
                             1CE = 359
                             2CE = 363
                             3CE = 365
                             1CF = 366
2CF = 371
                             3CF = 373
                             1D0 = 374
                             2D0 = 377
                             3D0 = 378
                             1D1 = 380
                             2D1 = 399
                             3D1 = 407
                             1D2 = 411
```

```
2D2 = 413
                           3D2 = 414
                           1D3 = 423
                           2D3 = 427
                           3D3 = 429
                           1D4 = 430
                           2D4 = 435
                           3D4 = 437
                           1D5 = 438
                           2D5 = 441
                           3D5 = 442
                           1D6 = 444
                           2D6 = 455
                           3D6 = 459
                           1D7 = 461
                           2D7 = 462
                           3D7 = 467
                           1D8 = 469
                           2D8 = 470
                           3D8 = 473"
END_OBJECT
                        = COLUMN
                       = COLUMN
OBJECT
  COLUMN NUMBER
                       = 45
                       = MINUS_X_SUBST_QUALITY
  NAME
 DATA_TYPE
                       = ASCII_INTEGER
  START_BYTE
                       = 249
  BYTES
                       = 5
                       = "I5"
  FORMAT
  MISSING CONSTANT
                       = 43960
 DESCRIPTION
                       = "MINUS X LED SUBSTRACE POSITION QUALITY"
                       = COLUMN
END_OBJECT
OBJECT
                       = COLUMN
  COLUMN_NUMBER
                       = 46
  NAME
                       = MINUS X CX
  DATA TYPE
                       = ASCII_INTEGER
  START_BYTE
                       = 255
  BYTES
                       = 5
  FORMAT
                       = "I5"
  MISSING_CONSTANT
                       = 43960
                       = "MINUS X LED C DOT X POSITION"
 DESCRIPTION
END_OBJECT
                       = COLUMN
OBJECT
                       = COLUMN
  COLUMN_NUMBER
                       = 47
  NAME
                       = MINUS_X_CY
  DATA_TYPE
                       = ASCII_INTEGER
  START_BYTE
                       = 261
                       = 5
= "I5"
  BYTES
  FORMAT
                     = 43960
 MISSING CONSTANT
                       = "MINUS X LED C DOT Y POSITION"
 DESCRIPTION
END_OBJECT
                       = COLUMN
                       = COLUMN
OBJECT
  COLUMN_NUMBER
                       = 48
  NAME
                       = MINUS X DX
 DATA_TYPE
                       = ASCII_INTEGER
  START_BYTE
                       = 267
  BYTES
                       = 5
                       = "I5"
  FORMAT
 MISSING_CONSTANT
                       = 43960
 DESCRIPTION
                       = "MINUS X LED D DOT X POSITION"
END_OBJECT
                       = COLUMN
OBJECT
                       = COLUMN
  COLUMN_NUMBER
                       = 49
                       = MINUS_X_DY
  NAME
  DATA TYPE
                       = ASCII_INTEGER
  START_BYTE
                       = 273
                       = 5
= "I5"
  BYTES
  FORMAT
  MISSING_CONSTANT
                       = 43960
```

```
= "MINUS X LED D DOT Y POSITION"
 DESCRIPTION
END_OBJECT
                       = COLUMN
OBJECT
                       = COLUMN
  COLUMN_NUMBER
                       = 50
  NAME
                       = MINUS X TARGET LABEL
  DATA TYPE
                       = ASCII_INTEGER
  START_BYTE
                       = 279
  BYTES
                       = 5
                       = "I5"
 FORMAT
 MISSING CONSTANT
                       = 43960
 DESCRIPTION
                       = "MINUS X LED TARGET LABEL (N/A WITH FLIGHT TARGETS)"
END_OBJECT
                       = COLUMN
OBJECT
                        = COLUMN
  COLUMN_NUMBER
                       = 51
                       = X OFFSET
  NAME
  DATA_TYPE
                       = ASCII_REAL
  START_BYTE
                       = 285
 BYTES
                       = 9
                       = "MICROMETER"
 UNIT
                       = "F9.2"
  FORMAT
 DESCRIPTION
                       = "SUBSTRATE OFFSET IN X"
END OBJECT
                        = COLUMN
                        = COLUMN
OBJECT
  COLUMN_NUMBER
                       = 52
                       = Y_0FFSET
  NAME
 DATA_TYPE
START_BYTE
                       = ASCII_REAL
                       = 295
  BYTES
                       = 9
                       = "MICROMETER"
 UNIT
  FORMAT
                       = "F9.2"
 DESCRIPTION
                       = "SUBSTRATE OFFSET IN Y"
                       = COLUMN
END_OBJECT
OBJECT
                       = COLUMN
  COLUMN_NUMBER
                       = 53
                       = X_ORIGIN
  NAME
                       = ASCII_REAL
  DATA TYPE
  START_BYTE
                       = 305
  BYTES
                       = 9
 UNIT
                       = "MICROMETER"
                       = "F9.2"
  FORMAT
                       = "SUBSTRATE ORIGIN X IN COSISCOPE FIELD OF VIEW"
 DESCRIPTION
                       = COLUMN
END_OBJECT
OBJECT
                       = COLUMN
  COLUMN_NUMBER
                       = 53
                       = Y_ORIGIN
  NAME
  DATA TYPE
                       = ASCII REAL
  START_BYTE
                       = 315
  BYTES
                       = 9
  UNIT
                       = "MICROMETER"
  FORMAT
                       = "F9.2"
                       = "SUBSTRATE ORIGIN Y IN COSISCOPE FIELD OF VIEW"
  DESCRIPTION
                       = COLUMN
END_OBJECT
                       = COLUMN
OBJECT
  COLUMN_NUMBER
                       = 54
                       = ROTATION
  NAME
 DATA_TYPE
                       = ASCII_REAL
  START_BYTE
                       = 325
  BYTES
                       = 8
                       = "DEGREE"
  UNTT
                       = "F8.4"
  FORMAT
 DESCRIPTION
                       = "SUBSTRATE ROTATION ANGLE"
                       = COLUMN
END_OBJECT
```

4.3.12 Substrate history ancillary product

4.3.12.1General description

Substrate history product contains information about substrate storage and expose periods, cleaning and heating actions, COSISCOPE camera images and grains lists and any spectra taken. The history product contains history from the moment substrates were installed in the COSIMA flight instrument.

4.3.12.2Label example

```
PDS VERSION ID
                                       = PDS3
LABEL_REVISTON_NOTE
                                       = "V1.1"
/* FILE FORMAT */
RECORD_TYPE
                                       = FIXED_LENGTH
RECORD BYTES
                                       = 148
FILE_RECORDS
LABEL_RECORDS
                                            67
                                       = 18
/* POINTER TO DATA OBJECT */
^HISTORY TABLE
                                       = 19
/* GENERAL DATA DESCRIPTION PARAMETERS */
                                      = "CS_2D8_SUBSTRATE_HIST.TAB"
FILE_NAME
DATA_SET_ID
                                       = "R0-CAL-COSIMA-3-V2.0"
DATA SET NAME
                                      = "ROSETTA-ORBITER CAL COSIMA 3 V2.0"
PRODUCT_ID
PRODUCT_CREATION_TIME
                                       = "CS_2D8_SUBSTRATE_HIST"
                                       = 2008-11-12T09:15:54
PRODUCT TYPE
                                       = "ANCDR"
{\tt PROCESS\overline{I}NG\_LEVEL\_ID}
                                       = 6
MISSION ID
                                       = "ROSETTA"
                                      = "INTERNATIONAL ROSETTA MISSION"
MISSION NAME
MISSION PHASE NAME
                                      = "N/A"
                                      = "R0"
INSTRUMENT HOST ID
INSTRUMENT_HOST_NAME
                                      = "ROSETTA-ORBITER"
INSTRUMENT_ID
INSTRUMENT_NAME
                                      = "COSIMA"
                                      = "COMETARY SECONDARY ION MASS ANALYZER"
INSTRUMENT TYPE
                                      = "MASS SPECTROMETER"
INSTRUMENT_MODE_ID
INSTRUMENT_MODE_DESC
                                      = "N/A"
                                      = "N/A"
TARGET NAME
                                      = "CALIBRATION"
TARGET_TYPE
START_TIME
STOP_TIME
                                       = "CALIBRATION"
                                      = 2002 - 05 - 29T00 : 00 : 00
                                       = 2008-07-24T00:00:00
SPACECRAFT_CLOCK_START_COUNT
SPACECRAFT_CLOCK_STOP_COUNT
                                      = "N/A"
= "1/0175478364.35517"
SC\_SUN\_POS\overline{I}TION\_\overline{V}ECTO\overline{R}
                                      = "N/A"
SC_TARGET_POSITION_VECTOR
SC_TARGET_VELOCITY_VECTOR
SPACECRAFT_ALTITUDE
                                      = "N/A"
                                      = "N/A"
                                      = "N/A"
SUB_SPACECRAFT_LATITUDE
SUB_SPACECRAFT_LONGITUDE
                                      = "N/A"
                                      = "N/A"
PRODUCER ID
                                      = "FMI"
PRODUCER_FULL_NAME
PRODUCER_INSTITUTION_NAME
                                      = "JOHAN SILEN"
                                      = "FINNISH METEOROLOGICAL INSTITUTE"
DATA QUALITY ID
                                       = -1
                                       = "-1 = not checked"
DATA_QUALITY_DESC
                                       = "2D8"
ROSETTA: COSIMA_SUBSTRATE_ID
                                      = "Silver, blank"
ROSETTA: COSIMA SUBSTRATE DESC
OBJECT
                                       = HISTORY TABLE
  NAME
                                       = SUBSTRATE HISTORY
  INTERCHANGE FORMAT
                                       = ASCII
  ROWS
                                       = 49
  COLUMNS
                                      = 9
  ROW_BYTES
                                      = 148
  ^STRUCTURE
                                      = "COSIMA_HISTORY.FMT"
                                       = "SUBSTRATE HISTORY"
  DESCRIPTION
                                       = HISTORY_TABLE
END_OBJECT
```

COSIMA_HISTORY.FMT:

END

```
OBJECT
                                  = COLUMN
  COLUMN NUMBER
                                  = 1
  NAME
                                  = UTC START DATE
  DATA TYPE
                                  = DAT\overline{E}
  START_BYTE
                                  = 1
  BYTES
                                  = 19
 FORMAT
                                  = "A19"
                                  = "START TIME IN UTC"
  DESCRIPTION
END OBJECT
                                  = COLUMN
0BJECT
                                  = COLUMN
  COLUMN NUMBER
                                  = 2
  NAME
                                  = UTC STOP DATE
  DATA TYPE
                                  = DAT\overline{E}
  START_BYTE
                                  = 21
  BYTES
                                  = 19
                                  = "A19"
  FORMAT
                                  = "STOP TIME IN UTC"
  DESCRIPTION
END_OBJECT
                                  = COLUMN
OBJECT
                                  = COLUMN
  COLUMN_NUMBER
                                  = 3
  NAME
                                  = TIME
  DATA TYPE
                                  = ASCII_INTEGER
  START_BYTE
                                  = 41
  BYTES
                                  = 10
                                  = "SECOND"
  UNIT
  {\tt MISSING\_CONSTANT}
                                  = -1
  FORMAT
                                  = "I10"
                                  = "TIME SPENT IN THE POSITION IN SECONDS"
  DESCRIPTION
                                  = COLUMN
END_OBJECT
OBJECT
                                  = COLUMN
  COLUMN NUMBER
                                  = 4
                                  = POSITION
  NAME
  DATA_TYPE
                                  = CHARACTER
  START_BYTE
                                  = 53
  BYTES
                                  = 9
  FORMAT
                                  = "A9"
  DESCRIPTION
                                  = "POSITION, POSSIBLE VALUES ARE
                                        STORAGE, in target storage IMAGE, substrate image
                                         GRAINS, dust position list
                                      PEAKS, peak list acquisition
SCAN, total count acquition
SPECTRUM, spectrum acquistion
                                         EXPOSE, exposed to the outside CLEAN, at beam cleaning position
                                     CHEMISTRY, at heating station"
END OBJECT
                                  = COLUMN
OBJECT
                                  = COLUMN
  COLUMN NUMBER
                                  = 5
                                  = X COORDINATE
  NAME
  DATA TYPE
                                  = ASCII INTEGER
  START_BYTE
                                  = 64
  BYTES
                                  = 5
  UNIT
                                  = "MICROMETER"
  MISSING_CONSTANT
                                  = -1
                                  = "I5"
  FORMAT
  DESCRIPTION
                                  = "SUBSTRATE X-COORDINATE IN MICROMETERS,
                                     ZERO IS AT LEFT"
                                  = COLUMN
END OBJECT
OBJ<u>E</u>CT
                                  = COLUMN
  COLUMN_NUMBER
                                  = 6
                                  = Y_COORDINATE
  NAME
  DATA_TYPE
                                  = ASCII_INTEGER
  START_BYTE
                                  = 70
  BYTFS
                                  = 5
  UNIT
                                  = "MICROMETER"
  MISSING_CONSTANT
                                  = -1
                                  = "I5"
  FORMAT
                                  = "SUBSTRATE Y-COORDINATE IN MICROMETERS,
 DESCRIPTION
                                     ZERO IS AT BOTTOM"
END OBJECT
                                  = COLUMN
0BJECT
                                  = COLUMN
  COLUMN NUMBER
                                  = 7
```

NAME = TIP CURRENT DATA_TYPE = ASCII_INTEGER START_BYTE = 76 **BYTES** = 3 ${\tt MISSING_CONSTANT}$ = -99**FORMAT** = "I3" = "MICROAMPERE" UNIT DESCRIPTION = "INDIUM BEAM TIP CURRENT" END OBJECT = COLUMN **OBJECT** = COLUMN COLUMN NUMBER = 8 NAME = SCIENCE_FILENAME DATA TYPE = CHARACTER START_BYTE = 81 **BYTES** = "A31" **FORMAT** DESCRIPTION = "SCIENCE DATA LABEL FILENAME" END_OBJECT = COLUMN = COLUMN 0BJECT COLUMN_NUMBER = 9 = HOUSEKEEPING_FILENAME NAME DATA TYPE = CHARACTER $STAR\overline{T}_BYTE$ = 115 **BYTES** = 31 **FORMAT** = "A31" **DESCRIPTION** = "SCIENCE DATA RELATED HOUSEKEEPING LABEL FILENAME" END_OBJECT = COLUMN

5 Appendix: Directory Listing of Data Set RO-CAL-COSIMA-3-V3.0

TOP-LEVEL-DIRECTORY - AAREADME.TXT This file - VOLDESC.CAT Description of the data volume - [CATALOG] The directory containing information about COSIMA calibration data set |- CATINFO.TXT Info about CATALOG directory contents |- MISSION.CAT Rosetta mission description, provided by Rosetta project |- INSTHOST.CAT Rosetta spacecraft description, provided by Rosetta project |- INST.CAT COSIMA instrument description |- DATASET.CAT Dataset description - SOFT.CAT Software description. Empty for COSIMA datasets |- PERSON.CAT Dataset provider contact information |- REF.CAT References |- TARGET.CAT Target descriptions [DATA] The directory for instrument data products

- [SUB_YXX]

Substrate YXX data products, where Y is substrate target holder position 1=top, 2=middle, 3=bottom. XX is target holder ID number, range from C1 to D8, where counting is done in hexadecimal

- CS YXX SUBSTRATE HIST.TAB

Substrate history product, where Y is substrate target holder position 1=top, 2=middle, 3=bottom. XX is target holder ID number, range from C1 to D8, where counting is done in hexadecimal

- CS_YXX_YYYYMMDDTHHMMSS_SP_Z.TAB

Substrate spectrum, where Y is substrate target holder position 1=top, 2=middle, 3=bottom. XX is target holder ID number, range from C1 to D8, where counting is done in hexadecimal. YYYYMMDDTHHMMSS is the date. Z is either P for positive or N for negative spectrum.

- CS YXX YYYYMMDDTHHMMSS PK Z.TAB

Substrate peak list, where Y is substrate target holder position 1=top, 2=middle, 3=bottom. XX is target holder ID number, range from C1 to D8, where counting is done in hexadecimal. YYYYMMDDTHHMMSS is the date. Z is either P for positive or N for negative peak list.

- CS YXX YYYYMMDDTHHMMSS S HK.TAB

Substrate spectrum or peak list housekeeping data, where Y is substrate target holder position 1=top, 2=middle, 3=bottom. XX is target holder ID number, range from C1 to D8, where counting is done in hexadecimal. YYYYMMDDTHHMMSS is the date.

- CS_YXX_YYYYMMDDTHHMMSS_SCAN.TAB

Substrate scan data, where Y is substrate target holder position 1=top, 2=middle, 3=bottom. XX is target holder ID number, range from C1 to D8, where counting is done in hexadecimal. YYYYMMDDTHHMMSS is the date.

- CS_YXX_YYYYMMDDTHHMMSS_SCHK.TAB

Substrate scan housekeeping data, where Y is substrate target holder position 1=top, 2=middle, 3=bottom. XX is target holder ID number, range from C1 to D8, where counting is done in hexadecimal. YYYYMMDDTHHMMSS is the date.

- CS_YXX_YYYYMMDDTHHMMSS_HEAT.TAB

Substrate heating data, where Y is substrate target holder position 1=top, 2=middle, 3=bottom. XX is target holder ID number, range from C1 to D8, where counting is done in hexadecimal. YYYYMMDDTHHMMSS is the date.

- CS_YXX_YYYYMMDDTHHMMSS_CLEA.TAB

Substrate cleaning data, where Y is substrate target holder position 1=top, 2=middle, 3=bottom. XX is target holder ID number, range from C1 to D8, where counting is done in hexadecimal. YYYYMMDDTHHMMSS is the date.

- CS YXX YYYYMMDDTHHMMSS CLHK.TAB

Substrate cleaning housekeeping data, where Y is substrate target holder position 1=top, 2=middle, 3=bottom. XX is target holder ID number, range from C1 to D8, where counting is done in hexadecimal. YYYYMMDDTHHMMSS is the date.

- CS_YXX_YYYYMMDDTHHMMSS_GR__.TAB

Substrate grain list, where Y is substrate target holder position 1=top, 2=middle, 3=bottom. XX is target holder ID number, range from C1 to D8, where counting is done in hexadecimal. YYYYMMDDTHHMMSS is the date.

- CS YXX YYYYMMDDTHHMMSS IM Z.FIT

Substrate FITS-format image, where Y is substrate target holder position 1=top, 2=middle, 3=bottom. XX is target holder ID number, range from C1 to D8, where counting is done in hexadecimal. YYYYMMDDTHHMMSS is the date. ZZ is either P for right (plus) side led or M (minus) for left side led illumination.

- CS YXX YYYYMMDDTHHMMSS G HK.TAB

Substrate grain list or image housekeeping data, where Y is substrate target holder position 1=top, 2=middle, 3=bottom. XX is target holder ID number, range from C1 to D8, where counting is done in hexadecimal. YYYYMMDDTHHMMSS is

ļ I I	the date.
- [DOCUMENT]	The directory for documentation
- DOCINFO.TXT	Info about DOCUMENT directory contents
- COSIMASIS.ASC	COSIMA PDS interface description in ASCII format
- COSIMASIS.PDF	COSIMA PDS interface description in PDF format
- COSIMASISXXX.JPG	COSIMA PDS interface description figures for ASCII version, XXX is gives the figure number in the form 001, 002
- COSIMAPAPER.ASC	COSIMA instrument paper in ASCII format
- COSIMAPAPER.PDF	COSIMA instrument paper in PDF format
- COSIMAPAPERXXX.JPG CO	OSIMA instrument paper images in JPG format.
- [INDEX]	The directory for index files
- INDEX.LBL	A PDS detached label describing INDEX.TAB
- INDEX.TAB	Tabular summary of the data files
- INDXINFO.TXT	Info about INDEX directory contents
- [LABEL]	The directory for formatting files used by the attached labels
- LABINFO.TXT	Info about LABEL directory contents
- COSIMA_HISTORY.FMT	Substrate history column object definitions
- COSIMA_SPECTRUM_DATA.F	MT Spectrum column object definitions
- COSIMA_SPECTRUM_HK.FMT	Spectrum housekeeping statistics column object definitions
- COSIMA_SPECTRUM_PEAKS.I	FMT Spectrum peak data column object definitions
- COSIMA_SPECTRUM_PEAK_S	CALE.FMT Spectrum peak data scaling column object definitions
- COSIMA_SPECTRUM_TDC_CALIB.FMT	

Spectrum time to digital unit temperature calibration result column object definitions

- COSIMA_SPECTRUM_TDC_TIMING.FMT

Spectrum time to digital unit timing setup column object

definitions

- COSIMA_CLEANING.FMT Substrate cleaning column

object definitions

- COSIMA_HEATING_DATA.FMT

Substrate heating data column

object definitions

- COSIMA_HEATING_SETUP.FMT

Substrate heating setup column

object definitions

|- COSIMA_SCAN_DATA.FMT | Substrate scan column

object definitions

- COSISCOPE_GRAINS.FMT Cosiscope grain search result

column object definitions

- COSISCOPE HK.FMT Cosiscope housekeeping statistics

column object definitions